

SIEMENS

AT Command Set Siemens Cellular Engines



TC35 Module
TC37 Module
TC35 Terminal

Version: 02.10
DocID: TC35-ATC-01-V02.10

Wireless Modules

Document Name: **AT Command Set**
Siemens Cellular Engines

Version: **02.10**
Date: **23.05.2001**

Technical Support: wm.support@mch.siemens.de

Doc Id: **TC35-ATC-01-V02.10**
Status: **Released**

Copying of this document and giving it to others and the use or communication of the contents thereof, are forbidden without express authority. Offenders are liable to the payment of damages. All rights reserved in the event of grant of a patent or the registration of a utility model or design.

Copyright © Siemens AG 2001

Contents

0	Version History.....	7
1	Introduction	8
1.1	Conventions	8
1.2	Restrictions	9
1.3	Supported character sets	10
1.4	Autobauding	10
2	Standard V.25ter AT Commands.....	11
2.1	A/ Repeat previous command line	11
2.2	+++ Switch from data mode to command mode	11
2.3	AT\Qn Flowcontrol	12
2.4	ATA Answer a call.....	12
2.5	ATD Mobile originated call to dial a number	13
2.6	ATD<mem><n> Originate call to phone number <n> in memory <mem>	14
2.7	ATD<n> Originate call to phone number in current memory	15
2.8	ATD<str> Originate call to phone number in memory with corresponding field	16
2.9	ATDI Mobile originated call to dialable ISDN number <n>	17
2.10	ATDL Redial last telephone number used	18
2.11	ATE Enable command echo	19
2.12	ATH Disconnect existing connection.....	19
2.13	ATI Display product identification information	20
2.14	ATL Set monitor speaker loudness	20
2.15	ATM Set monitor speaker mode	20
2.16	ATO Switch from command mode to data mode	20
2.17	ATQ Set result code presentation mode	21
2.18	ATP Select pulse dialling.....	21
2.19	ATS0 Set number of rings before automatically answering the call	21
2.20	ATS3 Write command line termination character	22
2.21	ATS4 Set response formatting character	22
2.22	ATS5 Write command line editing character.....	22
2.23	ATS6 Set pause before blind dialling	23
2.24	ATS7 Set number of seconds to wait for connection completion	23
2.25	ATS8 Set number of seconds to wait for comma dial modifier	23
2.26	ATS10 Set disconnect delay after indicating the absence of data carrier	24
2.27	ATS18 Extended error report	24
2.28	ATT Select tone dialling	24
2.29	ATV Set result code format mode	25
2.30	ATX Set CONNECT result code format and call monitoring.....	25
2.31	ATZ Set all current parameters to user defined profile	26
2.32	AT&C Set circuit Data Carrier Detect (DCD) function mode.....	26
2.33	AT&D Set circuit Data Terminal Ready (DTR) function mode	26
2.34	AT&F Set all current parameters to manufacturer defaults.....	27
2.35	AT&S Set circuit Data Set Ready (DSR) function mode.....	27
2.36	AT&V Display current configuration	28
2.37	AT+GCAP Request complete TA capabilities list	29
2.38	AT+GMI Request manufacturer identification	29
2.39	AT+GMM Request TA model identification	29
2.40	AT+GMR Request TA revision identification of software status	30
2.41	AT+GSN Request TA serial number identification(IMEI).....	30
2.42	AT+ILRR Set TE-TA local rate reporting.....	31
2.43	AT+IPR Set fixed local rate	32

3	AT Commands for FAX	34
3.1	AT+FBADLIN Bad Line Threshold	34
3.2	AT+FBADMUL Error Threshold Multiplier	35
3.3	AT+FBOR Query data bit order	35
3.4	AT+FCIG Query or set the Local polling id	36
3.5	AT+FCLASS Fax: Select, read or test service class	36
3.6	AT+FCQ Copy Quality Checking	37
3.7	AT+FCR Capability to receive	37
3.8	AT+FDCC Query or set capabilities	38
3.9	AT+FDFFC Data Compression Format Conversion	39
3.10	AT+FDIS Query or set session parameters	40
3.11	AT+FDR Begin or continue phase C data reception	41
3.12	AT+FDT Data Transmission	41
3.13	AT+FET End a page or document	42
3.14	AT+FK Kill operation, orderly FAX abort	42
3.15	AT+FLID Query or set the Local Id setting capabilities	42
3.16	AT+FMDL identify Product Model	43
3.17	AT+FMFR Request Manufacturer Identification	43
3.18	AT+FOPT Set bit order independently	43
3.19	AT+FPHCTO DTE Phase C Response Timeout	44
3.20	AT+FREV Identify Product Revision	44
3.21	AT+FRH Receive Data Using HDLC Framing	44
3.22	AT+FRM Receive Data	45
3.23	AT+FRS Receive Silence	45
3.24	AT+FTH Transmit Data Using HDLC Framing	45
3.25	AT+FTM Transmit Data	46
3.26	AT+FTS Stop Transmission and Wait	46
3.27	AT+FVRFC Vertical resolution format conversion	47
4	AT Commands originating from GSM 07.07	48
4.1	AT+CACM Accumulated call meter (ACM) reset or query	48
4.2	AT+CALA Set alarm time	49
4.3	AT+CAMM Accumulated call meter maximum (ACMmax) set or query	51
4.4	AT+CAOC Advice of Charge information	52
4.5	AT+CBST Select bearer service type	53
4.6	AT+CCFC Call forwarding number and conditions control	54
4.7	AT+CCCLK Real Time Clock	55
4.8	AT+CEER Extended error report	55
4.9	AT+CFUN Set phone functionality	56
4.10	AT+CGMI Request manufacturer identification	57
4.11	AT+CGMM Request model identification	57
4.12	AT+CGMR Request revision identification of software status	57
4.13	AT+CGSN Request product serial number identification (IMEI) identical to GSN	58
4.14	AT+CHLD Call hold and multiparty	58
4.15	AT+CHUP Hang up call	59
4.16	AT+CIMI Request international mobile subscriber identity	59
4.17	AT+CLCC List current calls of ME	60
4.18	AT+CLCK Facility lock	61
4.19	AT+CLIP Calling line identification presentation	63
4.20	AT+CLIR Calling line identification restriction (done by *# Sequence)	64
4.21	AT+CLVL Loudspeaker volume level	64
4.22	AT+CMEE Report mobile equipment error	65
4.23	AT+CMUT Mute control	66
4.24	AT+CMUX Enter multiplex mode	67
4.25	AT+COPN Read operator names	68
4.26	AT+COPS Operator selection	69
4.27	AT+CPAS Mobile equipment activity status	70

4.28	AT+CPBR	Read current phonebook entries	71
4.29	AT+CPBS	Select phonebook memory storage	72
4.30	AT+CPBW	Write phonebook entry	73
4.31	AT+CPIN	Enter PIN	74
4.32	AT+CPIN2	Enter PIN2	75
4.33	AT+CPUC	Price per unit and currency table	76
4.34	AT+CPWD	Change password	77
4.35	AT+CR	Service reporting control	78
4.36	AT+CRC	Set Cellular Result Codes for incoming call indication	79
4.37	AT+CREG	Network registration	80
4.38	AT+CRLP	Select radio link protocol param. for orig. non-transparent data call	81
4.39	AT+CRSM	Restricted SIM access	82
4.40	AT+CSCS	Set TE character set	83
4.41	AT+CSQ	Signal quality	84
4.42	AT+CSSN	Supplementary service notifications	85
4.43	AT+CUSD	Unstructured supplementary service data	86
4.44	AT+VTD=<n>	Tone duration	87
4.45	AT+VTS	DTMF and tone generation (<Tone> in {0-9, *, #, A, B, C, D})	87
4.46	AT+WS46	Select wireless network	88

5 AT commands originating from GSM 07.05 for SMS..... 89

5.1	AT+CMGC	Send an SMS command	89
5.2	AT+CMGD	Delete SMS message	90
5.3	AT+CMGF	Select SMS message format	90
5.4	AT+CMGL	List SMS messages from preferred store	91
5.5	AT+CMGR	Read SMS message	94
5.6	AT+CMGS	Send SMS message	97
5.7	AT+CMGW	Write SMS message to memory	98
5.8	AT+CMSS	Send SMS message from storage	99
5.9	AT+CNMA	New SMS message acknowledge to ME/TE, only phase 2+	100
5.10	AT+CNMI	New SMS message indications	101
5.11	AT+CPMS	Preferred SMS message storage	103
5.12	AT+CSCA	SMS service centre address	104
5.13	AT+CSCB	Select cell broadcast messages	104
5.14	AT+CSDH	Show SMS text mode parameters	105
5.15	AT+CSMP	Set SMS text mode parameters	106
5.16	AT+CSMS	Select Message Service	107

6 Siemens defined AT commands for enhanced functions..... 108

6.1	AT+CXXCID	Display card ID (identical to AT^SCID)	108
6.2	AT^MONI	Monitor idle mode and dedicated mode	108
6.3	AT^MONP	Monitor neighbour cells	110
6.4	AT^SACM	Advice of charge and query of ACM and ACMmax	111
6.5	AT^SBC	Battery charge and Charger Control	112
6.6	AT^SCID	Display SIM card identification number	113
6.7	AT^SCKS	Set SIM connection presentation mode and query SIM connection status	114
6.8	AT^SCNI	List Call Number Information	115
6.9	AT^SCTM	Set critical operating temperature presentation mode or query temperature	116
6.10	AT^SDLD	Delete the "last number redial" memory	117
6.11	AT^SHOM	Display Homezone	117
6.12	AT^SLCD	Display Last Call Duration	117
6.13	AT^SLCK	Facility lock (including self-defined locks)	118
6.14	AT^SMGL	List SMS messages from preferred storage	119
6.15	AT^SMGO	Set or query SMS overflow presentation mode or query SMS overflow	120
6.16	AT^SMSO	Switch off mobile station	121
6.17	AT^SMGR	Read SMS message without set to REC READ	121
6.18	AT^SM20	Set M20 Compatibility	121

6.19	AT^SNFD Set audio parameters to manufacturer default values	122
6.20	AT^SNFI Set microphone path parameters	122
6.21	AT^SNFM Mute microphone	123
6.22	AT^SNFO Set audio output (= loudspeaker path) parameter	124
6.23	AT^SNFS Select audio hardware set.....	125
6.24	AT^SNFV Set loudspeaker volume.....	126
6.25	AT^SNFW Write audio setting in non-volatile store	126
6.26	AT^SPBC Seek the first entry in the sorted telephone book	127
6.27	AT^SPBG Read entry from the sorted telephone book via the sorted index.....	127
6.28	AT^SPBS Steps the selected phonebook alphabetically	128
6.29	AT^SPIC Display PIN counter.....	129
6.30	AT^SPLM Read the PLMN list	129
6.31	AT^SPLR Read entry from the preferred operators list	130
6.32	AT^SPLW Write an entry to the preferred operators list.....	130
6.33	AT^SPWD Change password for a lock (including locks defined by Siemens AG)	131
6.34	AT^SSYNC Configure SYNC Pin.....	132
6.35	AT^STCD Display Total Call Duration.....	133

7 Summary of ERRORS and Messages 134

7.1	Summary of CME ERRORS related to GSM 07.07	134
7.2	Summary of CMS ERRORS related to GSM 07.05	135
7.3	Summary of all Unsolicited Result Codes (URC).....	137
7.4	Result codes	137
7.5	Cause Location ID for the extended error report (AT+CEER)	138
7.6	Release causes for the Extended Error Report (AT+CEER).....	138
7.7	Release cause for last Supplementary Service Call (AT+CEER).....	139
7.8	List of PIN-requiring AT Commands	140
7.9	List of *# codes.....	143
7.10	Alphabet tables.....	144

General note

With respect to any damages arising in connection with the described product or this document, Siemens shall be liable according to the General Conditions on which the delivery of the described product and this document are based.

This product is not intended for use in life support appliances, devices or systems where a malfunction of the product can reasonably be expected to result in personal injury. Siemens AG customers using or selling this product for use in such applications do so at their own risk and agree to fully indemnify Siemens for any damages resulting from illegal use or resale.

Applications incorporating the described product must be designed to be in accordance with the technical specifications provided in these guidelines. Failure to comply with any of the required procedures can result in malfunctions or serious discrepancies in results.

Furthermore, all safety instructions regarding the use of mobile technical systems, including GSM products, which also apply to cellular phones must be followed.

Subject to change without notice at any time.

0 Version History

This chapter reports modifications and improvements over previous versions of the document.

"AT Command Set" Version **02.00 => 02.10**

Chapter	Page	AT command	What is new
4.18	61	AT+CLCK Facility lock	Parameter "CS" (keypad lock) is presented, but not supported
6.13	118	AT^SLCK Facility lock (including self-defined locks)	Parameter "CS" (keypad lock) is presented, but not supported Added following parameters: "PF", "PN", "PU", "PP", "PC"
6.24	126	AT^SNFV Set loudspeaker volume	Notes modified

1 Introduction

This document provides the AT Command Set for the following Siemens GSM engines:

- **TC35 Module**
- **TC37 Module**
- **TC35 Terminal**

The AT commands detailed in this document are supported by all three products. Where differences occur, they are noted in the chapter that refers to the command. In this version, the only exception is the AT[^]SSYNC command that offers various modes depending on the model (see Chapter 6.34).

1.1 Conventions

Throughout the document, the GSM engines are referred to as ME (Mobile Equipment), MS (Mobile Station), TA (Terminal Adapter), DCE (Data Communication Equipment) or facsimile DCE (FAX modem, FAX board).

To control your GSM engine you can simply send AT Commands via its serial interface. The controlling device at the other end of the serial line is referred to as TE (Terminal Equipment), DTE (Data Terminal Equipment) or plainly 'the application' (probably running on an embedded system).

Response:

All the AT Commands described in this document are usually followed by a response that includes "<CR><LF><response><CR><LF>". Throughout this document, only the response is listed, not each <CR><LF>.

AT commands and responses:

Test command	AT+CXXX=?	The mobile equipment returns the list of parameters and value ranges set with the corresponding Write command or by internal processes.
Read command	AT+CXXX?	This command returns the currently set value of the parameter or parameters
Write command	AT+CXXX=<...>	This command sets user-definable parameter values.
Execution command	AT+CXXX	The execution command reads non-variable parameters affected by internal processes in the TC35.

General:

Underlined parameters are default parameters.

Optional parameters may be omitted in case of using default values. Do not omit constrained parameters to use default parameters. Double quotes indicate strings. Symbols within double quotes will be recognized as strings. A string without double quotes will be interrupted by comma. All spaces will be ignored when using strings without double quotes. It is possible to omit the leading zeros of strings which represent numbers.

In case of using V.25ter commands without giving an optional parameter, its value will be assumed as 0.

1.2 Restrictions

If autobauding is active, the multiplex mode (see **+CMUX**, pg. 67) can't be activated (and if multiplex mode has been entered, **AT+IPR=<rate>** is not possible).

When the serial interface is in multiplex mode (see **+CMUX**, pg. 67), data calls are only possible on logical channel 1. Due to this restriction, AT commands have a different behaviour on channels 2+3 compared to channel 1. Some commands are not available, some other commands have a different response.

The following list contains these commands:

Command	Behaviour on channel 1	Differences on channel 2+3
AT+CBST	as described	not usable
AT+CR	as described	not usable
AT+CRLP	as described	not usable
AT+F.... (Fax Commands)	as described	not usable
+++	as described	not usable
AT&C	as described	not usable
AT&D	as described	not usable
AT&F	as described	Data Call parameters not changed
AT&S	as described	not usable
AT&V	as described	Data Call parameters not displayed
ATA	as described	no Data Calls
ATD	as described	no Data Calls
ATDI<n>	as described	not usable
ATO	as described	not usable
ATS0 ¹⁾	as described	not usable
ATS3 ¹⁾	as described	not usable
ATS4 ¹⁾	as described	not usable
ATS5 ¹⁾	as described	not usable
ATS6 ¹⁾	as described	not usable
ATS7 ¹⁾	as described	not usable
ATS8 ¹⁾	as described	not usable
ATS10 ¹⁾	as described	not usable
ATS18 ¹⁾	as described	not usable
ATIQ	as described	not usable
ATZ	as described	Data Call parameters not changed

¹⁾ TC35 supports the registers S0 - S29. You can change S0,S3,S4,S5,S6,S7,S8,S10 and S18 via the related ATSn commands (see starting from pg. 21). The other registers are read-only and for internal use only!

Allowed combinations of commands:

All these commands should not be combined with other commands on the same command line, otherwise the responses may not be in the expected order.

V.25ter commands	With	FAX commands, Prefix AT+F
GSM 7.07 commands	With	Siemens commands, Prefix AT^S
GSM 7.05 commands (SMS)		Used standalone

Example:

```
at+cpbs?;^snfi?
```

Response:

```
+CPBS: "SM",23,125
```

```
^SNFI: 5,32767
```

```
OK
```

1.3 Supported character sets

The ME uses 2 character sets: GSM 03.38 (7 bit, see character tables in annex 7.10 „Alphabet tables“, pg. 144) and UCS2 (16 Bit, refer ISO/IEC 10646). Also refer to subclause „AT+CSCS Set TE character set“, pg. 83.

With the intention of using an ASCII terminal to enter characters which are coded differently in ASCII and GSM (e.g. Ä, Ö, Ü), these characters have to be entered via escape sequences. Such a character is translated into the corresponding GSM character value and if output later, the GSM character value is issued. Any ASCII terminal then will have to show wrong responses.

For instance:

GSM 03.38 character	GSM character hex. value	Corresponding ASCII character	ASCII Esc sequence	Hex Esc sequence
Ö	5C	\	\5C	5C 35 43
"	22	"	\22	5C 32 32
ò	08	BSP	\08	5C 30 38
@	00 ¹⁾	NULL	\00	5C 30 30

¹⁾ Use of the GSM Null character may cause problems on application level when using a 'C'-function as „strlen()“ and should thus be represented by an escape sequence.

1.4 Autobauding

The serial interface of the ME supports autobauding. Therefore it is possible to detect the baud rate used by the TE while receiving the strings „AT“ or „at“ (Attention). This two-character abbreviation is always used to start a command line to be sent from TE to TA.

There are certain rules to be followed when autobauding is active:

1. Only the strings „AT“ or „at“ can be detected (neither „aT“ nor „At“!).
2. Autodetection works in the range from 1200 to 115200 baud.
3. The serial interface has to be used with 8 data bits, no parity and 1 stop bit anyway.

If autobauding is active

- the multiplex mode (see +CMUX, pg. 67) cannot be activated (and if multiplex mode has been entered, **AT+IPR=<rate>** is not possible).
- the command A/ (and a/) cannot be used.

The device is shipped with autobaud mode enabled.

For further implications regarding the autobaud mode and baud rate selection see the following AT Commands:

1. AT+ILRR Set TE-TA local rate reporting , pg. 30
2. AT+IPR Set fixed local rate, pg. 32

2 Standard V.25ter AT Commands

These AT Commands are related to ITU-T (International Telecommunication Union, Telecommunication sector) V.25ter document.

The TC35 Module, the TC37 Module and the TC35 Terminal support the registers S0-S29. You can change S0,S3,S4,S5,S6,S7,S8,S10,S18 by using the appropriate ATSn commands. All the other registers are read-only and for internal usage only!

2.1 A/ Repeat previous command line

Execute command	Response
	Repeat previous command line <i>Note:</i> Line does not have to end with terminating character. Parameter
Reference	Note
V.25ter	<ol style="list-style-type: none"> 1. After beginning with the character „a“ or „A“, a second character „t“ „T“ or „/“ has to follow. In case of using a wrong second character, it is necessary to start again with character „a“ or „A“. 2. If autobauding is active (see +IPR, pg. 31), the command A/ (and a/) cannot be used.

2.2 +++ Switch from data mode to command mode

Execute command	Response
+++	<p>If TA receives the characters +++: TA cancels the data flow via the AT interface and switches to command mode.</p> <p><i>Note:</i> This command is available in data mode only.</p> <p>OK</p> <p>The escape sequence consists of</p> <ol style="list-style-type: none"> 1. a transmit inactivity of at least 1000 ms, 2. three escape characters ('+') in succession all within 1000 ms and 3. a second inactivity of 1000 ms.
Reference	Note
V.25ter	

2.3 AT\Qn Flowcontrol

Execute command AT\Q<n>	<p>Response</p> <p>OK</p> <p>Parameter</p> <p><n> <u>0</u> AT\Q0 disables flow control</p> <p> 1 AT\Q1 XON/XOFF software flow control</p> <p> 2 AT\Q2 only CTS by DCE</p> <p> 3 AT\Q3 RTS/CTS</p>
Reference	Note Line state refers to RS-232 levels.

2.4 ATA Answer a call

Execute command ATA	<p>Response</p> <p>TA causes remote station to go off-hook (e.g. answer call).</p> <p><i>Note1:</i> Any additional commands on the same command line are ignored.</p> <p><i>Note2:</i> This command may be aborted generally by receiving a character during execution. It can't be aborted in some connection setup states, such as handshaking.</p> <p>If successfully connected:</p> <p>Response in case of data call:</p> <p>CONNECT<text></p> <p><i>Note:</i> <text> output only if +ATX parameter setting with value > 0.</p> <p>TA switches to data mode.</p> <p>Response in case of voice call:</p> <p>OK</p> <p>When TA returns to command mode after call release:</p> <p>OK</p> <p>If no connection</p> <p>NO CARRIER</p> <p>Parameter</p>
Reference V.25ter	Note See also AT+ATX and chapter 7.4 for <text>

2.5 ATD Mobile originated call to dial a number

<p>Execute command</p> <p>ATD[<n>][<mgs m>];]</p>	<p>Response</p> <p>TA attempts to set up an outgoing call.</p> <p>Note: This command may be aborted generally by receiving an ATH command during execution. It can't be aborted in some connection setup states, such as handshaking. Different behavior between voice and data call. Behaviour depends on parameter setting of AT^SM20. Voice call setup terminates immediately with OK. Data call setup terminates when call has been established.</p> <p>If no dialtone (parameter setting ATX2 or ATX4) NO DIALTONE</p> <p>If busy (parameter setting ATX3 or ATX4) BUSY</p> <p>If a connection cannot be set up NO CARRIER</p> <p>If successfully connected and non-voice call CONNECT<text></p> <p>Note: <text> output only if +ATX parameter setting with value > 0. TA switches to data state.</p> <p>When TA returns to command mode after call release OK</p> <p>If successfully connected and voice call OK</p> <p>Parameter</p> <p><n> string of dialling digits and optionally V.25ter modifiers (dialling digits): 0-9, *, #, +, A, B, C</p> <p>V.25ter modifiers: these are ignored: ,(comma), T, P, !, W, @</p> <p>Emergency call: <n> = 112 worldwide number (no SIM needed)</p> <p><mgs m> string of GSM modifiers: l CLIR invocation i CLIR suppression</p> <p>Default value of <n>: last dialled number <;> voice call , return to command state</p>
<p>Reference</p> <p>V.25ter/GSM 07.07</p>	<p>Note</p> <ol style="list-style-type: none"> 1. Parameter „l“ and „i“ only if no *#-code is within the dial string. 2. <mgs m> is not supported for data calls. 3. See also +ATX and chapter 7.4 for <text>. 4. The *#-codes are available for voice calls (i.e. use ‘; ’) only. 5. If ATD is used with an USSD command (e.g. ATD*100#;) an AT+CUSD=1 is executed implicitly. (see „AT+CUSD Unstructured supplementary service data“, pg. 85).

2.6 ATD<mem><n> Originate call to phone number <n> in memory <mem>

<p>Execute command ATD<mem> <n>[<mgsms>];]</p>	<p>Response TA attempts to set up an outgoing call to stored number. Note: This command may be aborted generally by receiving a character during execution. Abortion is not possible during some states of connection establishment such as handshaking. If error is related to ME functionality +CME ERROR: <err> If no dialtone (parameter setting ATX2 or ATX4) NO DIALTONE If busy (parameter setting ATX3 or ATX4) BUSY If a connection cannot be set up NO CARRIER If successfully connected and non-voice call CONNECT<text> Note: <text> output only if +ATX parameter setting with value > 0. TA switches to data state. When TA returns to command mode after call release OK If successfully connected and voice call OK</p>
	<p>Parameter <mem> phonebook: <mem> "SM" SIM phonebook: " FD " SIM fixdialling-phonebook " LD " SIM last-dialling-phonebook " MC " ME missed (unanswered received) calls list " RC " SIM received calls list " ME " ME Phonebook " ON " SIM (or ME) own numbers (MSISDNs) list Note: <mem> must be included in quotation marks (""), if parameter <mgsms> is used. If not, quotation marks are optional.</p>
	<p><n> integer type memory location should be in the range of locations available in the memory used <mgsms> l CLIR invocation i CLIR suppression <;> voice call , return to command state</p>
<p>Reference V.25ter/GSM 07.07</p>	<p>Note 1. There is no <mem> for emergency call ("EN"). 2. Parameter <mgsms> only if no *# code is within the dial string. 3. Command is not supported for data call! 4. The *# codes are only available for voice calls (i.e use ;). 5. See also ATX and chapter 7.4 for <text>.</p>

2.7 ATD<n> Originate call to phone number in current memory

<p>Execute command ATD<n>[<msg sm>];</p>	<p>Response</p> <p>TA attempts to set up an outgoing call to stored number. The used memory is already selected with command +CPBS.</p> <p>Note: This command may be aborted generally by receiving a character during execution. It can't be aborted in some connection setup states, such as handshaking.</p> <p>If error is related to ME functionality +CME ERROR: <err></p> <p>If no dialtone (parameter setting ATX2 or ATX4) NO DIALTONE</p> <p>If busy (parameter setting ATX3 or ATX4) BUSY</p> <p>If a connection cannot be set up NO CARRIER</p> <p>If successfully connected and non-voice call CONNECT<text> <i>Note:</i> <text> output only if +ATX parameter setting with value > 0. TA switches to data state. When TA returns to command mode after call release OK</p> <p>If successfully connected and voice call OK</p> <p>Parameter</p> <p><n> integer type memory location should be in the range of locations available in the memory used</p> <p><msgm> l CLIR invocation i CLIR suppression</p> <p><;> voice call, return to command state</p>
<p>Reference V.25ter/GSM 07.07</p>	<p>Note</p> <ol style="list-style-type: none"> 1. Parameter <msgm> only if no *# code is within the dial string. 2. Command is not supported for data call! 3. The *# codes are only available for voice calls (i.e. use ';;'). 4. See also +ATX and chapter 7.4 for <text>.

2.8 ATD<str> Originate call to phone number in memory with corresponding field

<p>Execute command ATD<str>[mgsm][:]</p>	<p>Response</p> <p>TA attempts to set up an outgoing call to stored number. The current phonebook, set by AT+CPBS, is searched for the entry <str>.</p> <p>Note: This command may be aborted generally by receiving a character during execution. It can't be aborted in some connection setup states, such as handshaking.</p> <p>If error is related to ME functionality +CME ERROR: <err></p> <p>If no dialtone (parameter setting ATX2 or ATX4) NO DIALTONE</p> <p>If busy (parameter setting ATX3 or ATX4) BUSY</p> <p>If a connection cannot be set up NO CARRIER</p> <p>If successfully connected and non-voice call CONNECT<text></p> <p>Note: <text> output only if +ATX parameter setting with value > 0. TA switches to data state. When TA returns to command mode after call release OK</p> <p>If successfully connected and voice call OK</p> <p>Parameter</p> <p><str> string type value ("x"), which should equal an alphanumeric field in at least one phonebook entry in the searched memories; used character set should be the one selected with Select TE Character Set +CSCS. <str> can contain escape sequences as described in chapter „Supported character sets“, pg. 10. <str> must be wrapped in quotation marks (""), if escape sequences or parameter <mgsm> are used. If not, quotation marks are optional.</p> <p><mgsm> CLIR activation i CLIR suppression</p> <p><;> voice call, return to command state</p>
<p>Reference V.25ter/GSM 07.07</p>	<p>Note Command is not supported for data calls! See also ATX and chapter 7.4 for <text></p>

2.9 ATDI Mobile originated call to dialable ISDN number <n>

<p>Execute command ATDI<n>[:]</p>	<p>Response</p> <p>TA attempts to set up an outgoing call to ISDN number. Note: This command may be aborted generally by receiving a character during execution. This command cannot be aborted in some connection setup states, such as handshaking.</p> <p>If no dialtone (parameter setting ATX2 or ATX4) NO DIALTONE</p> <p>If busy (parameter setting ATX3 or ATX4) BUSY</p> <p>If a connection cannot be set up NO CARRIER</p> <p>If successful connected and non-voice call CONNECT<text> '</p> <p>Note: <text> output only if +ATX parameter setting with value > 0. TA switches to data state. When TA returns to command mode after call release OK</p> <p>If successfully connected and voice call OK</p>
	<p>Parameter</p> <p><n> [+]<d> phone number string with maximum length of 20 characters</p> <p>+ <d> international dialling format ISDN number string of digits: +,0-9, A, B, C</p> <p><;> voice call</p>
<p>Reference V.25ter</p>	<p>Note</p>

2.10 ATDL Redial last telephone number used

Execute command ATDL[;]	Response TA attempts to set up an outgoing call to stored number. Note: This command may be aborted generally by receiving a character during execution. This command cannot be aborted in some connection setup states, such as handshaking. If there is no last number or number is not valid: +CME ERROR or: If no dialtone (parameter setting ATX2 or ATX4) NO DIALTONE If busy (parameter setting ATX3 or ATX4) BUSY If a connection cannot be set up NO CARRIER If successfully connected and non-voice call CONNECT<text> Note: <text> output only if +ATX parameter setting with value > 0. TA switches to data state. When TA returns to command mode after call release OK If successfully connected and voice call OK Parameter <;> voice call
Reference V.25ter	Note In case of voice calls ";" is necessary.

2.11 ATE Enable command echo

Write command ATE[<value>]	<p>This setting determines whether or not the TA echoes characters received from TE during command state.</p> <p>Response OK</p> <p>Parameter</p> <table border="0"> <tr> <td style="padding-right: 20px;"><value></td> <td style="padding-right: 20px;">0</td> <td>Echo mode off</td> </tr> <tr> <td></td> <td>1</td> <td>Echo mode on</td> </tr> </table>	<value>	0	Echo mode off		1	Echo mode on
<value>	0	Echo mode off					
	1	Echo mode on					
Reference V.25ter	<p>Note</p> <ol style="list-style-type: none"> In case of using the command without parameter, <value> is set to 0. Echo is disabled with the start of multiplex mode (see AT+CMUX, pg. 67). Therefore echo is not available on logical channels: ATE0 responds with OK, ATE1 responds with ERROR. 						

2.12 ATH Disconnect existing connection

Execute command ATH[n]	<p>Response</p> <p>Disconnect existing call from command line by local TE and terminate call OK</p> <p><i>Note:</i> OK is issued after circuit 109 (DCD) is turned off (RS-232 level), if it was previously on.</p> <p>Parameter</p> <table border="0"> <tr> <td style="padding-right: 20px;"><n></td> <td style="padding-right: 20px;">0</td> <td>disconnect from line and terminate call</td> </tr> </table>	<n>	0	disconnect from line and terminate call
<n>	0	disconnect from line and terminate call		
Reference V.25ter	<p>Note</p> <p>If multiplex mode (AT+CMUX) is used: ATH terminates every data call, even if it is issued via logical channels 2 or 3. This behavior is in accordance with ITU-T V.25 ter; (07/97, see „6.3.6 Hook control”: "ATH is terminating any call in progress.")</p>			

2.13 ATI Display product identification information

Execute command ATI	Response ME issues product information text SIEMENS TC35 REVISION x.yy OK Explanation of „Revision“ parameter: Version x and variant yy of software release.
Reference V.25ter	Note

2.14 ATL Set monitor speaker loudness

Execute command ATL[val]	Response OK
Reference V.25ter	Note 1. Commands ATL and ATM are implemented only for V.25ter compatibility reasons, no action takes place. 2. In multiplex mode the command is supported on logical channel 1 only.

2.15 ATM Set monitor speaker mode

Execute command ATM[val]	Response OK
Reference V.25ter	Note 1. Commands ATL and ATM are implemented only for V.25ter compatibility reasons, no action takes place. 2. In multiplex mode the command is supported on logical channel 1 only.

2.16 ATO Switch from command mode to data mode

Execute command ATO[n]	Response TA resumes the connection and switches back from command mode to data mode. If connection is not successfully resumed NO CARRIER or TA returns to data mode from command mode CONNECT <text> Note: <text> output only if +ATX parameter setting with value > 0. Parameter <n> 0 switch from command mode to data mode
Reference V.25ter	Note

2.17 ATQ Set result code presentation mode

Write command ATQ[<n>]	Response This parameter setting determines whether or not the TA transmits any result code to the TE. Information text transmitted in response is not affected by this setting. If <n>=0: OK If <n>=1: (none) Parameter <n> 0 DCE transmits result code 1 Result codes are suppressed and not transmitted
Reference V.25ter	Note

2.18 ATP Select pulse dialling

Execute command ATP	Response OK
Reference V.25ter	Note No effect for GSM

2.19 ATS0 Set number of rings before automatically answering the call

Read command ATS0?	Response <n> OK
Write command ATS0=<n>	This parameter setting determines the number of rings before automatic answering. Response OK
	Parameter <n> 000 automatic answering is disabled 001-255 enable automatic answering on the specified ring number
Reference V.25ter	Note <ul style="list-style-type: none"> This command works only in data and fax mode. The TC35 supports the registers S0 - S29. A user can change S0,S3,S4,S5,S6,S7,S8,S10 and S18 via the related ATSn commands. The other registers are read-only and for internal usage only!

2.20 ATS3 Write command line termination character

Read command ATS3?	Response <n> OK
Write command ATS3=<n>	This parameter setting determines the character recognized by TA to terminate an incoming command line. Response OK
	Parameter <n> 000- <u>013</u> -127 command line termination character Note: Using other value than 13 may cause problems when entering commands
Reference V.25ter	Note

2.21 ATS4 Set response formatting character

Read command ATS4?	Response <n> OK
Write command ATS4=<n>	This parameter setting determines the character generated by the TA for result code and information text. Response OK
	Parameter <n> 000- <u>010</u> -127 response formatting character.
Reference V.25ter	Note

2.22 ATS5 Write command line editing character

Read command ATS5?	Response <n> OK
Write command ATS5=<n>	This parameter setting determines the character recognized by TA as a request to delete the immediately preceding character from the command line. Response OK
	Parameter <n> 000- <u>008</u> -127 command line editing character
Reference V.25ter	Note

2.23 ATS6 Set pause before blind dialling

Read command ATS6?	Response <n> OK
Write command ATS6=<n>	No effect for GSM Response OK
	Parameter <n> <u>000</u> -255 number of seconds to wait before blind dialling.
Reference V.25ter	Note

2.24 ATS7 Set number of seconds to wait for connection completion

Read command ATS7?	Response <n> OK
Write command ATS7=<n>	This parameter setting determines the amount of time to wait for the connection completion when answering or originating a call. Response OK
	Parameter <n> 000 – <u>060</u> no. of seconds to wait for connection completion.
Reference V.25ter	Note Values bigger than 60 cause no error, but <n> will be set down to maximum value of 60.

2.25 ATS8 Set number of seconds to wait for comma dial modifier

Read command ATS8?	Response <n> OK
Write command ATS8=<n>	No effect for GSM Response OK
	Parameter <n> 000 no pause when comma encountered in dial string <u>002</u> Default value 01-255 number of seconds to wait
Reference V.25ter	Note

2.26 ATS10 Set disconnect delay after indicating the absence of data carrier

Read command ATS10?	Response <n> OK
Write command ATS10=<n>	This parameter setting determines the amount of time, that the TA remains connected in absence of a data carrier. If the data carrier is detected before disconnect, the TA remains connected. Response OK
	Parameter <n> 001- <u>002</u> -254 number of tenths of seconds of delay
Reference V.25ter	Note

2.27 ATS18 Extended error report

Test command ATS18?	Response <n> OK
Execute command ATS18=<n>	TA returns an extended report of the reason for the last call release and location. <n> 0 – 255, odd numbers set extended error report and even numbers disable this feature. Response +Cause: <location ID>: <reason > OK Parameter <location ID> Location ID as number code (see subclause 7.5). <reason> Reason for last call release as number code (see subclause 7.6).
Reference Siemens	Note This command works for data calls only. For voice calls please use AT+CEER.

2.28 ATT Select tone dialling

Execute command ATT	Response OK
Reference V.25ter	Note No effect for GSM

2.29 ATV Set result code format mode

<p>Write command ATV[<value>]</p>	<p>Response</p> <p>This parameter setting determines the contents of the header and trailer transmitted with result codes and information responses.</p> <p>When <value> =0</p> <p>0</p> <p>When <value> =1</p> <p>OK</p> <p>Parameter</p> <p><value></p> <p>0 Information response: <text><CR><LF> Short result code format: <numeric code><CR></p> <p>1 Information response: <CR><LF><text><CR><LF> Long result code format: <CR><LF><verbose code><CR><LF></p>
<p>Reference V.25ter</p>	<p>Note</p> <p>In case of using the command without parameter <value> will be set to 0. Information responses described in chapter 7 (verbose code and numeric code).</p>

2.30 ATX Set CONNECT result code format and call monitoring

<p>Write command ATX[<value>]</p>	<p>Response</p> <p>This parameter setting determines whether or not the TA detects the presence of dial tone and busy signal and whether or not TA transmits particular result codes.</p> <p>OK</p> <p>Parameter</p> <p><value></p> <p>0 CONNECT result code only returned, dial tone and busy detection are both disabled</p> <p>1 CONNECT<text> result code only returned, dial tone and busy detection are both disabled</p> <p>2 CONNECT<text> result code returned, dial tone detection is enabled, busy detection is disabled</p> <p>3 CONNECT<text> result code returned, dial tone detection is disabled, busy detection is enabled</p> <p>4 CONNECT<text> result code returned, dial tone and busy detection are both enabled</p>
<p>Reference V.25ter</p>	<p>Note</p> <p>Related <text> see chapter 7.4.</p>

2.31 ATZ Set all current parameters to user defined profile

Execute command ATZ[<value>]	Response TA sets all current parameters to the user defined profile. If a connection exists, it will be terminated. Note1: The user defined profile is stored in non-volatile memory. Note2: If invalid, the user profile will be reset to the factory default profile. Note3: Any additional commands on the same command line may be ignored. A delay of 300 ms is needed before next command is sent, otherwise "ok" response may be corrupted. OK
	Parameter <value> 0 Reset to profile number 0
Reference V.25ter	Note The TC35 has only the factory default profile

2.32 AT&C Set circuit Data Carrier Detect (DCD) function mode

Write command AT&C[<value>]	Response This parameter determines how the state of circuit 109(DCD) relates to the detection of received line signal from the distant end. OK
	Parameter <value> 0 DCD line is always ON. <u>1</u> DCD line is ON in the presence of data carrier only. <u>2</u>
Reference V.25ter	Note Line state refers to RS-232 levels.

2.33 AT&D Set circuit Data Terminal Ready (DTR) function mode

Write command AT&D[<value>]	Response This parameter determines how the TA responds when circuit 108/2 (DTR) is changed from ON to OFF during data mode. OK
	Parameter <value> 0 TA ignores status on DTR. 1 ON->OFF on DTR: Change to command mode while retaining the connected call. <u>2</u> ON->OFF on DTR: Disconnect call, change to command mode. During state DTR = OFF is auto-answer off.
Reference V.25ter	Note Line state refers to RS-232 levels.

2.34 AT&F Set all current parameters to manufacturer defaults

Execute command AT&F[<i>value</i>]	Response TA sets all current parameters to the manufacturer defined profile. <i>Note:</i> Any additional commands on the same command line are ignored. OK Parameter < value > 0 set all TA parameters to manufacturer default
Reference V.25ter	Note AT Commands which parameters will be set to manufacturer default: E, Q, V, X, +CBST, +CRLP, +CRC, +CR, +CNMI, +CMEE, +CSMS, ^SCKS, ^SACM, +CREG, +CLIP, the S Parameters, &D, &C, &S No user profiles supported.

2.35 AT&S Set circuit Data Set Ready (DSR) function mode

Write command AT&S< <i>value</i> >	Response This parameter determines how the TA sets circuit 107 (DSR) depending on the communication state of the TA interfacing TE. OK
	Parameter < value > <u>0</u> DSR always on. 1 TA in command mode: DSR is OFF. TA in data mode: DSR is ON.
Reference V.25ter	Note Line state refers to RS-232 levels.

2.36 AT&V Display current configuration

<p>Execute command AT&V[<n>]</p>	<p>TA returns the current parameter setting.</p> <p>Response</p> <p>The following table shows four different kinds of responses depending on whether the PIN is entered or not, and whether channel 1 is used or communication is done via logical channels 2 or 3. This requires the multiplex mode to be enabled (see "AT+CMUX Enter multiplex mode", pg. 67).</p> <p>Parameter</p> <p><n> 0 profile number</p>	
	<p>PIN entered or not required (see AT+CPIN, pg. 73)</p>	<p>Required PIN not entered</p>
<p>Channel 1 (with or without multiplex mode enabled)</p>	<p>ACTIVE PROFILE: E1 Q0 V1 X4 &C1 &D2 &S0 \Q0 S0:000 S3:013 S4:010 S5:008 S6:000 S7:060 S8:000 S10:002 S18:000 +CBST: 7,0,1 +CRLP: 61,61,78,6 +CR: 0 +FCLASS: 0 +CRC: 0 +CMGF: 0 +CNMI: 0,0,0,0,1 +ILRR: 0 +IPR: 19200 +CMEE: 2 ^SMGO: 0,0 +CSMS: 0,1,1,1 ^SACM: 0,"000000","000000" ^SCKS: 0,1 +CREG: 0 +CLIP: 0,2 +CAOC: 0 +COPS: 0,0,"operator"</p> <p>OK</p>	<p>ACTIVE PROFILE: E1 Q0 V1 X4 &C1 &D2 &S0 \Q0 S0:000 S3:013 S4:010 S5:008 S6:000 S7:060 S8:000 S10:002 S18:000 +CBST: 7,0,1 +CRLP: 61,61,78,6 +CR: 0 +FCLASS: 0 +ILRR: 0 +IPR: 19200 +CMEE: 2 ^SCKS: 0,1</p> <p>OK</p>
<p>Logical channels 2 and 3 (Multiplex mode enabled)</p>	<p>+CRC: 0 +CMGF: 0 +CNMI: 0,0,0,0,1 +ILRR: 0 +IPR: 19200 +CMEE: 2 ^SMGO: 0,0 +CSMS: 0,1,1,1 ^SACM: 0,"000000","000000" ^SCKS: 0,1 +CREG: 0 +CLIP: 0,2 +CAOC: 0 +COPS: 0,0,"operator"</p> <p>OK</p>	<p>+ILRR: 0 +IPR: 19200 +CMEE: 2 ^SCKS: 0,1</p> <p>OK</p>
<p>Reference</p>	<p>Note</p> <p>Parameter values and order are subject to change.</p>	

2.37 AT+GCAP Request complete TA capabilities list

Test command AT+GCAP=?	Response OK Parameter
Execute command AT+GCAP	Response TA reports a list of additional capabilities. +GCAP: <name> OK Parameter <name> e.g.: +CGSM, +FCLASS
Reference V.25ter	Note +CGSM: The response text shows which GSM commands of the ETSI standard are supported.

2.38 AT+GMI Request manufacturer identification

Test command AT+GMI=?	Response OK
Execute command AT+GMI	Response TA reports information to identify the manufacturer. SIEMENS OK
Reference V.25ter	Note See also "AT+CGMI Request manufacturer identification".

2.39 AT+GMM Request TA model identification

Test command AT+GMM=?	Response OK
Execute command AT+GMM	TA reports one or more lines of information text which permit the user to identify the specific model of device. TC35 OK
Reference V.25ter	Note See also "AT+CGMM Request model identification".

2.40 AT+GMR Request TA revision identification of software status

Test command AT+GMR=?	Response OK
Execute command AT+GMR	Response TA returns product software version identification text. <revision> OK Parameter <revision> x.yy Explanation of „Revision“ parameter: Version x and variant yy of software release.
Reference V.25ter	Note See also “AT+CGMR Request revision identification of software status”.

2.41 AT+GSN Request TA serial number identification(IMEI)

Test command AT+GSN=?	Response OK
Execute command AT+GSN	Response TA reports one or more lines of information text which permit the user to identify the individual device. <sn> OK Parameter <sn> IMEI of the telephone (International Mobile station Equipment Identity)
Reference V.25ter	Note The serial number (IMEI) varies for every individual ME device.

2.42 AT+ILRR Set TE-TA local rate reporting

Test command AT+ILRR=?	Response +ILRR: (list of supported <value>s) OK Parameter See write command
Read command AT+ILRR?	Response +ILRR: <value> OK Parameter See write command
Write command AT+ILRR= <value>	This parameter setting determines whether or not an intermediate result code of local rate is reported at connection setup. The rate is reported before the final result code of the connection is transmitted to the TE. Response OK Parameter <value> 0 Disables reporting of local port rate 1 Enables reporting of local port rate
	Intermediate result +ILRR:<rate> <i>Note:</i> Indicates port rate setting on connection. Parameter <rate> port rate setting on call connection in bit per second 0 (Autobauding, see pg. 10) 300 600 1200 2400 4800 9600 14400 19200 28800 38400 57600 115200
Reference V.25ter	Note If autobauding is active, the command A/ (and a/) can not be used.

2.43 AT+IPR Set fixed local rate

<p>Test command AT+IPR=?</p>	<p>Response +IPR: (list of supported auto-detectable <rate>s), (list of supported fixed-only <rate>s) OK Parameter See write command</p>
<p>Read command AT+IPR?</p>	<p>Response +IPR: <rate> OK Parameter See write command</p>
<p>Write command AT+IPR=<rate></p>	<p>This command determines the data rate of the TA on the serial interface. A selected bit rate takes effect following the issue of any result code associated with this command (e.g. OK).</p> <p>The selected bit rate is stored into non-volatile memory and is also used after next power-up. However, in case of autobaud mode (+IPR=0) the actually detected bit rate is not saved, and has to be determined at next power-up again (see notes below).</p> <p>Response OK If error is related to ME functionality ERROR/+CME ERROR: <err></p> <p>Parameter <rate> bit rate per second 0 (Autobauding, , see pg. 10) 300 600 1200 2400 4800 9600 14400 19200 recommended 28800 38400 57600 115200</p>
<p>Reference V.25ter</p>	<p>Note</p> <ol style="list-style-type: none"> 1. AT+IPR=x can be combined with other command strings on the same line. Regard restrictions in chapter 1.2 (see pg. 9) and below! 2. If switching to autobaud mode (+IPR=0) is combined with other commands on the same line (see above), switching to autobauding will take place just after the response is output by the TA to the last command on that line. 3. When using AT+IPR=x, a delay of 100 ms is needed between a response to the last command on the same line (e.g. OK) and the next command. 4. If autobaud mode is active: <ol style="list-style-type: none"> a) Before a new bit rate is detected (by receiving the first At Command string, see pg. 10), unsolicited result codes (if any) will be send with the

previous bit rate.

- b) Because in autobaud mode the ME doesn't know which bit rate is to be used after power-on. For this reason the unsolicited result code "SYSSTART" cannot be sent. Therefore it is recommended to first send an At Command string (see pg. 10) to the ME to let the autobaud mechanism determine the bit rate used by the TE.
- 5. If this command switches from a bit rate that can't be detected by the autobaud mechanism (e.g. 300 baud) to autobaud mode (via **+IPR=0**), the responses of **+IPR=0** and all following commands on the same line may be corrupted.
- 6. If autobauding is active, the command **A/** (and **a/**) can not be used.
- 7. If autobauding is active, the multiplex mode (see **+CMUX**, pg. 67) can not be activated.
- 8. If multiplex mode has been entered, **+IPR=<rate>** is not possible.

3 AT Commands for FAX

The following commands can be used for FAX transmission.

If the ME is acting as a Fax-Modem to a PC-based application (e.g. „WinFax“) it is necessary to select the proper Service Class (Fax Class) provided by the ME. The ME reports its Service Class capabilities, both the current setting and the range of services available. This is provided by the AT+FCLASS command (see pg. 36).

Currently defined Service Class values (see TIA/EIA-592-A)			
ME	+FCLASS parameter	Service Class	Reference, Standard
👍	0	data modem	e.g. TIA/EIA-602 or ITU V.25ter
👍	1	Service Class 1	EIA/TIA-578-A
	1.0	Service Class 1	ITU-T T.31
👍	2	manufacture specific	this document and EIA PN-2388 (draft)
	2.0	Service Class 2	TIA/EIA-592
	2.1	Service Class 2	TIA/EIA-592-A or ITU-T T.32
	8	Voice DCE	TIA IS-101
	Reserved		

Note: Be aware that there is a difference between Service Classes 2 and 2.0! Only the first is applicable to the ME.

3.1 AT+FBADLIN Bad Line Threshold

Read command AT+FBADLIN?	<p>This command defines the “Copy-Quality-OK”-threshold. If <badline> consecutive lines have pixel count errors in normal resolution (98 dpi) mode, then the copy quality is unacceptable. If <badline> * 2 consecutive lines have pixel count errors in fine resolution (196 dpi) mode, then the copy quality is unacceptable. “Copy Quality Not OK” occurs if either the error percentage is too high or too many consecutive lines contain errors. A value of 0 implies that error checking is not present or disabled.</p> <p>Response <badlin> OK</p> <p>Parameter See write command</p>
Write command AT+FBADLIN=<badlin>	<p>Response OK</p> <p>If error is related to ME functionality: ERROR</p> <p>Parameter <badlin> 0 – <u>10</u> - 255 bad lines</p>
Reference EIA PN-2388	<p>Note Used for Faxclass 2 only</p>

3.2 AT+FBADMUL Error Threshold Multiplier

Read command AT+FBADMUL ?	This command defines the "Copy-Quality-OK" multiplier. The number of lines received with a bad pixel count is multiplied by this number. If the result exceeds the total number of lines on the page the error rate is considered too high. A threshold multiplier value of 20 corresponds to a 5% error rate. A value of 0 implies that error checking is not present or disabled. Response <badmul> OK Parameter See write command
Write command AT+FBADMUL =<n>	Response OK If error is related to ME functionality: ERROR Parameter <n> 0 – <u>20</u> – 255
Reference EIA PN-2388	Note Used for Faxclass 2 only

3.3 AT+FBOR Query data bit order

Test command AT+FBOR=?	Query the bit order for receive-mode. The mode is set by the ME dependent on the selected Service Class, see "AT+FCLASS Fax: Select, read or test service class", pg. 36. Response (list of supported bit order modes <bor>s) OK Parameter See write command
Read command AT+FBOR?	Response <bor> OK Parameter See write command
Write command AT+FBOR=<bor>	Response OK Parameter <bor> 0 direct bit order for both Phase C and for Phase B/D data. 1 Reversed bit order for Phase C data, direct Bit Order for Phase B/D data.
Reference EIA PN-2388	Note Used for Faxclass 2 only

3.4 AT+FCIG Query or set the Local polling id

Test command AT+FCIG=?	Response (max. length of Local Polling ID string) (range of supported ASCII character values) OK Parameter See write command
Read command AT+FCIG?	Response <id> OK Parameter See write command
Write command AT+FCIG =<id>	Response OK Parameter <id> Local Polling ID string, max. length and possible content as reported by test command. Default value is empty string ("").
Reference EIA PN-2388	Note See also "AT+FLID Query or set the Local Id setting capabilities", pg. 42. Used for Faxclass 2 only

3.5 AT+FCLASS Fax: Select, read or test service class

Test command AT+FCLASS=?	See introduction to fax commands, pg. 34. Response (list of supported <n>s) OK Parameter See write command									
Read command AT+FCLASS?	Response <n> OK Parameter See write command									
Write command AT+FCLASS= <n>	The ME is set to a particular mode of operation (data, fax). This causes the MA to process information in a manner suitable for that type of information. Response OK Parameter <table border="0" style="width: 100%;"> <tr> <td style="width: 10%;"><n></td> <td style="width: 10%; text-align: center;"><u>0</u></td> <td style="width: 80%;">data (e.g. EIA/TIA-602 or ITU V.25ter)</td> </tr> <tr> <td></td> <td style="text-align: center;">1</td> <td>Fax class 1 (EIA/TIA-578-A, Service Class 1)</td> </tr> <tr> <td></td> <td style="text-align: center;">2</td> <td>Fax class 2 (EIA/TIA SP-2388, an early draft version of EIA/TIA-592-A – Service class 2.1)</td> </tr> </table>	<n>	<u>0</u>	data (e.g. EIA/TIA-602 or ITU V.25ter)		1	Fax class 1 (EIA/TIA-578-A, Service Class 1)		2	Fax class 2 (EIA/TIA SP-2388, an early draft version of EIA/TIA-592-A – Service class 2.1)
<n>	<u>0</u>	data (e.g. EIA/TIA-602 or ITU V.25ter)								
	1	Fax class 1 (EIA/TIA-578-A, Service Class 1)								
	2	Fax class 2 (EIA/TIA SP-2388, an early draft version of EIA/TIA-592-A – Service class 2.1)								
Reference EIA/TIA-592-A	Note Using Error Correcting Mode (ECM) when sending FAXes over GSM should be avoided.									

3.6 AT+FCQ Copy Quality Checking

Test command AT+FCQ=?	This command controls Copy Quality checking when receiving a fax. Response (list of supported copy quality checking <cq>s) OK Parameter See write command
Read command AT+FCQ?	Response <cq> OK Parameter See write command
Write command AT+FCQ =<cq>	Response OK Parameter <cq> 0 No copy quality checking. The ME will generate Copy Quality OK (MCF) responses to complete pages. 1 ME can check 1-D phase data. The connected application must check copy quality for 2-D phase C data
Reference EIA PN-2388	Note Used for for Faxclass 2 only.

3.7 AT+FCR Capability to receive

Write command AT+FCR=<cr>	Response OK Parameter <cr> <u>0</u> ME will not receive message data. This can be used when the application has insufficient storage. The ME can send and can be polled for a file. 1 ME can receive message data.
Reference EIA PN-2388	Note Used for Faxclass 2 only

3.8 AT+FDCC Query or set capabilities

<p>Test command AT+FDCC=?</p>	<p>This command allows the connected application to sense and constrain the capabilities of the facsimile DCE (=ME), from the choices defined in CCITT T.30 Table 2.</p> <p>Response (list of <VR>s), (list of
s), (list of <WD>s), (list of <LN>s), (list of <DF>s), (list of <EC>s), (list of <BF>s), (list of <ST>s)</p> <p>OK</p> <p>Parameter</p> <p>VR: Vertical Resolution, BR: Bit Rate, WD: Page Width, LN: Page Length, DF: Data Compression Format, EC: Error Correction Mode, BF: Binary File Transfer Mode, ST: Scan Time/Line.</p> <p><i>Note:</i> For further information see AT+FDIS, pg. 40</p>
<p>Read command AT+FDCC?</p>	<p>Response <dcc> OK</p> <p>Parameter See write command</p>
<p>Write command AT+FDCC=<VR>,
,<WD>,<LN>,<DF>,<EC>,<BF>,<ST></p>	<p>Response OK</p> <p>Parameter</p> <p>VR: Vertical Resolution, BR: Bit Rate, WD: Page Width, LN: Page Length, DF: Data Compression Format, EC: Error Correction Mode, BF: Binary File Transfer Mode, ST: Scan Time/Line.</p> <p><i>Note:</i> For further information see AT+FDIS, pg. 40</p>
<p>Reference EIA PN-2388</p>	<p>Note Used for Faxclass 2 only</p>

3.9 AT+FDFFC Data Compression Format Conversion

<p>Test command AT+FDFFC=?</p>	<p>This parameter determines the ME response to a mismatch between the data format negotiated for the facsimile session, reported by the +FDCS:DF subparameter, and the Phase C data desired by the controlling application, indicated by the optional +FDT:DF subparameter, or the +FDIS=DF subparameter for the +FDR operation.</p> <p>Response (list of supported <df>s) OK</p> <p>Parameter See write command</p>
<p>Read command AT+FDFFC?</p>	<p>Response <df> OK</p> <p>Parameter See write command</p>
<p>Write command AT+FDFFC =<df></p>	<p>Response OK</p> <p>Parameter <df> <u>0</u> Mismatch checking is always disabled. The controlling application has to check the +FDCS: DF subparameter and transfer matching data.</p>
<p>Reference EIA PN-2388</p>	<p>Note Used for Fax Class 2 only</p>

3.10 AT+FDIS Query or set session parameters

Test command AT+FDIS=?	<p>This command allows the controlling application to sense and constrain the capabilities used for the current session. It uses +FDIS to generate DIS or DTC messages directly, and uses +FDIS and received DIS messages to generate DCS messages.</p> <p>Response (list of <VR>s), (list of
s), (list of <WD>s), (list of <LN>s), (list of <DF>s), (list of <EC>s), (list of <BF>s), (list of <ST>s)</p> <p>Parameter See write command</p>																																																																																																																										
Read command AT+FDIS?	<p>Response <cdec> OK</p> <p>Parameter See write command</p>																																																																																																																										
Write command AT+FDIS = <VR>, ,<WD>,<LN>,<DF>,<EC>,<BF>,<ST>	<p>Response OK</p> <p>Parameter</p> <table border="0"> <tr> <td>Vertical Resolution VR</td> <td></td> <td>0</td> <td>normal, 98 lpi</td> </tr> <tr> <td></td> <td></td> <td><u>1</u></td> <td>fine, 196 lpi</td> </tr> <tr> <td>Bit Rate BR</td> <td></td> <td>0</td> <td>2400 bit/s, V.27ter</td> </tr> <tr> <td></td> <td></td> <td>1</td> <td>4800 bit/s, V.27ter</td> </tr> <tr> <td></td> <td></td> <td>2</td> <td>7200 bit/s, V.29</td> </tr> <tr> <td></td> <td></td> <td><u>3</u></td> <td>9600 bit/s, V.29</td> </tr> <tr> <td>Page Width WD</td> <td></td> <td><u>0</u> *)</td> <td>1728 pixels in 215mm</td> </tr> <tr> <td></td> <td></td> <td>1</td> <td>2048 pixels in 255 mm</td> </tr> <tr> <td></td> <td></td> <td>2</td> <td>2432 pixels in 303 mm</td> </tr> <tr> <td></td> <td></td> <td>3</td> <td>1216 pixels in 151 mm</td> </tr> <tr> <td></td> <td></td> <td>4</td> <td>864 pixels in 107 mm</td> </tr> <tr> <td>Page Length LN</td> <td></td> <td>0</td> <td>A4, 297mm</td> </tr> <tr> <td></td> <td></td> <td>1</td> <td>B4, 364mm</td> </tr> <tr> <td></td> <td></td> <td><u>2</u></td> <td>unlimited length</td> </tr> <tr> <td>Data Compression Format DF</td> <td></td> <td><u>0</u> *)</td> <td>1-D modified Huffman</td> </tr> <tr> <td></td> <td></td> <td>1</td> <td>2-D modified read</td> </tr> <tr> <td></td> <td></td> <td>2</td> <td>2-D uncompressed mode</td> </tr> <tr> <td>Error correction (Annex A/T.30) EC</td> <td></td> <td><u>0</u> *)</td> <td>disable ECM</td> </tr> <tr> <td></td> <td></td> <td>1</td> <td>enable ECM, 64 bytes/frame</td> </tr> <tr> <td></td> <td></td> <td>2</td> <td>enable ECM, 256 bytes/frame</td> </tr> <tr> <td>Binary File mode Transfer Mode BF</td> <td></td> <td><u>0</u> *)</td> <td>disable BFT</td> </tr> <tr> <td></td> <td></td> <td>1</td> <td>enable BFT</td> </tr> <tr> <td>Scan Time/Line ST</td> <td></td> <td><u>0</u> *)</td> <td>0 ms (at VR= normal)</td> </tr> <tr> <td></td> <td></td> <td>1</td> <td>5 ms</td> </tr> <tr> <td></td> <td></td> <td>2</td> <td>10 ms</td> </tr> <tr> <td></td> <td></td> <td>3</td> <td>10 ms</td> </tr> <tr> <td></td> <td></td> <td>4</td> <td>20 ms</td> </tr> <tr> <td></td> <td></td> <td>5</td> <td>20 ms</td> </tr> <tr> <td></td> <td></td> <td>6</td> <td>40 ms</td> </tr> <tr> <td></td> <td></td> <td>7</td> <td>40 ms</td> </tr> </table> <p>*) Note: Only the default value needs to be implemented. Use test command to check which parameter values are really possible!</p>			Vertical Resolution VR		0	normal, 98 lpi			<u>1</u>	fine, 196 lpi	Bit Rate BR		0	2400 bit/s, V.27ter			1	4800 bit/s, V.27ter			2	7200 bit/s, V.29			<u>3</u>	9600 bit/s, V.29	Page Width WD		<u>0</u> *)	1728 pixels in 215mm			1	2048 pixels in 255 mm			2	2432 pixels in 303 mm			3	1216 pixels in 151 mm			4	864 pixels in 107 mm	Page Length LN		0	A4, 297mm			1	B4, 364mm			<u>2</u>	unlimited length	Data Compression Format DF		<u>0</u> *)	1-D modified Huffman			1	2-D modified read			2	2-D uncompressed mode	Error correction (Annex A/T.30) EC		<u>0</u> *)	disable ECM			1	enable ECM, 64 bytes/frame			2	enable ECM, 256 bytes/frame	Binary File mode Transfer Mode BF		<u>0</u> *)	disable BFT			1	enable BFT	Scan Time/Line ST		<u>0</u> *)	0 ms (at VR= normal)			1	5 ms			2	10 ms			3	10 ms			4	20 ms			5	20 ms			6	40 ms			7	40 ms
Vertical Resolution VR		0	normal, 98 lpi																																																																																																																								
		<u>1</u>	fine, 196 lpi																																																																																																																								
Bit Rate BR		0	2400 bit/s, V.27ter																																																																																																																								
		1	4800 bit/s, V.27ter																																																																																																																								
		2	7200 bit/s, V.29																																																																																																																								
		<u>3</u>	9600 bit/s, V.29																																																																																																																								
Page Width WD		<u>0</u> *)	1728 pixels in 215mm																																																																																																																								
		1	2048 pixels in 255 mm																																																																																																																								
		2	2432 pixels in 303 mm																																																																																																																								
		3	1216 pixels in 151 mm																																																																																																																								
		4	864 pixels in 107 mm																																																																																																																								
Page Length LN		0	A4, 297mm																																																																																																																								
		1	B4, 364mm																																																																																																																								
		<u>2</u>	unlimited length																																																																																																																								
Data Compression Format DF		<u>0</u> *)	1-D modified Huffman																																																																																																																								
		1	2-D modified read																																																																																																																								
		2	2-D uncompressed mode																																																																																																																								
Error correction (Annex A/T.30) EC		<u>0</u> *)	disable ECM																																																																																																																								
		1	enable ECM, 64 bytes/frame																																																																																																																								
		2	enable ECM, 256 bytes/frame																																																																																																																								
Binary File mode Transfer Mode BF		<u>0</u> *)	disable BFT																																																																																																																								
		1	enable BFT																																																																																																																								
Scan Time/Line ST		<u>0</u> *)	0 ms (at VR= normal)																																																																																																																								
		1	5 ms																																																																																																																								
		2	10 ms																																																																																																																								
		3	10 ms																																																																																																																								
		4	20 ms																																																																																																																								
		5	20 ms																																																																																																																								
		6	40 ms																																																																																																																								
		7	40 ms																																																																																																																								
Reference EIA PN-2388	<p>Note Used for Faxclass 2 only</p>																																																																																																																										

3.11 AT+FDR Begin or continue phase C data reception

Execute command AT+FDR	The +FDR command initiates transition to Phase C data reception. Response CONNECT or OK If error is related to ME functionality: ERROR
Reference EIA PN-2388	Note Used for Faxclass 2 only

3.12 AT+FDT Data Transmission

Execute command AT+FDT	This command requests the ME to transmit a Phase C page. When the ME is ready to accept Phase C data, it issues the negotiation responses and the CONNECT result code to the application. In Phase B, the +FDT command releases the ME to proceed with negotiation, and releases the DCS message to the remote station. In Phase C, the +FDT command resumes transmission after the end of a data stream transmitted before. Response CONNECT
Write command AT+FDT =<dt>	Response CONNECT Parameter <dt> DF,VR,WD,LN comma separated parameter list Data Compression Format DF <u>0</u> 1-D modified Huffman 1 2-D modified read 2 2-D uncompressed mode Vertical Resolution VR 0 normal, 98 lpi <u>1</u> fine, 196 lpi Bit Rate BR 0 2400 bit/s, V.27ter 1 4800 bit/s, V.27ter 2 7200 bit/s, V.29 <u>3</u> 9600 bit/s, V.29 Page Width WD <u>0</u> 1728 pixels in 215mm 1 2048 pixels in 255 mm 2 2432 pixels in 303 mm 3 1216 pixels in 151 mm 4 864 pixels in 107 mm Page Length LN 0 A4, 297mm 1 B4, 364mm <u>2</u> unlimited length
Reference EIA PN-2388	Note Used for Faxclass 2 only

3.13 AT+FET End a page or document

Write command AT+FET=<ppm> >	This command indicates that the current page or partial page is complete. An ERROR response code results if this command is issued while the mode is on-hook. Response OK Parameter <ppm> Post Page Message Codes 1 another document next 2 no more pages or documents 4 another page, procedure interrupt 5 another document, procedure interrupt
Reference EIA PN-2388	Note Used for Faxclass 2 only

3.14 AT+FK Kill operation, orderly FAX abort

Execute command AT+FK	This command causes the TA to terminate the session in an orderly manner. Response OK
Reference	Note Used for Faxclass 2 only

3.15 AT+FLID Query or set the Local Id setting capabilities

Test command AT+FLID=?	Response (max. character length of Local ID string) (range of supported ASCII character values) OK Parameter See write command
Read command AT+FLID?	Response < lid > OK Parameter See write command
Write command AT+FLID =<lid>	Response OK Parameter <lid> Local ID string, max. length and possible content as reported by test command. Default value is empty string ("").
Reference EIA PN-2388	Note See also "AT+FCIG Query or set the Local polling id ", pg. 35. Used for Faxclass 2 only

3.16 AT+FMDL identify Product Model

Read command AT+FMDL?	Send the model identification to the TA Response Gipsy Soft Protocolstack OK
Reference Siemens	Note Used for Faxclass 2 only

3.17 AT+FMFR Request Manufacturer Identification

Read command AT+FMFR?	Send the manufacturer identification to the TA Response SIEMENS OK
Reference Siemens	Note Used for Faxclass 2 only

3.18 AT+FOPT Set bit order independently

Write command AT+FOPT=<opt> t>	Model specific command to set bit order independently of the understanding which is "mirrored" and which is direct. Response OK Parameter <table data-bbox="406 1310 798 1377"> <tr> <td><opt></td> <td>0</td> <td>non-standard</td> </tr> <tr> <td></td> <td>1</td> <td>standard</td> </tr> </table>	<opt>	0	non-standard		1	standard
<opt>	0	non-standard					
	1	standard					
Reference Siemens	Note Used for Faxclass 2 only						

3.19 AT+FPHCTO DTE Phase C Response Timeout

Read command AT+FPHCTO?	<p>The time-out value <tout> determines how long the DCE will wait for a command after reaching the end of data when transmitting in Phase C. When time-out is reached, the DCE assumes that there are no more pages or documents to send.</p> <p>Response <tout> OK</p> <p>Parameter See write command</p>
Write command AT+FPHCTO=<tout>	<p>Parameter <tout> 0 – <u>30</u> – 255 time-out value in 100ms units.</p> <p>Response OK If error is related to ME functionality: ERROR</p>
Reference EIA PN-2388	<p>Note Used for Faxclass 2 only</p>

3.20 AT+FREV Identify Product Revision

Test command AT+FREV?	<p>Sends the revision identification to the TA</p> <p>Response V2.550 OK</p>
Reference Siemens	<p>Note Used for Faxclass 2 only</p>

3.21 AT+FRH Receive Data Using HDLC Framing

Execute command AT+FRH=<mod>	<p>This command causes the TA to receive frames using the HDLC protocol and the modulation defined below. An ERROR response code results if this command is issued while the modem is on-hook.</p> <p>Response CONNECT If error is related to ME functionality: ERROR</p> <p>Parameter <mod> modulation mode</p> <table border="0"> <tr> <td>3</td> <td>V21 Ch2</td> <td>300 bps</td> </tr> <tr> <td>24</td> <td>V.27ter</td> <td>2400 bps</td> </tr> <tr> <td>48</td> <td>V.27ter</td> <td>4800 bps</td> </tr> <tr> <td>72</td> <td>V.29</td> <td>7200 bps</td> </tr> <tr> <td>96</td> <td>V.29</td> <td>9600 bps</td> </tr> </table>	3	V21 Ch2	300 bps	24	V.27ter	2400 bps	48	V.27ter	4800 bps	72	V.29	7200 bps	96	V.29	9600 bps
3	V21 Ch2	300 bps														
24	V.27ter	2400 bps														
48	V.27ter	4800 bps														
72	V.29	7200 bps														
96	V.29	9600 bps														
Reference TIA/EIA-578	<p>Note Used for Faxclass 1 only</p>															

3.22 AT+FRM Receive Data

Test command AT+FRM=?	Response (List of supported modulation modes <mod>s) OK Parameter See write command																
Write command AT+FRM=<mod>	This command causes the TA to enter the receiver-mode using the modulation defined below. An ERROR response code results if this command is issued while the modem is on-hook. Response CONNECT If error is related to ME functionality: ERROR Parameter <table border="0"> <tr> <td><mod></td> <td>96</td> <td>V.29</td> <td>9600 bps</td> </tr> <tr> <td></td> <td>72</td> <td>V.29</td> <td>7200 bps</td> </tr> <tr> <td></td> <td>48</td> <td>V.27ter</td> <td>4800 bps</td> </tr> <tr> <td></td> <td>24</td> <td>V.27ter</td> <td>2400 bps</td> </tr> </table>	<mod>	96	V.29	9600 bps		72	V.29	7200 bps		48	V.27ter	4800 bps		24	V.27ter	2400 bps
<mod>	96	V.29	9600 bps														
	72	V.29	7200 bps														
	48	V.27ter	4800 bps														
	24	V.27ter	2400 bps														
Reference TIA/EIA-578	Note Used for Faxclass 1 only																

3.23 AT+FRS Receive Silence

Write command AT+FRS=<time> >	+FRS=n causes the TA to report an OK result code to the TE after <time> 10 millisecond intervals of silence have been detected on the line. This command is aborted if any character is received by the DTE. The modem discards the aborting character and issues an OK result code. An ERROR response code results if this command is issued while the mode is on-hook. Response OK If error is related to ME functionality: ERROR Parameter <table border="0"> <tr> <td><time></td> <td>0 – 255</td> <td>no. Of 10 millisecond intervals</td> </tr> </table>	<time>	0 – 255	no. Of 10 millisecond intervals
<time>	0 – 255	no. Of 10 millisecond intervals		
Reference TIA/EIA-578	Note Used for Faxclass 1 only			

3.24 AT+FTH Transmit Data Using HDLC Framing

Write command AT+FTH=<mod> >	This command causes the TA to transmit data using HDLC protocol and the modulation mode defined below. An ERROR response code results if this command is issued while the modem is on-hook. Response CONNECT Parameter <table border="0"> <tr> <td><mod></td> <td>3</td> <td>V.21 Ch2</td> <td>300 bps</td> </tr> </table>	<mod>	3	V.21 Ch2	300 bps
<mod>	3	V.21 Ch2	300 bps		
Reference TIA/EIA-578	Note Used for Faxclass 1 only				

3.25 AT+FTM Transmit Data

Test command AT+FTM=?	Response (List of supported modulation modes) OK Parameter See write command																				
Write command AT+FTM=<mod>	This command causes the TA to transmit data using the modulation mode defined below. An ERROR response code results if this command is issued while the modem is on-hook. Response CONNECT If error is related to ME functionality: ERROR Parameter <table border="0"> <tr> <td><mod></td> <td>modulation mode</td> <td></td> <td></td> </tr> <tr> <td>96</td> <td>V.29</td> <td>9600</td> <td>bps</td> </tr> <tr> <td>72</td> <td>V.29</td> <td>7200</td> <td>bps</td> </tr> <tr> <td>48</td> <td>V.27ter</td> <td>4800</td> <td>bps</td> </tr> <tr> <td>24</td> <td>V.27ter</td> <td>2400</td> <td>bps</td> </tr> </table>	<mod>	modulation mode			96	V.29	9600	bps	72	V.29	7200	bps	48	V.27ter	4800	bps	24	V.27ter	2400	bps
<mod>	modulation mode																				
96	V.29	9600	bps																		
72	V.29	7200	bps																		
48	V.27ter	4800	bps																		
24	V.27ter	2400	bps																		
Reference TIA/EIA-578	Note Used for Faxclass 1 only																				

3.26 AT+FTS Stop Transmission and Wait

Write command AT+FTS=<time>	This command causes the TA to terminate a transmission and wait for <time> 10 millisecond intervals before responding with the OK result code to the DTE. Response An ERROR response code results if this command is issued while the modem is on-hook. Parameter <table border="0"> <tr> <td><time></td> <td>0 – 85</td> <td>no. of 10 millisecond intervals</td> </tr> </table>	<time>	0 – 85	no. of 10 millisecond intervals
<time>	0 – 85	no. of 10 millisecond intervals		
Reference TIA/EIA-578	Note Used for Faxclass 1 only			

3.27 AT+FVRFC Vertical resolution format conversion

Test command AT+FVRFC=?	This command determines the DCE response to a mismatch between the vertical resolution negotiated for the facsimile session and the Phase C data desired by the DTE. Response (List of supported mismatch checking modes) OK Parameter See write command
Read command AT+FVRFC?	Response <vrfc> OK Parameter See write command
Write command AT+FVRFC =<vrfc>	Response OK Parameter <vrfc> 0 disable mismatch checking. <u>2</u> enable mismatch checking, with resolution conversion of 1-D data in the DCE, and an implied AT+FK command executed on 2-D mismatch detection
Reference EIA PN-2388	Note Used for Faxclass 2 only

The following AT-commands are dummy commands. Invoking these commands will not cause ERROR result codes, but these commands have no functionality.

AT+FAA	Auto Answer mode
AT+FECM	Error Correction Mode control
AT+FLNFC	Page Length format conversion
AT+FLPL	Indicate document available for polling
AT+FMINS	Minimum Phase C speed
AT+FRBC	Phase C data receive byte count
AT+FREL	Phase C received EOL alignment
AT+FSPL	Enable polling
AT+FTBC	Phase C data transmit byte count
AT+FWDFC	Page width format conversion

4 AT Commands originating from GSM 07.07

These AT Commands are according to ETSI (European Telecommunications Standards Institute) GSM 07.07 document.

4.1 AT+CACM Accumulated call meter (ACM) reset or query

Test command AT+CACM=?	Response OK Parameter
Read command AT+CACM?	Response TA returns the current ACM value. +CACM: <acm> OK If error is related to ME functionality: +CME ERROR: <err> Parameter <acm> string type; three bytes of the current ACM value in hexadecimal format (e.g. "00001E" indicates decimal value 30) 000000 – FFFFFFFF
Write command AT+CACM= [<passwd>]	Parameter <passwd> string type: SIM PIN2 Response TA resets the Advice of Charge related to the accumulated call meter (ACM) value in SIM file EF(ACM). ACM contains the total number of home units for both the current and preceding calls. OK If error is related to ME functionality: +CME ERROR: <err>
Reference GSM 07.07	Note

4.2 AT+CALA Set alarm time

<p>Test command AT+CALA=?</p>	<p>Test command returns supported array index values <n>, alarm types <type>, and maximum length of the text <tlength> to be output.</p> <p>Response +CALA: (list of supported <n>s), (list of supported <type>s), (range of supported <tlength>) OK If error is related to ME functionality: +CME ERROR: <err></p> <p>Parameter See write command</p>
<p>Read command AT+CALA?</p>	<p>Read command returns the list of current active alarm settings in the ME.</p> <p>Response +CALA: <time>[,<n>[,<type>[,<text>]]] If error is related to ME functionality: +CME ERROR: <err></p> <p>Parameter See write command</p>
<p>Write command AT+CALA=<time>[,<n>[,<type>[,<text>]]]</p>	<p>The write command sets an alarm time in the ME. The alarm is retained only when (and if!) the device enters the power-down mode via AT^SMSO (pg. 120). The alarm set is lost in case of total power-disconnection. However, in this case the clock starts with <time> = "00/01/01,00:00:00" on next power-up (see +CCLK, pg. 54).</p> <p>Response OK If setting fails in an ME error: +CME ERROR: <err> Refer subclause 7.1, pg. 134, for <err> values.</p> <p>Parameter</p> <p><time> string type value; format is "yy/MM/dd,hh:mm:ss", where characters indicate year (two last digits), month, day, hour, minutes. E.g. 6th of May 1994, 22:10:00 hours equals to "94/05/06,22:10:00" (refer +CCLK).</p> <p><n> integer type value indicating the array index of the alarm. Index starts with 0. If only this value is returned by the test command, it is default and indicates that only one alarm time is possible; however, if a second alarm time is set, the previous alarm is deleted.</p> <p><type> integer type value indicating the type of the alarm 0 Alarm indication: text message via serial interface</p> <p><text> string type value indicating the text to be displayed when alarm time is reached; maximum length is <tlength>. After first connection to power supply <text> is undefined. <i>Note:</i> <text> will be stored in non-volatile flash memory when the device enters the power-down mode via AT^SMSO (pg. 120). <text></p>

	<p>is available after power-off and any happened alarm. Therefore for consecutive alarm settings input <text> again is not necessary and should be avoided due to limited no. of flash memory write cycles (e.g. 100.000).</p> <p><tlength> integer type value indicating the maximum length of <text>. The maximum length is 16.</p>
	<p>Unsolicited result code As indication of an alarm event output is: +CALA: <text></p>
Reference GSM 07.07	<p>Note</p> <p><text> should not contain characters which are coded differently in ASCII and GSM (e.g. Ä, Ö, Ü), see also „Supported character sets“, pg. 10 and “Alphabet tables“, pg. 144.</p> <p>Please consider when using multiplex mode (+CMUX, pg. 67):</p> <ol style="list-style-type: none"> 1. It is possible to use +CALA with every logical channel (1 – 3). 2. The total no. of possible alarm events is shared by all channels. If <n> = 0 is returned by the test command, this indicates that only one common alarm time is possible for all logical channels. 3. For every channel a different <text> parameter can be stored. 4. <text> will be output on the same logical channel the alarm was entered. If not in multiplex mode, <text> will be output independent of the related channel. 5. The read command returns all pending alarms, independent on which logical channel an alarm was entered. It's up to the user to identify these alarms by specific <text>s.

4.3 AT+CAMM Accumulated call meter maximum (ACMmax) set or query

<p>Test command AT+CAMM=?</p>	<p>Response OK Parameter</p>
<p>Read command AT+CAMM?</p>	<p>Response TA returns the current ACMmax value. +CAMM: <acmmax> OK If error is related to ME functionality: +CME ERROR: <err> Parameter See write command</p>
<p>Write command AT+CAMM=[<acmmax>[,<passwd>]]</p>	<p>Response TA sets the Advice of Charge related to the accumulated call meter maximum value in SIM file EF (ACMmax). ACMmax contains the maximum number of home units allowed to be consumed by the subscriber. OK If error is related to ME functionality: +CME ERROR: <err> Parameter <acmmax> string type; three bytes of the max. ACM value in hexadecimal format (e.g. "00001E" indicates decimal value 30) 000000 disable ACMmax feature 000001-FFFFFF <passwd> string type SIM PIN2</p>
<p>Reference GSM 07.07</p>	<p>Note</p>

4.4 AT+CAOC Advice of Charge information

Test command AT+CAOC=?	Response +CAOC: (list of supported <mode>s) OK Parameter See write command
Read command AT+CAOC?	Response +CAOC: <mode> OK Parameter See write command
Write command AT+CAOC= <mode>	Response TA sets the Advice of Charge supplementary service function mode. If error is related to ME functionality: +CME ERROR: <err> If <mode>=0, TA returns the current call meter value OK Parameter <mode> 0 query CCM value <ccm> string type; three bytes of the current CCM value in hexadecimal format (e.g. "00001E" indicates decimal value 30); bytes are similarly coded as ACMmax value in the SIM 000000-FFFFFF
Execute command AT+CAOC	Response TA returns the current call meter value If error is related to ME functionality: +CME ERROR: <err> If <mode>=0, TA returns the current call meter value +CAOC: <ccm> OK Parameter See write command
Reference GSM 07.07	Note

4.5 AT+CBST Select bearer service type

<p>Test command AT+CBST=?</p>	<p>Response +CBST: (list of supported <speed>s) ,(list of supported <name>s) ,(list of supported <ce>s) OK Parameter See write command</p>														
<p>Read command AT+CBST?</p>	<p>Response +CBST: <speed>,<name>,<ce> OK Parameter See write command</p>														
<p>Write command AT+CBST= [<speed> [,<name> me>[,<ce>]]]</p>	<p>Response TA selects the bearer service <name> with data rate <speed> and the connection element <ce> to be used when data calls are originated. Values may also be used during mobile terminated data call setup, especially in case of single numbering scheme calls. OK Parameter <speed></p> <table data-bbox="638 1003 1018 1249"> <tr><td>0</td><td>auto bauding</td></tr> <tr><td>4</td><td>2400 bps(V.22bis)</td></tr> <tr><td>6</td><td>4800 bps(V.32)</td></tr> <tr><td><u>7</u></td><td>9600 bps(V.32)</td></tr> <tr><td>68</td><td>2400 bps (V.110)</td></tr> <tr><td>70</td><td>4800 bps (V.110)</td></tr> <tr><td>71</td><td>9600 bps (V.110)</td></tr> </table> <p><name> 0 asynchronous modem <ce> 1 non-transparent Transparent mode is not available at TC35</p>	0	auto bauding	4	2400 bps(V.22bis)	6	4800 bps(V.32)	<u>7</u>	9600 bps(V.32)	68	2400 bps (V.110)	70	4800 bps (V.110)	71	9600 bps (V.110)
0	auto bauding														
4	2400 bps(V.22bis)														
6	4800 bps(V.32)														
<u>7</u>	9600 bps(V.32)														
68	2400 bps (V.110)														
70	4800 bps (V.110)														
71	9600 bps (V.110)														
<p>Reference GSM 07.07</p>	<p>Note GSM 02.02[1]: List of allowed combinations of subparameters. The PLMN influences the second air interface (to the terminator), therefore another mode may be established by the network.</p>														

4.6 AT+CCFC Call forwarding number and conditions control

<p>Test command AT+CCFC=?</p>	<p>Response +CCFC: (list/range of supported <reas>s) OK</p> <p>Parameter See execute command</p>																																																			
<p>Execute command AT+CCFC = <reas>, <mode> [, <number>], <type> [,<class> [,<time>]]]</p>	<p>Response TA controls the call forwarding supplementary service. Registration, erasure, activation, deactivation, and status query are supported. When querying the status of a network service (<mode> = 2), the response line for 'not active' (<status> = 0) should be returned only if service is not active for any <class>.</p> <p>If <mode> <>2 and command successful OK</p> <p>If <mode> = 2 and command successful (only in connection with <reas> 03) +CCFC: <status>, <class1>[, <number>, <type> [, <time>]] [<cr><lf>+ccfc:]="" b="" ok<=""></cr><lf>+ccfc:></p> <p>If error is related to ME functionality: +CME ERROR: <err></p> <p>Parameter</p> <table border="0"> <tr> <td><reas></td> <td>0</td> <td>unconditional</td> </tr> <tr> <td></td> <td>1</td> <td>mobile busy</td> </tr> <tr> <td></td> <td>2</td> <td>no reply</td> </tr> <tr> <td></td> <td>3</td> <td>not reachable</td> </tr> <tr> <td></td> <td>4</td> <td>reason not supported</td> </tr> <tr> <td></td> <td>5</td> <td>reason not supported</td> </tr> <tr> <td><mode></td> <td>0</td> <td>disable</td> </tr> <tr> <td></td> <td>1</td> <td>enable</td> </tr> <tr> <td></td> <td>2</td> <td>query status</td> </tr> <tr> <td></td> <td>3</td> <td>registration</td> </tr> <tr> <td></td> <td>4</td> <td>erasure</td> </tr> </table> <p><number> string type phone number of forwarding address in format specified by <type></p> <p><type> type of address in integer format; default 145 when dialling string includes international access code character "+", otherwise 129</p> <table border="0"> <tr> <td><class></td> <td>1</td> <td>voice</td> </tr> <tr> <td></td> <td>2</td> <td>data</td> </tr> <tr> <td></td> <td>4</td> <td>fax</td> </tr> <tr> <td></td> <td>7</td> <td>all classes</td> </tr> </table> <p><time> time to wait before call is forwarded, rounded to a multiple of 5 sec. Default is 20. 1...20..30 (only for <reas>=no reply)</p> <table border="0"> <tr> <td><status></td> <td>0</td> <td>not active</td> </tr> <tr> <td></td> <td>1</td> <td>active</td> </tr> </table>	<reas>	0	unconditional		1	mobile busy		2	no reply		3	not reachable		4	reason not supported		5	reason not supported	<mode>	0	disable		1	enable		2	query status		3	registration		4	erasure	<class>	1	voice		2	data		4	fax		7	all classes	<status>	0	not active		1	active
<reas>	0	unconditional																																																		
	1	mobile busy																																																		
	2	no reply																																																		
	3	not reachable																																																		
	4	reason not supported																																																		
	5	reason not supported																																																		
<mode>	0	disable																																																		
	1	enable																																																		
	2	query status																																																		
	3	registration																																																		
	4	erasure																																																		
<class>	1	voice																																																		
	2	data																																																		
	4	fax																																																		
	7	all classes																																																		
<status>	0	not active																																																		
	1	active																																																		
<p>Reference GSM 07.07</p>	<p>Note If status is "not active" parameter <class> can be ignored (0)</p>																																																			

4.7 AT+CCLK Real Time Clock	
Test command AT+CCLK=?	Response OK
Read command AT+CCLK?	Response +CCLK: <time> OK/ERROR/+CME ERROR Parameter: <time>: string type value; format is "yy/MM/dd, hh:mm:ss", where characters indicate year (two last digits), month, day, hour, minutes; e.g. 6 th of May 1994, 22:10:00 hours equals to "94/05/06,22:10:00"
Write command AT+CCLK=<time>	Response OK/ERROR/+CME ERROR Parameter: <time> see read command
Reference GSM 07.07	Note 1. <time> is retained if the device enters the power-down mode via AT^SMSO (pg. 120), and may be switched on via an alarm event (see AT+CALA, pg. 48). 2. <time> is lost in the case of total power-disconnection (and no separate battery back-up for the clock is provided via the ZIF-cable). In this case the clock starts with <time> = "00/01/01,00:00:00" on next power-up.

4.8 AT+CEER Extended error report	
Test command AT+CEER=?	Response OK
Execute command AT+CEER	TA returns an extended error report of the reason for the last call release and location. Response +CEER: <location ID>, <reason>, <ss_release>OK Parameter <location ID> Location ID as number code (see subclause 7.5) <reason> Reason for last call release as number code (see subclause 7.6) <ss_release> Release cause for last Supplementary Service Call (see subclause 7.7)
Reference GSM 07.07	Note <ul style="list-style-type: none"> AT+CEER is not available for data calls, please use AT+SMS18=1. Default output in the case of a no-error-situation is +CEER: 0,0,0.

4.9 AT+CFUN Set phone functionality

<p>Test command AT+CFUN=?</p>	<p>Response</p> <p>The write command selects the level of functionality <fun> in the ME. Level "full functionality" is where the highest level of power is drawn. "Minimum functionality" is where minimum power is drawn.</p> <p>+CFUN: (list of supported <fun>s), (list of supported <rst>s)</p> <p>If error is related to ME functionality: +CME ERROR: <err></p>
	<p>Parameter See below</p>
<p>Read command AT+CFUN?</p>	<p>Response</p> <p>+CFUN: <fun></p> <p>If error is related to ME functionality: +CME ERROR: <err></p>
	<p>Parameter See below</p>
<p>Execute command AT+CFUN=[<fun>,<rst>]</p>	<p>Response</p> <p>OK</p> <p>If error is related to ME functionality: +CME ERROR: <err></p>
	<p>Parameter</p> <p><fun> 0 Minimum functionality (Sleep mode) <i>Note:</i> If command AT+CFUN=0 is input, do not send further characters until the device really has entered sleep mode. Otherwise these characters remain in the input buffer and will delay output of an URC (see pg. 137, e.g. "RING"). <i>Note:</i> Any established connection will be terminated.</p> <p> 1 Full functionality (only used as placeholder for +CFUN=1,1).</p> <p><rst> 0 Do not reset the ME before setting it to <fun> power level. (only used as placeholder for +CFUN=0,0).</p> <p> 1 ME resets and restarts in full functionality mode. If <rst> = 1 the first parameter <fun> has no effect.</p>
<p>Reference GSM 07.07</p>	<p>Note</p> <ol style="list-style-type: none"> For indication of current ME's operation mode see „AT^SSYNC Configure SYNC Pin“, pg. 132. Identify a ME's standby mode can be done via it's lowered supply current only. The time power saving can start after command issue is unspecified due to remaining network activities. After restart it is necessary to use AT+CPIN again. GSM module wakes up with incoming call, Real Time Clock alarm, falling edge of RTS (RS-232 levels) and with the appearance of an unsolicited result code (URC, see chapter 7.3).

4.10 AT+CGMI Request manufacturer identification

Test command AT+CGMI=?	Response OK
Execute command AT+CGMI	Response TA returns manufacturer identification text. SIEMENS OK
Reference GSM 07.07	Note See also "AT+GMI Request manufacturer identification".

4.11 AT+CGMM Request model identification

Test command AT+CGMM=?	Response OK
Execute command AT+CGMM	Response TA returns product model identification text. TC35 OK
Reference GSM 07.07	Note See also "AT+GMM Request TA model identification".

4.12 AT+CGMR Request revision identification of software status

Test command AT+CGMR=?	Response OK
Execute command AT+CGMR	Response TA returns product firmware version identification text. <revision> OK Parameter <revision> x.yy Explanation of „Revision“ parameter: Version x and variant yy of software release.
Reference GSM 07.07	Note See also "AT+GMR Request TA revision identification of software status".

4.13 AT+CGSN Request product serial number identification (IMEI) identical to GSN

Test command AT+CGSN=?	Response OK
Execute command AT+CGSN	Response TA returns identification text for determination of the individual ME. <sn> OK Parameter <sn> IMEI of the telephone (International Mobile station Equipment Identity)
Reference GSM 07.07	Note See also "AT+GSN Request TA serial number identification".

4.14 AT+CHLD Call hold and multiparty

Test command AT+CHLD=?	Response +CHLD: (list of supported <n>s) OK												
Execute command AT+CHLD=[<n >]	Response TA controls the supplementary services Call Hold, MultiParty and Explicit Call Transfer. Calls can be put on hold, recovered, released, added to conversation and transferred. <i>Note:</i> Supplementary services are only applicable to teleservice 11 (Speech telephony). OK If error is related to ME functionality: +CME ERROR: <err> Parameter <n> <table border="0" style="margin-left: 20px;"> <tr> <td style="padding-right: 20px;">0</td> <td>Terminate all held calls or UDUB (User Determined User Busy) for a waiting call</td> </tr> <tr> <td>1</td> <td>Terminate all active calls (if any) and accept the other call (waiting call or held call)</td> </tr> <tr> <td>1X</td> <td>Terminate the active call number X (X= 1-7)</td> </tr> <tr> <td>2</td> <td>Place all active calls on hold (if any) and accept the other call (waiting call or held call) as the active call</td> </tr> <tr> <td>2X</td> <td>Place all active calls except call X (X= 1-7) on hold</td> </tr> <tr> <td>3</td> <td>Add the held call to the active calls</td> </tr> </table> Note: If both held and a waiting call exists the above procedures shall apply to the waiting call (i.e. not to the held call) in conflicting situations.	0	Terminate all held calls or UDUB (User Determined User Busy) for a waiting call	1	Terminate all active calls (if any) and accept the other call (waiting call or held call)	1X	Terminate the active call number X (X= 1-7)	2	Place all active calls on hold (if any) and accept the other call (waiting call or held call) as the active call	2X	Place all active calls except call X (X= 1-7) on hold	3	Add the held call to the active calls
0	Terminate all held calls or UDUB (User Determined User Busy) for a waiting call												
1	Terminate all active calls (if any) and accept the other call (waiting call or held call)												
1X	Terminate the active call number X (X= 1-7)												
2	Place all active calls on hold (if any) and accept the other call (waiting call or held call) as the active call												
2X	Place all active calls except call X (X= 1-7) on hold												
3	Add the held call to the active calls												
Reference GSM 07.07	Note												

4.15 AT+CHUP Hang up call	
Test command AT+CHUP=?	Response OK
Execute command AT+CHUP	Cancel all active and held calls. Response OK/ERROR
Reference GSM 07.07	Note

4.16 AT+CIMI Request international mobile subscriber identity	
Test command AT+CIMI=?	Response OK
Execute command AT+CIMI	Response TA returns < IMSI > for identifying the individual SIM which is attached to ME. <IMSI> OK If error is related to ME functionality: +CME ERROR: <err> Parameter <IMSI> International Mobile Subscriber Identity (string without double quotes)
Reference GSM 07.07	Note

4.17 AT+CLCC List current calls of ME

<p>Test command AT+CLCC=?</p>	<p>Response OK Parameters</p>
<p>Execute command AT+CLCC</p>	<p>Response TA returns a list of current calls of ME. Note: If command succeeds but no calls are available, no information response is sent to TE. [+CLCC: <id1>,<dir>,<stat>,<mode>,<mpty>,<number>,<type>,<alpha>]]] [<CR><LF>+CLCC: <id2>,<dir>,<stat>,<mode>,<mpty>,<number>,<type>,<alpha>]]] [...]]] OK If error is related to ME functionality: +CME ERROR: <err></p>
	<p>Parameters</p> <p><idx> Integer type; call identification number as described in GSM 02.30[19] subclause 4.5.5.1; this number can be used in +CHLD command operations</p> <p><dir> 0 mobile originated (MO) call 1 mobile terminated (MT) call</p> <p><stat> state of the call: 0 active 1 held 2 dialing (MO call) 3 alerting (MO call) 4 incoming (MT call) 5 waiting (MT call)</p> <p><mode> bearer/teleservice: 0 voice 1 data 2 fax 9 unknown</p> <p><mpty> 0 call is not one of multiparty (conference) call parties 1 call is one of multiparty (conference) call parties</p> <p><number> string type phone number in format specified by <type></p> <p><type> type of address octet in integer format; 145 when dialling string includes international access code character "+", otherwise 129</p> <p><alpha> string type alphanumeric representation of <number> corresponding to the entry found in phone-book; used character set should be the one selected with command Select TE Character Set +CSCS</p>
<p>Reference GSM 07.07</p>	<p>Note</p>

4.18 AT+CLCK Facility lock

<p>Test command AT+CLCK=?</p>	<p>Response +CLCK: (list of supported <fac>s) OK Parameter See execute command</p>
<p>Execute command AT+CLCK = <fac>, <mode> [, <passwd> [, <class>]]</p>	<p>This command is used to lock, unlock or interrogate a ME or a network facility <fac>. When querying the status of a network service (<mode> = 2) the response line for a 'not active' case (<status> = 0) should be returned only if service is not active for any <class>. It should be possible to abort the command when network facilities are set or interrogated.</p> <p>If <mode> <> 2 and command is successful Response OK If <mode> = 2 and command is successful +CLCK: <status>[, <class1>]<CR><LF> +CLCK: <status>, class2....]] OK If error is related to ME functionality: +CME ERROR: <err></p> <p>Parameter <fac> "CS" Keypad lock (not supported since keypad cannot be connected) "PS" PH-SIM (lock PHone to SIM card). ME requests password when other than current SIM card inserted; ME may remember certain number of previously used cards thus not requiring password when they are inserted. "SC" SIM (lock SIM cards). SIM requests password upon ME power-up and when this lock command issued. "FD" SIM fixed dialling memory feature (if PIN2 authentication has not been performed during the current session, PIN2 is required as <passwd>) "AO" BAOC (Bar All Outgoing Calls) "OI" BOIC (Bar Outgoing International Calls) "OX" BOIC-exHC (Bar Outgoing International Calls except to Home Country) "AI" BAIC (Bar All Incoming Calls) "IR" BIC-Roam (Bar Incoming Calls when Roaming outside the home country) "AB" All Barring services (applicable only for <mode>=0) "AG" All outGoing barring services (applicable only for <mode>=0) "AC" All inComing barring services (applicable only for <mode>=0)</p> <p><u>The following parameters depend on the factory settings:</u> "PF" lock Phone to the very First SIM card "PN" Network Personalisation "PU" Network subset Personalisation "PP" Service Provider Personalisation "PC" Corporate Personalisation</p>

	<p><mode></p> <ul style="list-style-type: none"> 0 unlock 1 lock 2 query status <p><passwd> password</p> <p><class></p> <ul style="list-style-type: none"> 1 voice 2 data 4 fax 7 all classes (default) <p><status></p> <ul style="list-style-type: none"> 0 off 1 on
<p>Reference GSM 07.07</p>	<p>Note A password is needed before the first use of <fac>“PS” and therefore has to be given via AT+CPWD.</p>

4.19 AT+CLIP Calling line identification presentation

<p>Test command AT+CLIP=?</p>	<p>This command refers to the GSM supplementary service CLIP (Calling Line Identification Presentation) that enables a called subscriber to get the calling line identity (CLI) of the calling party when receiving a mobile terminated call.</p> <p>Response + CLIP: (list of supported <n>s) OK</p> <p>Parameter See write command</p>
<p>Read command AT+CLIP?</p>	<p>Response +CLIP: <n>, <m> OK</p> <p>If error is related to ME functionality: +CME ERROR: <err></p> <p>Parameter See write command</p>
<p>Write command AT+CLIP=<n></p>	<p>Set command enables or disables the presentation of the CLI at the TE. It has no effect on the execution of the supplementary service CLIP in the network.</p> <p>Response OK</p> <p>If error is related to ME functionality: +CME ERROR: <err></p> <p>Parameter</p> <p><n> 0 suppress unsolicited result codes 1 display unsolicited result codes</p> <p><m> 0 CLIP not provisioned 1 CLIP provisioned 2 unknown</p>
	<p>Unsolicited result code</p> <p>When CLIP is enabled at the TE (and is permitted by the calling subscriber), an unsolicited result code is returned after every RING (or +CRING: <type>) at a mobile terminating call.</p> <p>Voice call response format: +CLIP: <number>, <type>,,,<CLI validity></p> <p>Data/FAX call response format: +CLIP: <number>, <type></p> <p>Parameter</p> <p><number> string type phone number of calling address in format specified by <type></p> <p><type> type of address octet in integer format; 145 when dialling string includes international access code character "+", otherwise 129.</p> <p><CLI validity></p> <p>0 CLI valid 1 CLI has been withheld by the originator. 3 CLI is not available due to interworking problems or limitations of originating network. <number> shall be an empty string ("") and <type> value will not be significant.</p>
<p>Reference GSM 07.07</p>	<p>Note</p>

4.20 AT+CLIR Calling line identification restriction (done by *# Sequence)

This command is not available in TC35, but the same function can be invoked by ATD*31#<Phonenumber> (presentation of number) and ATD#31#<Phonenumber> (no number presentation) command.

Current settings can be queried with ATD*#31#;
The result will be:

+CLIR: <n>,<m>

Defined values

<n> (parameter sets the adjustment for outgoing calls):

- 0 presentation indicator is used according to the subscription of the CLIR service
- 1 CLIR invocation
- 2 CLIR suppression

<m> (parameter shows the subscriber CLIR service status in the network):

- 0 CLIR not provisioned
- 1 CLIR provisioned in permanent mode
- 2 unknown (e.g. no network, etc.)
- 3 CLIR temporary mode presentation restricted
- 4 CLIR temporary mode presentation allowed

4.21 AT+CLVL Loudspeaker volume level

Test command AT+CLVL=?	Response +CLVL: (list of supported <level>s) OK
Read command AT+CLVL?	Response +CLVL: <level> OK/ERROR/+CME ERROR
Write command AT+CLVL=<level>	Response OK/ERROR/+CME ERROR Parameter <level> Loudspeaker Volume Level (0-4)
Reference GSM 07.07	Note 1. The volume level is not changeable in audio mode 1. 2. The changed volume level value will not be saved with AT^SNFW, instead it will be saved after AT^SMSO only.

4.22 AT+CMEE Report mobile equipment error	
Test command AT+CMEE=?	Response +CMEE: (list of supported <n>s) OK Parameter See write command
Read command AT+CMEE?	Response +CMEE: <n> OK Parameter See write command
Write command AT+CMEE=<n>	TA disables or enables the use of result code +CME ERROR: <err> as an indication of an error relating to ME functionality. Response OK Parameter <n> <u>0</u> disable result code 1 enable result code and use numeric values 2 enable result code and use verbose values
Reference GSM 07.07	Note The possible error result codes are listed in chapter 7 If using multiplex mode (see "AT+CMUX Enter multiplex mode", pg. 67): A setting with this command is only valid for the logical channel via it was issued. The setting of the other channels may differ.

4.23 AT+CMUT Mute control

Test command AT+CMUT=?	Response +CMUT: (list of supported <n>s) OK
Read command AT+CMUT?	Response +CMUT: <n> OK/ERROR/+CME ERROR
Write command AT+CMUT=<n>	Response OK/ERROR/+CME ERROR Parameter <n>: 0 mute off 1 mute on
Reference GSM 07.07	Note

	<ol style="list-style-type: none"> 4. There are different possibilities to switch from data mode to command mode: <ol style="list-style-type: none"> a) Circuit 108/2 (DTR) changes from ON to OFF, reaction depends on command at&d (caution: at&d0: TA ignores status on DTR). b) The message Modem Status Command (MSC) for control channel is defined by the multiplexer protocol GSM07.10. MSC conveys V.24 signals. Bit 3 of Control Signal Octet is DTR, reaction depends on command at&d (caution: at&d0: TA ignores status on DTR). 5. The parameter maximum frame size (N1) of at+cmux in GSM07.07 is fixed to 97, the parameter is not changeable. All other parameters are not available. 6. Echo is disabled with the start of multiplex mode (see ATE, pg. 18). Therefore echo is not available on logical channels: ATE0 responds with OK, ATE1 responds with ERROR. 7. Multiplex mode can't be activated if autobauding is active (+IPR=0, see "AT+IPR Set fixed local rate", pg. 31). 8. If multiplex mode has been entered, AT+IPR=<rate> is not possible. 9. Multiplex mode can be terminated with AT^SMSO („AT^SMSO Switch off mobile station" pg. 120). It has to be reestablished after power-on.
--	---

4.25 AT+COPN Read operator names	
Test command AT+COPN=?	Response OK
Execute command AT+COPN	<p>TA returns the list of operator names from the ME. Each operator code <numeric> that has an alphanumeric equivalent <alphan> in the ME memory is returned.</p> <p>Response +COPN: numeric <numeric1>,long alphanumeric <alpha1><CR><LF> +COPN:.....OK</p> <p>If error is related to ME functionality: +CME ERROR: <err></p> <p>Parameter</p> <p><numeric> string type; operator in numeric form; GSM location area identification number</p> <p><alphan> string type; operator in long alphanumeric format; can contain up to 16 characters</p>
Reference GSM 07.07	Note See also AT^SPLM, pg. 129

4.26 AT+COPS Operator selection

<p>Test command AT+COPS=?</p>	<p>Response</p> <p>TA returns a list of quadruplets, each representing an operator present in the network. Any of the formats may be unavailable and will then be an empty field (,,). The list of operators comes in the following order: Home network, networks referenced in SIM, and other networks.</p> <p>+COPS: (list of supported<stat>, long alphanumeric <oper>,, numeric <oper>s) [(list of supported <mode>s), (list of supported <format>s)] OK</p> <p>If error is related to ME functionality: +CME ERROR: <err></p> <p>Parameter See write command</p>																																				
<p>Read command AT+COPS?</p>	<p>Response</p> <p>TA returns the current mode and the currently selected operator. If no operator is selected, <format> and <oper> are omitted.</p> <p>+COPS: <mode>[, <format>[, <oper>]] OK</p> <p>If error is related to ME functionality: +CME ERROR: <err></p> <p>Parameter See write command</p>																																				
<p>Write command AT+COPS = <mode> [, <format>[, <oper>]]</p>	<p>Response</p> <p>TA forces an attempt to select and register the GSM network operator. If the selected operator is not available, no other operator shall be selected (except <mode>=4). The selected operator name format shall apply to further read commands (+COPS?) also.</p> <p><u>Parameters used</u></p> <p>OK</p> <p>If error is related to ME functionality: +CME ERROR: <err></p> <p>Parameter</p> <table border="0"> <tr> <td style="vertical-align: top;"><stat></td> <td style="vertical-align: top;">0</td> <td style="vertical-align: top;">unknown</td> </tr> <tr> <td></td> <td style="vertical-align: top;">1</td> <td style="vertical-align: top;">operator available</td> </tr> <tr> <td></td> <td style="vertical-align: top;">2</td> <td style="vertical-align: top;">operator current</td> </tr> <tr> <td></td> <td style="vertical-align: top;">3</td> <td style="vertical-align: top;">operator forbidden</td> </tr> <tr> <td style="vertical-align: top;"><oper></td> <td colspan="2" style="vertical-align: top;">operator in format as in per <format></td> </tr> <tr> <td style="vertical-align: top;"><mode></td> <td style="vertical-align: top;"><u>0</u></td> <td style="vertical-align: top;">automatic mode; <oper> field is ignored</td> </tr> <tr> <td></td> <td style="vertical-align: top;">1</td> <td style="vertical-align: top;">manual operator selection; <oper> field shall be present <format> can only be = 2)</td> </tr> <tr> <td></td> <td style="vertical-align: top;">2</td> <td style="vertical-align: top;">manual deregister from network and remain unregistered until mode 0,1,4 is selected</td> </tr> <tr> <td></td> <td style="vertical-align: top;">3</td> <td style="vertical-align: top;">set only <format> (for read command +COPS?)</td> </tr> <tr> <td></td> <td style="vertical-align: top;">4</td> <td style="vertical-align: top;">automatic, manual selected; if manual selection fails, automatic mode (<mode>=0) is entered (<oper> field shall be present)</td> </tr> <tr> <td style="vertical-align: top;"><format></td> <td style="vertical-align: top;"><u>0</u></td> <td style="vertical-align: top;">long format alphanumeric <oper>; can be up to 16 character long</td> </tr> <tr> <td></td> <td style="vertical-align: top;">2</td> <td style="vertical-align: top;">numeric <oper>; GSM Location Area Identification number</td> </tr> </table>	<stat>	0	unknown		1	operator available		2	operator current		3	operator forbidden	<oper>	operator in format as in per <format>		<mode>	<u>0</u>	automatic mode; <oper> field is ignored		1	manual operator selection; <oper> field shall be present <format> can only be = 2)		2	manual deregister from network and remain unregistered until mode 0,1,4 is selected		3	set only <format> (for read command +COPS?)		4	automatic, manual selected; if manual selection fails, automatic mode (<mode>=0) is entered (<oper> field shall be present)	<format>	<u>0</u>	long format alphanumeric <oper>; can be up to 16 character long		2	numeric <oper>; GSM Location Area Identification number
<stat>	0	unknown																																			
	1	operator available																																			
	2	operator current																																			
	3	operator forbidden																																			
<oper>	operator in format as in per <format>																																				
<mode>	<u>0</u>	automatic mode; <oper> field is ignored																																			
	1	manual operator selection; <oper> field shall be present <format> can only be = 2)																																			
	2	manual deregister from network and remain unregistered until mode 0,1,4 is selected																																			
	3	set only <format> (for read command +COPS?)																																			
	4	automatic, manual selected; if manual selection fails, automatic mode (<mode>=0) is entered (<oper> field shall be present)																																			
<format>	<u>0</u>	long format alphanumeric <oper>; can be up to 16 character long																																			
	2	numeric <oper>; GSM Location Area Identification number																																			
<p>Reference GSM 07.07</p>	<p>Note</p>																																				

4.27 AT+CPAS Mobile equipment activity status

<p>Test command AT+CPAS=?</p>	<p>Response +CPAS: (list of supported <pas>s) OK Parameter See execute command</p>									
<p>Execute command AT+CPAS</p>	<p>Response TA returns the activity status of ME. +CPAS: <pas> OK If error is related to ME functionality: +CME ERROR: <err> Parameter <table border="0" data-bbox="403 712 1404 824"> <tr> <td style="padding-right: 20px;"><pas></td> <td style="padding-right: 20px;">0</td> <td>ready</td> </tr> <tr> <td></td> <td>3</td> <td>incoming call (ringing)</td> </tr> <tr> <td></td> <td>4</td> <td>call in progress or call hold</td> </tr> </table> </p>	<pas>	0	ready		3	incoming call (ringing)		4	call in progress or call hold
<pas>	0	ready								
	3	incoming call (ringing)								
	4	call in progress or call hold								
<p>Reference GSM 07.07</p>	<p>Note</p>									

4.28 AT+CPBR Read current phonebook entries

<p>Test command AT+CPBR=?</p>	<p>Response</p> <p>TA returns location range supported by the current storage as a compound value and the maximum length of <number> and <text> fields.</p> <p>Note: In case of SIM storage, the length may not be available. If storage does not offer format information, the format list should be empty parentheses.</p> <p>+CPBR: (list of supported <index>s), <nlength>, <tlength> OK</p> <p>If error is related to ME functionality: +CME ERROR: <err></p> <p>Parameter</p> <p><index> location number</p> <p><nlength> max. length of phone number, normally 20, for a small number of locations 40</p> <p><tlength> max. length of text for number</p>
<p>Execute command AT+CPBR = <index1> [, <index2>]</p>	<p>Response</p> <p>TA returns phonebook entries in location number range <index1> ... <index2> from the current phonebook memory storage selected with +CPBS. If <index2> is left out, only location <index1> is returned.</p> <p>+CPBR: <index1>, <number>, <type>, <text> [<CR> <LF> +CPBR:+CPBR: <index2>, <number>, <type>, <text>] OK</p> <p>If error is related to ME functionality: +CME ERROR</p> <p>Parameter</p> <p><index1> read from this location number</p> <p><index2> read to this location number</p> <p><number> phone number</p> <p><type> type of address octet in integer format; 145 when dialling string includes international access code character "+", otherwise 129.</p> <p><text> string type field of maximum length <tlength>; character set as specified by command Select TE Character Set +CSCS</p>
<p>Reference GSM 07.07</p>	<p>Note</p>

4.29 AT+CPBS Select phonebook memory storage

<p>Test command AT+CPBS=?</p>	<p>Response +CPBS: (list of supported <storage>s) OK If error is related to ME functionality: +CME ERROR: <err> Parameter See write command</p>
<p>Read command AT+CPBS?</p>	<p>Response TA returns currently selected memory +CPBS: <storage>,<used>,<total> OK If error is related to ME functionality: +CME ERROR: <err> Parameter See write command</p>
<p>Write command AT+CPBS= <storage></p>	<p>Response TA selects current phonebook memory storage, which is used by other phonebook commands. OK If error is related to ME functionality: +CME ERROR: <err></p>
	<p>Parameter <storage> "SM" SIM phonebook (SM Phonebook storage depends on the SIM-Card "FD" SIM fixdialling-phonebook (FD Phonebook storage pos.1-7) "LD" SIM last-dialling-phonebook (+CPBW not be applicable for this storage) (LD Phonebook storage pos.1-10) "MC" ME missed (unanswered received) calls list (+CPBW not applicable for this storage) (MC Phonebook storage pos.1-10) "RC" ME received calls list (+CPBW not applicable for this storage) (RC Phonebook storage pos.1-10) "ON" SIM (or ME) own numbers (MSISDNs) list "ME" ME Phonebook ME Phonebook storage pos.1-50</p> <p><used> Integer type value indicating the number of used locations in selected memory</p> <p><total> Integer type value indicating the total number of used locations in selected memory</p>
<p>Reference GSM 07.07</p>	<p>Note This command can be used right after power-on to get selected <storage>. Since data needs to be loaded from the SIM, values of <used> and <total> might not be available during the first 20 seconds.</p>

4.30 AT+CPBW Write phonebook entry

<p>Test command AT+CPBW=?</p>	<p>Response</p> <p>TA returns location range supported by the current storage, the maximum length of <number> field, supported number formats of the storage, and the maximum length of <text> field.</p> <p>Note: The length may not be available in case of SIM storage. If storage does not offer format information, the format list should be empty parentheses.</p> <p>+CPBW: (list of supported <index>s), <nlength>, (list of supported <typ>s), <tlength> OK</p> <p>If error is related to ME functionality: +CME ERROR: <err></p> <p>Parameter See write command.</p>
<p>Write command AT+CPBW= [<index>] [,<number> [,<typ>] [,<text>]]</p>	<p>Write the phonebook entry selected by <index> in the current phonebook (selected by +CPBS). Entry fields written are the phone number <number> (in the format <type>) and the <text> associated with the number. If both fields are omitted, the phonebook entry is deleted. If <index> is left out, but <number> is given, the entry is written to the first free location in the phonebook (the implementation of this feature is manufacturer specific). If writing fails, an ME error, +CME ERROR: <err> is returned.</p> <p>Parameter</p> <p><nlength> Max. length of telephone number, normally 20, for a small number of locations 40</p> <p><tlength> Max. length of text corresponding to the telephone number</p> <p><index> Location number within phonebook memory, range is given in test command response</p> <p><number> Phone number, range is given in test command response <nlength></p> <p><typ> Type of number (refer GSM 04.08 subclause 10.5.4.7)</p> <p><text> Text corresponding to the telephone number, range is given in test command response <tlength>, character set as specified by +CSCS. See note below.</p> <p>Response OK/ERROR/+CME ERROR</p>
<p>Reference GSM 07.07</p>	<p>Note</p> <p>If <text> contains characters which are coded differently in ASCII and GSM (e.g. Ä, Ö, Ü), these characters have to be entered via escape sequences as described in chapter „Supported character sets“, pg. 10.</p>

4.31 AT+CPIN Enter PIN

Test command AT+CPIN=?	Response OK																					
Read command AT+CPIN?	Response TA returns an alphanumeric string indicating whether some password is required or not. +CPIN: <code> OK If error is related to ME functionality: +CME ERROR: <err> Parameter <table border="0" style="width: 100%;"> <tr> <td style="width: 15%;"><code></td> <td style="width: 35%;">READY</td> <td style="width: 50%;">no further entry needed</td> </tr> <tr> <td></td> <td>SIM PIN</td> <td>ME is waiting for SIM PIN</td> </tr> <tr> <td></td> <td>SIM PUK</td> <td>ME is waiting for SIM PUK</td> </tr> <tr> <td></td> <td>PH_SIM PIN</td> <td>ME is waiting for phone to SIM card (antitheft)</td> </tr> <tr> <td></td> <td>PH_SIM PUK</td> <td>ME is waiting for SIM PUK (antitheft)</td> </tr> <tr> <td></td> <td>SIM PIN2</td> <td>PIN2, e.g. for editing the FDN book possible only if preceding command was acknowledged with +CME ERROR:17</td> </tr> <tr> <td></td> <td>SIM PUK2</td> <td>possible only if preceding command was acknowledged with error +CME ERROR:18.</td> </tr> </table>	<code>	READY	no further entry needed		SIM PIN	ME is waiting for SIM PIN		SIM PUK	ME is waiting for SIM PUK		PH_SIM PIN	ME is waiting for phone to SIM card (antitheft)		PH_SIM PUK	ME is waiting for SIM PUK (antitheft)		SIM PIN2	PIN2, e.g. for editing the FDN book possible only if preceding command was acknowledged with +CME ERROR:17		SIM PUK2	possible only if preceding command was acknowledged with error +CME ERROR:18 .
<code>	READY	no further entry needed																				
	SIM PIN	ME is waiting for SIM PIN																				
	SIM PUK	ME is waiting for SIM PUK																				
	PH_SIM PIN	ME is waiting for phone to SIM card (antitheft)																				
	PH_SIM PUK	ME is waiting for SIM PUK (antitheft)																				
	SIM PIN2	PIN2, e.g. for editing the FDN book possible only if preceding command was acknowledged with +CME ERROR:17																				
	SIM PUK2	possible only if preceding command was acknowledged with error +CME ERROR:18 .																				
Write command AT+CPIN=<pin> > [, <new pin>]	Response TA stores a password, which is necessary before it can be operated on (SIM PIN, SIM PUK, PH-SIM PIN, etc.). If the PIN is to be entered twice, the TA shall automatically repeat the PIN. If no PIN request is pending, no action is taken and an error message, +CME ERROR , is returned to TE. If the PIN required is SIM PUK or SIM PUK2, the second pin is required. This second pin, <newpin> , is used to replace the old pin in the SIM. OK If error is related to ME functionality: +CME ERROR: <err> Parameter <table border="0" style="width: 100%;"> <tr> <td style="width: 15%;"><pin></td> <td style="width: 85%;">password (string type) E.g.: AT+CPIN=9515<CR></td> </tr> <tr> <td><new pin></td> <td>if the PIN required is SIM PUK or SIM PUK2: new password</td> </tr> </table>	<pin>	password (string type) E.g.: AT+CPIN=9515<CR>	<new pin>	if the PIN required is SIM PUK or SIM PUK2: new password																	
<pin>	password (string type) E.g.: AT+CPIN=9515<CR>																					
<new pin>	if the PIN required is SIM PUK or SIM PUK2: new password																					
Reference GSM 07.07	Note <ol style="list-style-type: none"> 1. Attention: After entering a password via AT+CPIN all other commands that need access to the data on the SIM card may be blocked for up to 20 seconds! 2. Wait 10 seconds after PIN input before using SMS related commands. 3. <pin> and <new pin> can also be entered in double quotes (e.g. "1234"). 4. See additional Chapter 7.8 „List of PIN-requiring AT Commands“. 																					

4.32 AT+CPIN2 Enter PIN2

<p>Test command AT+CPIN2=?</p>	<p>Response OK</p>									
<p>Read command AT+CPIN2?</p>	<p>Response TA returns an alphanumeric string indicating whether some password is required or not. +CPIN2: <code> OK If error is related to ME functionality: +CME ERROR: <err> Parameter <table border="0" style="width: 100%;"> <tr> <td style="width: 15%;"><code></td> <td style="width: 35%;">READY</td> <td>ME is not pending for any password</td> </tr> <tr> <td></td> <td>SIM PIN2</td> <td>ME is waiting SIM PIN2 to be given (this <code> is recommended to be returned only when the last executed command resulted in PIN2 authentication failure (i.e. +CME ERROR:17)).</td> </tr> <tr> <td></td> <td>SIM PUK2</td> <td>ME is waiting SIM PUK2 to be given (this <code> is recommended to be returned only when the last executed command resulted in PUK2 authentication failure (i.e. +CME ERROR:18)).</td> </tr> </table> </p>	<code>	READY	ME is not pending for any password		SIM PIN2	ME is waiting SIM PIN2 to be given (this <code> is recommended to be returned only when the last executed command resulted in PIN2 authentication failure (i.e. +CME ERROR:17)).		SIM PUK2	ME is waiting SIM PUK2 to be given (this <code> is recommended to be returned only when the last executed command resulted in PUK2 authentication failure (i.e. +CME ERROR:18)).
<code>	READY	ME is not pending for any password								
	SIM PIN2	ME is waiting SIM PIN2 to be given (this <code> is recommended to be returned only when the last executed command resulted in PIN2 authentication failure (i.e. +CME ERROR:17)).								
	SIM PUK2	ME is waiting SIM PUK2 to be given (this <code> is recommended to be returned only when the last executed command resulted in PUK2 authentication failure (i.e. +CME ERROR:18)).								
<p>Write command AT+CPIN2=<pin> > [, <new pin>]</p>	<p>Response TA stores a password, which is necessary before it can be operated (SIM PIN2, SIM PUK2, etc.). If the PIN is to be entered twice, the TA shall automatically repeat the PIN. If no PIN request is pending, no action is taken and an error message, +CME ERROR, is returned to TE. If the PIN required is SIM PUK2, the second pin is required. This second pin, <newpin>, is used to replace the old pin2 in the SIM. OK If error is related to ME functionality: +CME ERROR: <err> Parameter <table border="0" style="width: 100%;"> <tr> <td style="width: 15%;"><pin></td> <td>password (string type) should be entered in double quotes. E.g.: AT+CPIN2="9515"</td> </tr> <tr> <td><new pin></td> <td>if the PIN required is SIM PUK2: new password</td> </tr> </table> </p>	<pin>	password (string type) should be entered in double quotes. E.g.: AT+CPIN2="9515"	<new pin>	if the PIN required is SIM PUK2: new password					
<pin>	password (string type) should be entered in double quotes. E.g.: AT+CPIN2="9515"									
<new pin>	if the PIN required is SIM PUK2: new password									
<p>Reference</p>	<p>Note Commands dependent on PIN2: "AT+CACM Accumulated call meter (ACM) reset or query" "AT+CAMM Accumulated call meter maximum (ACMmax) set or query" "AT+CLCK Facility lock" "AT+CPIN Enter PIN" "AT+CPWD Change password" "AT^SLCK Facility lock (including self-defined locks)" "AT+CPUC Price per unit and currency table" AT+CPWD is the only command, which PIN2 cannot be entered directly with the AT+CPIN command, the PIN2 can only be set if expected (+CPIN: SIM PIN2). To manipulate the "FD" Phonebook, PIN2 has to be entered before. If PIN2 is now set with AT+CPIN2="PIN2", it is possible writing to the FD Phonebook. Using the command AT+CLCK="FD",x PIN2 is again set to not set. Therefore writing to the FD Phonebook is no longer possible.</p>									

4.33 AT+CPUC Price per unit and currency table

Test command AT+CPUC=?	Response OK
Read command AT+CPUC?	Response Read command returns the current parameters of PUC. +CPUC: <currency>, <ppu> OK If error is related to ME functionality: +CME ERROR: <err> Parameter See write command
Write command AT+CPUC=<currency>,<ppu>[,<passwd>]	Response Write command sets the parameters of Advice of Charge related price per unit and currency table. SIM PIN2 is usually required to set the parameters. If error is related to ME functionality: +CME ERROR: <err> Parameter <currency> string type; three-character currency code (e.g. "GBP", "DEM"); character set as specified by command AT+CSCS Select TE character set.. If the currency name is longer than three characters, all characters will be cut off after the third position. Before they are written to the SIM Card, these characters are converted to the standard GSM alphabet. <ppu> string type; price per unit; dot is used as a decimal separator (e.g. "2.66"). Ist length is limited to 20 characters. If the string length is exceeded, the command is terminated with an error. This string may only contain digits and a dot. Leading zeros are removed from the string. The minimum and maximum value are determined by the structure of the SIM-PUCT file. The maximum price per unit value is 999 999 999.00. When successfully entered, this value is rounded to maximum accuracy. Note: Due to storage in mantisse (range 0-4095) and exponent (-7 to 7) it is possible that rounding errors occur. <passwd> string type; SIM PIN2. String parameter which can contain any combination of characters. The maximum string length is limited to 8 characters. If this value is exceeded, the command terminates with an error message. If the PIN2 is incorrect, a CME error (+CME ERROR: incorrect password) is output.
Reference GSM 07.07	Note

4.34 AT+CPWD Change password

<p>Test command AT+CPWD=?</p>	<p>Response TA returns a list of pairs which represent the available facilities and the maximum length of their password. +CPWD: (list of supported (<fac>, <pwdlength>)s) OK If error is related to ME functionality: +CME ERROR: <err> Parameter <fac> see execute command <pwdlength> integer max. length of password</p>
<p>Execute command AT+CPWD = <fac>, [<oldp- wd>], <newp- wd></p>	<p>Response TA sets a new password for the facility lock function. OK If error is related to ME functionality: +CME ERROR: <err> Parameter <fac> "SC" SIM (lock SIM card) (SIM asks password in ME power-up and when this lock command issued) "AO" BAOC (Bar All Outgoing Calls) "OI" BOIC (Bar Outgoing International Calls) "OX" BOIC-exHC (Bar Outgoing International Calls except to Home Country) "AI" BAIC (Bar All Incoming Calls) "IR" BIC-Roam (Bar Incoming Calls when Roaming outside the home country) "AB" All Barring services (applicable only for <mode> = 0) "AG" All outGoing barring services (applicable only for <mode> = 0) "AC" All inComing barring services (applicable only for <mode> = 0) "P2" SIM PIN2 "PS" Phone locked to SIM (device code) "PF" lock Phone to the very first SIM card "PN" Network Personalisation "PU" Network-subset Personalisation "PP" Service-Provider Personalisation "PC" Corporate Personalisation <oldpwd> password specified for the facility. If an old password has not yet been set, <oldpwd> has not to be entered. Note: A password may already have been set, depending on the provider. Please check with your provider. <newpwd> new password</p>
<p>Reference GSM 07.07</p>	<p>Note If you want to delete a formerly given password only, use the following syntax: at+cpwd=<fac>,<oldpwd></p>

4.35 AT+CR Service reporting control

<p>Test command AT+CR=?</p>	<p>Response +CR: (list of supported <mode>s) OK</p> <p>Parameter See write command</p>						
<p>Read command AT+CR?</p>	<p>Response +CR: <mode> OK</p> <p>Parameter See write command</p>						
<p>Write command AT+CR=<mode> ></p>	<p>Response TA controls whether or not intermediate result code +CR: <serv> is returned from the TA to the TE at call setup.</p> <p>OK</p> <p>Parameter</p> <table border="0"> <tr> <td><mode></td> <td><u>0</u></td> <td>disable</td> </tr> <tr> <td></td> <td>1</td> <td>enable</td> </tr> </table>	<mode>	<u>0</u>	disable		1	enable
<mode>	<u>0</u>	disable					
	1	enable					
	<p>Intermediate result code</p> <p>When enabled, an intermediate result code is transmitted at the point during connect negotiation when the TA has determined the speed and quality of service to be used, before any error control or data compression reports are transmitted, and before any final result code (e.g. CONNECT) is transmitted.</p> <p>+CR:<serv></p> <p>Parameter</p> <table border="0"> <tr> <td><serv></td> <td>REL ASYNC</td> <td>asynchronous non-transparent</td> </tr> </table>	<serv>	REL ASYNC	asynchronous non-transparent			
<serv>	REL ASYNC	asynchronous non-transparent					
<p>Reference GSM 07.07</p>	<p>Note</p> <p>The PLMN influences the second air interface (to the terminator), therefore another mode may be established from the network</p>						

4.36 AT+CRIC Set Cellular Result Codes for incoming call indication

<p>Test command AT+CRIC=?</p>	<p>Response +CRIC: (list of supported <mode>s) OK Parameter See write command</p>
<p>Read command AT+CRIC?</p>	<p>Response +CRIC: <mode> OK Parameter See write command</p>
<p>Write command AT+CRIC=[<mode>]</p>	<p>Response TA controls whether or not the extended format of incoming call indication is used. OK ParameterS <mode> <u>0</u> disable extended format 1 enable extended format</p>
	<p>Unsolicited result code When enabled, an incoming call is indicated to the TE with unsolicited result code +CRING: <type> instead of the normal RING. Parameter <type> REL ASYNC asynchronous non-transparent FAX facsimile VOICE voice</p>
<p>Reference GSM 07.07</p>	<p>Note</p>

4.37 AT+CREG Network registration	
Test command AT+CREG=?	<p>Response</p> <p>+CREG: (list of supported <n>s) OK</p> <p>Parameter</p> <p>See write command</p>
Read command AT+CREG?	<p>Response</p> <p>TA returns the status of result code presentation and an integer <stat> which shows whether the network has currently indicated the registration of the ME. Location information elements <lac> and <ci> are returned only when <n>=2 and ME is registered in the network.</p> <p>+CREG: <n>,<stat>[,<lac>,<ci>] OK</p> <p>If error is related to ME functionality:</p> <p>+CME ERROR: <err></p> <p>Parameter</p> <p>See write command</p>
Write command AT+CREG=[<n>]	<p>Response</p> <p>OK</p> <p>TA controls the presentation of an unsolicited result code +CREG: <stat> when <n>=1 and there is a change in the ME network registration status, or code +CREG: <stat>[,<lac>,<ci>] when <n>=2 and there is a change of the network cell.</p> <p>Parameter</p> <p><n> 0 disable network registration unsolicited result code</p> <p> 1 enable network registration unsolicited result code +CREG: <stat></p> <p> 2 Enable network registration and location information unsolicited result code +CREG:<stat>[,<lac>,<ci>]</p> <p>Note: Optional parameters will not be displayed during call</p> <p><stat> 0 not registered, ME is not currently searching for a new operator at which to register</p> <p> 1 registered, home network</p> <p> 2 not registered, but ME is currently searching for a new operator at which to register</p> <p> 3 registration denied</p> <p> 4 unknown</p> <p> 5 registered, roaming</p> <p><lac> string type; two byte location area code in hexadecimal format (e.g. "00C3" equals 193 in decimal)</p> <p><ci> string type; two byte cell ID in hexadecimal format</p>
	<p>Unsolicited result code</p> <p>When <n>=1 and there is a change in the ME network registration status: +CREG: <stat></p> <p>When <n>=2 and there is a change in the ME network registration status or a change of the network cell: +CREG: <stat>[,<lac>,<ci>]</p>
Reference GSM 07.07	<p>Note</p> <p>Optional parameters will not be displayed during call</p>

4.38 AT+CRLP Select radio link protocol param. for orig. non-transparent data call

<p>Test command AT+CRLP=?</p>	<p>Response TA returns values supported by the TA as a compound value. +CRLP: (list of supported <iws>s), (list of supported <mws>s), (list of supported <T1>s), (list of supported <N2>s) OK Parameter See write command</p>															
<p>Read command AT+CRLP?</p>	<p>Response TA returns current settings for the supported RLP version 0. +CRLP: <iws>,<mws>,<T1>,<N2>[,<verx>] OK Parameter See write command</p>															
<p>Write command AT+CRLP= [<iws> [,<mws> [,<T1> [,<N2 >]]]</p>	<p>Response TA sets radio link protocol (RLP) parameters used when non-transparent data calls are originated. OK Parameter <table border="0" style="width: 100%;"> <tr> <td style="width: 15%;"><iws></td> <td style="width: 15%;">0-<u>6</u>1</td> <td style="width: 70%;">Interworking window size (IWF to MS)</td> </tr> <tr> <td><mws></td> <td>0-<u>6</u>1</td> <td>Mobile window size (MS to IWF)</td> </tr> <tr> <td><T1></td> <td>48-<u>7</u>8-255</td> <td>Acknowledgement timer (T1 in 10 ms units)</td> </tr> <tr> <td><N2></td> <td>1-<u>6</u>-255</td> <td>Re-transmission attempts N2</td> </tr> <tr> <td><verx></td> <td>0</td> <td>RLP version number in integer format; when version indication is not present it shall equal 0.</td> </tr> </table> </p>	<iws>	0- <u>6</u> 1	Interworking window size (IWF to MS)	<mws>	0- <u>6</u> 1	Mobile window size (MS to IWF)	<T1>	48- <u>7</u> 8-255	Acknowledgement timer (T1 in 10 ms units)	<N2>	1- <u>6</u> -255	Re-transmission attempts N2	<verx>	0	RLP version number in integer format; when version indication is not present it shall equal 0.
<iws>	0- <u>6</u> 1	Interworking window size (IWF to MS)														
<mws>	0- <u>6</u> 1	Mobile window size (MS to IWF)														
<T1>	48- <u>7</u> 8-255	Acknowledgement timer (T1 in 10 ms units)														
<N2>	1- <u>6</u> -255	Re-transmission attempts N2														
<verx>	0	RLP version number in integer format; when version indication is not present it shall equal 0.														
<p>Reference GSM 07.07</p>	<p>Note - RLP version 0: single-link basic version; - RLP version 1: single-link extended version (e.g. extended by data compression); - RLP version 2: multi-link version. Compression and multi-link are not supported by TC35.</p>															

4.39 AT+CRSM Restricted SIM access

<p>Test command AT+CRSM=?</p>	<p>Response OK</p>																		
<p>Write command AT+CRSM=<command>[,<fileid> > [,<P1>,<P2>,<P3> [,<data>]]</p>	<p>Response By using this command instead of generic SIM Access TE application has easier but more limited access to the SIM database. As response to the command, ME sends the actual SIM information parameters and response data. +CRSM: <sw1>, <sw2> [,<response>] OK If error is related to ME functionality: +CME ERROR: <err></p> <p>Parameter</p> <table border="0"> <tr> <td><command></td> <td>176</td> <td>READ BINARY</td> </tr> <tr> <td></td> <td>178</td> <td>READ RECORD</td> </tr> <tr> <td></td> <td>192</td> <td>GET RESPONSE</td> </tr> <tr> <td></td> <td>214</td> <td>UPDATE BINARY</td> </tr> <tr> <td></td> <td>220</td> <td>UPDATE RECORD</td> </tr> <tr> <td></td> <td>242</td> <td>STATUS</td> </tr> </table> <p>all other values are reserved</p> <p><fileid> integer type; this is the identifier for an elementary data file on SIM. Mandatory for every command except STATUS</p> <p><P1>,<P2>,<P3> integer type; parameters passed on by the ME to the SIM</p> <p><data> information which shall be written to the SIM (hexadecimal character format)</p> <p><sw1>, <sw2> integer type; information from the SIM about the execution of the actual command. These parameters are delivered to the TE in both cases, on successful or failed execution of the command</p> <p><response> response of a successful completion of the command previously issued (hexadecimal character format)</p>	<command>	176	READ BINARY		178	READ RECORD		192	GET RESPONSE		214	UPDATE BINARY		220	UPDATE RECORD		242	STATUS
<command>	176	READ BINARY																	
	178	READ RECORD																	
	192	GET RESPONSE																	
	214	UPDATE BINARY																	
	220	UPDATE RECORD																	
	242	STATUS																	
<p>Reference GSM 07.07</p>	<p>Note Parameters <command>, <fileid>, <P1>, <P2>, <P3> can also be entered in hexadecimal format. Hexadecimal characters have to start with 0x.</p>																		

4.40 AT+CSCS Set TE character set

Test command AT+CSCS=?	Response +CSCS: (list of supported <chset>s) OK
Read command AT+CSCS?	Response +CSCS: <chset> OK
Write command AT+CSCS=[<chset >]	Response Write command informs TA which character set <chset> is used by the TE. TA is then able to convert character strings correctly between TE and ME character sets. OK
	Parameters <chset>: "GSM" GSM default alphabet (GSM 03.38 subclause 6.2.1); Note: This setting may cause software flow control problems due to values of XON/XOFF characters. "UCS2 " 16-bit universal multiple-octet coded character set (ISO/IEC10646 [32]); UCS2 character strings are converted to hexadecimal numbers from 0000 to FFFF; e.g. "004100620063" equals three 16-bit characters with decimal values 65, 98 and 99, \$(AT R97)\$
Reference GSM 07.07	Note 1) Also see chapter „Supported character sets“, pg. 10. 2) When TA-TE interface is set to 8-bit operation and used TE alphabet is 7-bit, the highest bit will be set to zero.

4.41 AT+CSQ Signal quality

<p>Test command AT+CSQ=?</p>	<p>Response +CSQ: (list of supported <rss>s), (list of supported <ber>) OK</p> <p>Parameter See execute command</p>																
<p>Execute command AT+CSQ</p>	<p>Response TA returns received signal strength indication <rss> and channel bit error rate <ber> from the ME. +CSQ: <rss>, <ber> OK</p> <p>Parameter</p> <table border="0"> <tr> <td><rss></td> <td>Receive level:</td> </tr> <tr> <td>0</td> <td>-113 dBm or less</td> </tr> <tr> <td>1</td> <td>-111 dBm</td> </tr> <tr> <td>2...30</td> <td>-109... -53 dBm</td> </tr> <tr> <td>31</td> <td>-51 dBm or greater</td> </tr> <tr> <td>99</td> <td>not known</td> </tr> </table> <p><ber> Bit error rate:</p> <table border="0"> <tr> <td>0...7</td> <td>as RXQUAL values in the table in GSM 05.08 section 8.2.4</td> </tr> <tr> <td>99</td> <td>not known</td> </tr> </table>	<rss>	Receive level:	0	-113 dBm or less	1	-111 dBm	2...30	-109... -53 dBm	31	-51 dBm or greater	99	not known	0...7	as RXQUAL values in the table in GSM 05.08 section 8.2.4	99	not known
<rss>	Receive level:																
0	-113 dBm or less																
1	-111 dBm																
2...30	-109... -53 dBm																
31	-51 dBm or greater																
99	not known																
0...7	as RXQUAL values in the table in GSM 05.08 section 8.2.4																
99	not known																
<p>Reference GSM 07.07</p>	<p>Note</p>																

4.42 AT+CSSN Supplementary service notifications	
Test command AT+CSSN=?	Response +CSSN: (list of supported <n>s), (list of supported <m>s)OK Parameter <n> 0 Suppresses the +CSSI messages 1 Activates the +CSSI messages <m> 0 Suppresses the +CSSU messages 1 Activates the +CSSU messages
Read command AT+CSSN?	Response +CSSN: <n>,<m>OK Parameter <n> See Test command <m> See Test command
Write command AT+CSSN=<n>[,<m>]	Response OK Parameter <n> See read command <m> See read command
	Unexpected message +CSSI: <code1> +CSSU: <code2> Parameter <code1> Intermediate result code 3 Waiting call is pending <code2> Unsolicited result code 5 Held call was terminated
Reference GSM 07.07	Note

4.43 AT+CUSD Unstructured supplementary service data

<p>Test command AT+CUSD=?</p>	<p>Response +CUSD: (list of supported <n>s) OK Parameter See write command</p>
<p>Read command AT+ CUSD?</p>	<p>Response TA returns the current <n> value. +CUSD: <n> OK If error is related to ME functionality: +CME ERROR: <err></p>
<p>Write command AT+ CUSD= <n>[,<str>[,<dcs>]]</p>	<p>This command allows control of the Unstructured Supplementary Service Data (USSD) according to GSM 02.90. Both network and mobile initiated operations are supported. Parameter <n> is used to disable/enable the presentation of an unsolicited result code (USSD response from the network, or network initiated operation) +CUSD:<m>[,<str>,<dcs>] to the TE.</p> <p>When <str> is given, a mobile initiated USSD-string or a response USSD-string to a network initiated operation is sent to the network. The response USSD-string from the network is returned in a subsequent unsolicited +CUSD result code.</p> <p>The interaction of this command with other commands based on other GSM supplementary services is described in the GSM standard.</p> <p>Parameter</p> <p><n> 0: disable the result code presentation in the TA 1: enable the result code presentation in the TA 2: cancel session (not applicable to read command response)</p> <p><str>: string type USSD-string (when <str> parameter is not given, network is not interrogated). If <dcs> indicates that GSM 03.38 default alphabet is used ME/TA converts GSM alphabet into current TE character set according to rules of GSM 07.05 Annex A.</p> <p><dcs>: GSM 03.38 Cell Broadcast Data Coding Scheme in integer format (default 15)</p> <p><m> 0: no further user action required (network initiated USSD-Notify, or no further information needed after mobile initiated operation) 1: further user action required (network initiated USSD-Request, or further information needed after mobile initiated operation) 2: USSD terminated by network</p> <p>Response OK If error is related to ME functionality: +CME ERROR: <err></p>
<p>Reference GSM 07.07</p>	<p>Note For the write command <dcs>=15 is supported only. On an unsolicited result code with parameter <m>=1 a '>' is given for further user action. The user action is finished with a <ctrl-Z> or aborted with <ESC>.</p>

4.44 AT+VTD=<n> Tone duration	
Test command AT+VTD=?	This command refers to an integer <duration> that defines the length of tones emitted as a result of the +VTS command. Response (list of supported <duration>s) OK Parameter See write command
Read command AT+VTD?	Response <duration> OK Parameter See write command
Write command AT+VTD = <duration>	Response OK Parameter <duration> <u>1</u> - 255 duration of the tone in 1/10 second
Reference GSM 07.07	Note

4.45 AT+VTS DTMF and tone generation (<Tone> in {0-9, *, #, A, B, C, D})	
Test command AT+VTS=?	Response +VTS: (list of supported <dtmf>s)[, (list of supported <duration>s)] OK Parameter See write command
Write command 1) AT+VTS=<dtmf - string> 2) AT+VTS=<dtmf>,<duration>	Response This command allows the transmission of DTMF tones and arbitrary tones in voice mode. These tones may be used (for example) when announcing the start of a recording period. 1) This is interpreted as a sequence of DTMF tones whose duration is set by the +VTD command. 2) This is interpreted as a DTMF tone whose duration is determined by <duration> . OK If error is related to ME functionality: +CME ERROR: <err> Parameter <dtmfstring> String of ASCII characters in the set 0-9,#,*,A, B, C, D. Maximal length of the string is 29. The string has to be entered between double-quote characters (""). <dtmf> ASCII character in the set 0-9,#,*, A, B, C, D. <duration> <u>1</u> -255 duration of a tone in 1/10 second
Reference GSM 07.07	Note This command only works during active voice call

4.46 AT+WS46 Select wireless network

Test command AT+WS46=?	Response (list of supported <n>s) OK
Read command AT+WS46?	Response <n> OK/ERROR/+CME ERROR
	Parameter <n> 12 GSM digital cellular
Write command AT+WS46=[<n>]	Response OK/ERROR/+CME ERROR
Reference GSM 07.07	Note

5 AT commands originating from GSM 07.05 for SMS

These AT Commands are according to ETSI (European Telecommunications Standards Institute) GSM 07.05 document.

5.1 AT+CMGC Send an SMS command	
Test command AT+CMGC=?	Response OK
Write command if text mode (AT+CMGF=1): AT+CMGC=<fo>,<ct>[,<pid>[,<mn>[,<da>[,<to da>]]]]<CR> text is entered <ctrl-Z/ESC>	Response if text mode (+CMGF=1) and sending successful: +CMGC: <mr>[,<scts>] if sending fails: +CMS ERROR: <err>
if PDU mode (AT+CMGF=0): AT+CMGC=<length><pdu><CR> PDU is given <ctrl-Z/ESC> +CMGC=?	Response if PDU mode (+CMGF=0) and sending successful: +CMGC: <mr>[,<ackpdu>] if sending fails: +CMS ERROR: <err> Parameter <length> Length of PDU <pdu> See "AT+CMGL" <mr> Message reference <fo> depending on the command or result code: first octet of GSM 03.40 SMS-DELIVER, SMS-SUBMIT (default 17), SMS-STATUS-REPORT, or SMS-COMMAND (default 2) in integer format <ct> GSM 03.40 TP-Command-Type in integer format (default 0) <pid> GSM 03.40 TP-Protocol-Identifier in integer format (default 0) <toda> GSM 04.11 TP-Destination-Address Type-of-Address octet in integer format (when first character of <da> is + (IRA 43) default is 145, otherwise default is 129) <da> GSM 03.40 TP-Destination-Address Address-Value field in string format; BCD numbers (or GSM default alphabet characters) are converted into characters; type of address given by <toda> <scts> GSM 03.40 TP-Service-Centre-Time-Stamp in time-string format (refer <dt>)
Reference GSM 07.05	Note 1. After invoking of the command CMGW, CMGS, CMGC it is necessary to wait for the ">" symbol and only afterwards the text can be sent to the module 2. With baudrates lower than 19200 it is recommended to use the line termination character only (refer to +ATS3, default <CR>, pg. 21) before entering the text/pdu. Use of the line termination character followed by the response formatting character (refer to +ATS4, default <LF>, pg. 21) can cause problems.

5.2 AT+CMGD Delete SMS message

Test command AT+CMGD=?	Response OK Parameter
Execute command AT+CMGD= <index>	Response TA deletes message from preferred message storage <mem1> location <index>. OK If error is related to ME functionality: +CMS ERROR <err> Parameter <index> integer type; value in the range of location numbers supported by the associated memory
Reference GSM 07.05	Note If there is no SMS stored at the selected index, the response is OK too.

5.3 AT+CMGF Select SMS message format

Test command AT+CMGF=?	Response +CMGF: (list of supported <mode>s) OK Parameter See write command
Read command AT+CMGF?	Response +CMGF: <mode> OK Parameter See write command
Write command AT+CMGF = [<mode>]	Response TA sets parameter which specifies the input and output format of messages to be used. OK Parameter <mode> 0 PDU mode 1 text mode
Reference GSM 07.05	Note

5.4 AT+CMGL List SMS messages from preferred store

<p>Test command AT+CMGL=?</p>	<p>Response +CMGL: (list of supported <stat>s) OK Parameter See execute command</p>
<p>Execute command AT+CMGL [=<stat>]</p>	<p>Parameter 1) If text mode: <stat> "REC UNREAD" Received unread messages (default) "REC READ" Received read messages "STO UNSENT" Stored unsent messages "STO SENT" Stored sent messages "ALL" All messages 2) If PDU mode: <stat> 0 Received unread messages (default) 1 Received read messages 2 Stored unsent messages 3 Stored sent messages 4 All messages Response TA returns messages with status value <stat> from message storage <mem1> to the TE. If status of the message is 'received unread', status in the storage changes to 'received read'. Note: If the selected <mem1> can contain different types of SMs (e.g. SMS-DELIVERs, SMS- SUBMITs, SMS- STATUS-REPORTs and SMS-COMMANDs), the response may be a mix of the responses of different SM types. TE application can recognize the response format by examining the third response parameter.</p>
	<p>Response <u>1) If text mode (+CMGF=1) and command successful:</u> for SMS- SUBMITs and/or SMS-DELIVERs: +CMGL: <index>,<stat>,<oa/da>,<[alpha]>,<[scts]>,<[tooa/toda>,<length><CR><LF><data><CR><LF> +CMGL: <index>,<stat>,<da/oa>,<[alpha]>,<[scts]>,<[tooa/toda>,<length><CR><LF><data>[...]] OK for SMS-STATUS-REPORTs: +CMGL: <index>,<stat>,<fo>,<mr>,<[ra]>,<[tora]>,<scts>,<dt>,<st> [<CR><LF> +CMGL: <index>,<stat>,<fo>,<mr>,<[ra]>,<[tora]>,<scts>,<dt>,<st> [...]] OK for SMS-COMMANDs: +CMGL: <index>,<stat>,<fo>,<ct><CR><LF> +CMGL: <index>,<stat>,<fo>,<ct>[...]] OK for CBM storage: +CMGL: <index>,<stat>,<sn>,<mid>,<page>,<pages><CR><LF><data><CR><LF> +CMGL: <index>,<stat>,<sn>,<mid>,<page>,<pages> <CR><LF><data>[...]]OK</p>

	<p>2) If PDU mode (+CMGF=0) and command successful: +CMGL: <index>,<stat>,[<alpha>],<length><CR><LF><pdu> [<CR><LF>+CMGL: <index>,<stat>,[<alpha>],<length><CR><LF><pdu> [...]] OK for CBM storage: +CMGL: <index>,<length><CR><LF><pdu></p> <p>3) If error is related to ME functionality: +CMS ERROR: <err></p>
	<p>Parameter</p> <p><alpha> string type alphanumeric representation of <da> or <oa> corresponding to the entry found in phonebook; implementation of this feature is manufacturer- specific</p> <p><ct> GSM 03.40 TP-Command-Type in integer format (default 0)</p> <p><da> GSM 03.40 TP-Destination-Address Address-Value field in string format; BCD numbers (or GSM default alphabet characters) are converted into characters; type of address given by < toda ></p> <p><data> In the case of SMS: GSM 03.40 TP-User-Data in text mode responses; format: -if <dcs> indicates that GSM 03.38 default alphabet is used and <fo> indicates that GSM 03.40 TP-User-Data-Header-Indication is not set: ME/TA converts GSM alphabet into current TE character set according to rules of Annex A -if <dcs> indicates that 8-bit or UCS2 data coding scheme is used, or <fo> indicates that GSM 03.40 TP-User-Data-Header-Indication is set: ME/TA converts each 8-bit octet into hexadecimal numbers containing two IRA characters (e.g. octet with integer value 42 is presented to TE as two characters 2A (IRA 50 and 65))</p> <p>In the case of CBS: GSM 03.41 CBM Content of Message in text mode responses; format: - if <dcs> indicates that GSM 03.38 default alphabet is used: ME/TA converts GSM alphabet into current TE character set according to rules of Annex A -if <dcs> indicates that 8-bit or UCS2 data coding scheme is used: ME/TA converts each 8-bit octet into hexadecimal numbers containing two IRA characters</p>
	<p>Parameter</p> <p><dt> GSM 03.40 TP-Discharge-Time in time-string format: "yy/MM/dd,hh:mm:ss±zz", where characters indicate year (two last digits), month, day, hour, minutes, seconds and time zone. For example, 6th of May 1994, 22:10:00 GMT+2 hours equals "94/05/06,22:10:00+08"</p> <p><fo> depending on the command or result code: first octet of GSM 03.40 SMS-DELIVER, SMS-SUBMIT (default 17), SMS- STATUS-REPORT, or SMS -COMMAND (default 2) in integer format</p> <p><length> integer type value indicating in the text mode (+CMGF=1) the length of the message body <data> (or <cdata>) in characters; or in PDU mode (+CMGF=0), the length of the actual TP data unit in octets (i.e. the RP layer SMSC address octets are not counted in the length)</p> <p><index> integer type; value in the range of location numbers supported by the associated memory</p>

	<p><mid> GSM 03.41 CBM Message Identifier in integer format</p> <p><mr> GSM 03.40 TP-Message-Reference in integer format</p> <p><oa> GSM 03.40 TP-Originating-Address Address-Value field in string format; BCD numbers (or GSM default alphabet characters) are converted into characters; type of address given by <tooa></p> <p><pages> GSM 03.41 CBM Page Parameter bits 0-3 in integer format</p> <p><pdu> In the case of SMS: GSM 04.11 SC address followed by GSM 03.40 TPDU in hexadecimal format: ME/TA converts each octet of TP data unit into hexadecimal numbers containing two IRA characters (e.g. octet with integer value 42 is presented to TE as two characters 2A (IRA 50 and 65)). In the case of CBS: GSM 03.41 TPDU in hexadecimal format.</p> <p><page> GSM 03.41 CBM Page Parameter bits 4-7 in integer format</p> <p><ra> GSM 03.40 TP-Recipient-Address Address-Value field in string format; BCD numbers (or GSM default alphabet characters) are converted into characters; type of address given by <tora></p> <p><scts> GSM 03.40 TP- Service-Centre-Time-Stamp in time-string format (refer <dt>)</p> <p><sn> GSM 03.41 CBM Serial Number in integer format</p> <p><st> GSM 03.40 TP-Status in integer format</p> <p><toda> GSM 04.11 TP-Destination-Address Type-of-Address octet in integer format (when first character of <da> is + (IRA 43) default is 145, otherwise default is 129)</p> <p><tooa> GSM 04.11 TP-Originating-Address Type-of-Address octet in integer format (default refer<toda>)</p> <p><tora> GSM 04.11 TP-Recipient-Address Type-of-Address octet in integer format (default refer<toda>)</p>
Reference GSM 07.05	Note

5.5 AT+CMGR Read SMS message

Test command AT+CMGR=?	Response OK Parameter
Execute command AT+CMGR= <index>	<p>Parameter <index> integer type; value in the range of location numbers supported by the associated memory</p> <p>Response TA returns SMS message with location value <index> from message storage <mem1> to the TE. If status of the message is 'received unread', status in the storage changes to 'received read'.</p> <p><u>1) If text mode (+CMGF=1) and command successful:</u></p> <p>for SMS-DELIVER: +CMGR: <stat>,<oa>,[<alpha>],<scts> [,<tooa>,<fo>,<pid>,<dcs>,<sca>,<tosca>,<length>]<CR><LF><data></p> <p>for SMS-SUBMIT: +CMGR: <stat>,<da>,[<alpha>] [,<toda>,<fo>,<pid>,<dcs>,<vp>],<sca>,<tosca>,<length>]<CR><LF><data></p> <p>for SMS-STATUS-REPORT: +CMGR: <stat>,<fo>,<mr>,[<ra>],[<tora>],<scts>,<dt>,<st></p> <p>for SMS- COMMAND: +CMGR: <stat>,<fo>,<ct> [,<pid>],[<mn>],[<da>],[<toda>],<length>]<CR><LF><cdata>]</p> <p>for CBM storage: +CMGR: <stat>,<sn>,<mid>,<dcs>,<page>,<pages><CR><LF><data></p> <p><u>2) If PDU mode (+CMGF=0) and command successful:</u></p> <p>+CMGR: <stat>,[<alpha>],<length><CR><LF><pdu> OK</p> <p>for CBM storage: +CMGR: <length><CR><LF><pdu></p> <p><u>3) If error is related to ME functionality:</u> +CMS ERROR: <err></p> <p>Parameter <alpha> string type alphanumeric representation of <da> or <oa> corresponding to the entry found in phonebook; implementation of this feature is manufacturer-specific <stat> integer type in PDU mode (default 0), or string type in text mode (default "REC UNREAD"); indicates the status of message in memory: defined values:</p>

- 0 "REC UNREAD" received unread message (i.e. new message)
- 1 "REC READ" received read message
- 2 "STO UNSENT" stored unsent message (only applicable to SMS)
- 3 "STO SENT" stored sent message (only applicable to SMS)

<ct> GSM 03.40 TP-Command-Type in integer format (default 0)

<da> GSM 03.40 TP- Destination-Address Address-Value field in string format; BCD numbers (or GSM default alphabet characters) are converted into characters; type of address given by <tda>

<data>

In the case of SMS: GSM 03.40 TP-User-Data in text mode responses; format:

-if <dc> indicates that GSM 03.38 default alphabet is used and <fo> indicates that GSM 03.40 TP-User-Data-Header-Indication is not set: ME/TA converts GSM alphabet into current TE character set according to rules covered in Annex A

-if <dc> indicates that 8-bit or UCS2 data coding scheme is used, or <fo> indicates that GSM 03.40 TP-User-Data-Header-Indication is set: ME/TA converts each 8-bit octet into hexadecimal numbers containing two IRA characters (e.g. octet with integer value 42 is presented to TE as two characters 2A (IRA 50 and 65))

In the case of CBS: GSM 03.41 CBM Content of Message in text mode responses; format:

- if <dc> indicates that GSM 03.38 default alphabet is used: ME/TA converts GSM alphabet into current TE character set according to rules covered in Annex A

-if <dc> indicates that 8-bit or UCS2 data coding scheme is used: ME/TA converts each 8-bit octet into hexadecimal numbers containing two IRA characters

<dc> depending on the command or result code: GSM 03.38 SMS Data Coding Scheme (default 0), or Cell Broadcast Data Coding Scheme in integer format

<cdata> GSM 03.40 TP-Command-Data in text mode responses; ME/TA converts each 8-bit octet into two IRA character long hexadecimal numbers (e.g. octet with integer value 42 is presented to TE as two characters 2A (IRA 50 and 65))

<dt> GSM 03.40 TP-Discharge-Time in time-string format: "yy/MM/dd,hh:mm:ss±zz", where characters indicate year (two last digits), month, day, hour, minutes, seconds and time zone. For example, 6th of May 1994, 22:10:00 GMT+2 hours equals "94/05/06,22:10:00+08"

<fo> depending on the command or result code: first octet of GSM 03.40 SMS- DELIVER, SMS-SUBMIT (default 17), SMS-STATUS-REPORT, or SMS-COMMAND (default 2) in integer format

<length> integer type value indicating in text mode (+CMGF=1) the length of the message body <data> (or <cdata>) in characters; or in PDU mode (+CMGF=0), the length of the actual TP data unit in octets (i.e. the RP layer SMSC address octets are not counted in the length)

<index> integer type; value in the range of location numbers supported by the associated memory

<mid> GSM 03.41 CBM Message Identifier in integer format

<mr> GSM 03.40 TP-Message-Reference in integer format

	<p><oa> GSM 03.40 TP-Originating-Address Address-Value field in string format; BCD numbers (or GSM default alphabet characters) are converted into characters; type of address given by <tooa></p> <p><page> GSM 03.41 CBM Page Parameter bits 4-7 in integer format</p> <p><pages> GSM 03.41 CBM Page Parameter bits 0-3 in integer format</p> <p><pdu> In the case of SMS: GSM 04.11 SC address followed by GSM 03.40 TPDU in hexadecimal format: ME/TA converts each octet of TP data unit into hexadecimal numbers containing two IRA characters (e.g. octet with integer value 42 is presented to TE as two characters 2A (IRA 50 and 65)). In the case of CBS: <ra> GSM 03.40 TP-Recipient-Address Address-Value field in string format; BCD numbers (or GSM default alphabet characters) are converted into characters; type of address given by <tora></p> <p><pid> GSM 03.40 TP-Protocol-Identifier in integer format (default 0)</p> <p><ra> GSM 03.40 TP-Recipient-Address Address-Value field in string format; BCD numbers (or GSM default alphabet characters) are converted to characters of the currently selected TE character set (refer command AT+CSCS Select TE character set.); type of address given by <tora></p> <p><sca> GSM 04.11 RP SC address Address-Value field in string format; BCD numbers (or GSM default alphabet characters) are converted to characters of the currently selected TE character set (refer command AT+CSCS Select TE character set); type of address given by <tosca></p> <p><scts> GSM 03.40 TP-Service-Centre-Time-Stamp in time-string format (refer <dt>)</p> <p><sn> GSM 03.41 CBM Serial Number in integer format</p> <p><st> GSM 03.40 TP-Status in integer format</p> <p><toda> GSM 04.11 TP-Destination-Address Type-of-Address octet in integer format (when first character of <da> is + (IRA 43) default is 145, otherwise default is 129)</p> <p><tooa> GSM 04.11 TP-Originating-Address Type-of-Address octet in integer format (default refer<toda>)</p> <p><tora> GSM 04.11 TP-Recipient-Address Type-of-Address octet in integer format (default refer<toda>)</p> <p><tosca> GSM 04.11 RP SC address Type-of-Address octet in integer format (default refer <toda>)</p> <p><vp> depending on SMS-SUBMIT <fo> setting: GSM 03.40 TP-Validity-Period either in integer format (default 167) or in time-string format (refer <dt>)</p>
<p>Reference GSM 07.05</p>	<p>Note</p> <p>Response to a CMGR to an empty record index: +CMGR: 0,,0</p> <p>Response to a CMGR to a not existing record index: +CMS ERROR: invalid memory index</p>

5.6 AT+CMGS Send SMS message

<p>Test command AT+CMGS=?</p>	<p>Response OK Parameter</p>
<p>Execute command</p> <p>1) If text mode (+CMGF=1): +CMGS=<da> [,<toda>]<CR> text is entered <ctrl-Z/ESC></p> <p>2) If PDU mode (+CMGF=0): +CMGS=<length> <CR> PDU is given <ctrl-Z/ESC> ESC aborts message</p>	<p>Response</p> <p>TA transmits SMS message from TE to network (SMS-SUBMIT). Message reference value <mr> is returned to TE on successful message delivery. Value can be used to identify message upon unsolicited delivery status report result code.</p> <p>1) If text mode (+CMGF=1) and sending successful: +CMGS: <mr>[,<scts>] OK</p> <p>2) If PDU mode (+CMGF=0) and sending successful: +CMGS: <mr>[,<ackpdu>] OK</p> <p>3) If error is related to ME functionality: +CMS ERROR: <err></p> <p>Parameter</p> <p><da> GSM 03.40 TP-Destination-Address Address-Value field in string format; BCD numbers (or GSM default alphabet characters) are converted into characters; type of address given by <toda></p> <p><toda> GSM 04.11 TP-Destination-Address Type-of-Address octet in integer format (when first character of <da> is + (IRA 43) default is 145, otherwise default is 129)</p> <p><length> integer type value indicating in the text mode (+CMGF=1) the length of the message body <data> (or <cdat>) in characters; or in PDU mode (+CMGF=0), the length of the actual TP data unit in octets (i.e. the RP layer SMSC address octets are not counted in the length)</p> <p><mr> GSM 03.40 TP-Message-Reference in integer format</p> <p><scts> GSM 03.40 TP-Service-Centre-Time-Stamp in time-string format (refer <dt>)</p> <p><dt> GSM 03.40 TP-Discharge-Time in time-string format: "yy/MM/dd,hh:mm:ss±zz", where characters indicate year (two last digits), month, day, hour, minutes, seconds and time zone. For example, 6th of May 1994, 22:10:00 GMT+2 hours equals "94/05/06,22:10:00+08"</p> <p><ackpdu> GSM 03.40 RP-User-Data element of RP-ACK PDU; format is same as for <pdu> in case of SMS, but without GSM 04.11 SC address field and parameter shall be enclosed in double quote characters like a normal string type parameter</p> <p><pdu> For SMS: GSM 04.11 SC address followed by GSM 03.40 TPDU in hexadecimal format: ME/TA converts each octet of TP data unit into hexadecimal numbers containing two IRA characters (e.g. octet with integer value 42 is presented to TE as two characters 2A (IRA 50 and 65)). In the case of CBS: GSM 03.41 TPDU in hexadecimal format.</p>
<p>Reference GSM 07.05</p>	<p>Note</p> <ol style="list-style-type: none"> 1. Use CTRL-Z at the end of input to send the message and return OK. 2. Use ESC at the end of message input to abort message send operation. NO message is sent although display returns OK! 3. Sending e-mails via SMS: Note that some providers do not recognise @ symbol. Possible alternative "!" for "@" 4. After invoking of the command CMGW, CMGS, CMGC it is necessary to wait for the ">" symbol and only afterwards the text can be sent to the module 5. With baudrates lower than 19200 it is recommended to use the line termination character only (refer to +ATS3, default <CR>, pg. 21) before entering the text/pdu. Use of the line termination character followed by the response formatting character (see +ATS4, default <LF>, pg. 21) can cause problems.

5.7 AT+CMGW Write SMS message to memory

<p>Test command AT+CMGW=?</p>	<p>Response OK Parameter</p>
<p>Execute command 1) If text mode (+CMGF=1): +CMGW[=<oa/da>[,<tooa/toda>[,<stat>]]] <CR> text is entered ctrl-Z/ESC><ESC> quits without sending 2) If PDU mode (+CMGF=0): +CMGW=<length>[,<stat>]<CR> PDU is given <ctrl-Z/ESC></p>	<p>Response TA transmits SMS (either SMS-DELIVER or SMS-SUBMIT) from TE to memory storage <mem2>. Memory location <index> of the stored message is returned. Message status will be set to 'stored unsent' unless otherwise given in parameter <stat>. <u>Note: SMS-COMMANDs and SMS-STATUS-REPORTs cannot be stored in text mode.</u> If writing is successful: +CMGW: <index> OK If error is related to ME functionality: +CMS ERROR: <err> Parameter <oa> GSM 03.40 TP-Originating-Address Address-Value field in string format; BCD numbers (or GSM default alphabet characters) are converted into characters; type of address given by <tooa> <da> GSM 03.40 TP-Destination-Address Address-Value field in string format; BCD numbers (or GSM default alphabet characters) are converted into characters; type of address given by <toda> <tooa> GSM 04.11 TP-Originating-Address Type-of-Address octet in integer format (default refer <toda>) <toda> GSM 04.11 TP-Destination-Address Type-of-Address octet in integer format (when first character of <da> is + (IRA 43) default is 145, otherwise default is 129) <length> integer type value indicating in the text mode (+CMGF=1) the length of the message body <data> (or <cdata>) in characters; or in PDU mode (+CMGF=0), the length of the actual TP data unit in octets (i.e. the RP layer SMSC address octets are not counted in the length) <stat> integer type in PDU mode (default 0), or string type in text mode (default "REC UNREAD"); indicates the status of message in memory; defined values: 0 "REC UNREAD" Received unread messages (default) 1 "REC READ" Received read messages 2 "STO UNSENT" Stored unsent messages 3 "STO SENT" Stored sent messages <pdu> In the case of SMS: GSM 04.11 SC address followed by GSM 03.40 TPDU in hexadecimal format: ME/TA converts each octet of TP data unit into hexadecimal numbers containing two IRA characters (e.g. octet with integer value 42 is presented to TE as two characters 2A (IRA 50 and 65)). In the case of CBS: GSM 03.41 TPDU in hexadecimal format. <index> Index of message in selected storage <mem2></p>
<p>Reference GSM 07.05</p>	<p>Note 1. Use CTRL-Z at the end of input to send the message and return OK. 2. Use ESC at the end of message input to abort message send operation. NO message is sent although display returns OK! 3. Sending e-mails via SMS: Note that some providers do not recognise @ symbol. Possible alternative "!" for "@" 4. After invoking of the command CMGW, CMGS, CMGC it is necessary</p>

	<p>to wait for the ">" symbol and only afterwards the text can be sent to the module</p> <p>5. With baudrates lower than 19200 it is recommended to use the line termination character only (refer to +ATS3, default <CR>, pg. 21) before entering the text/pdu. Use of the line termination character followed by the response formatting character (refer to +ATS4, default <LF>, pg. 21) can cause problems.</p>
--	--

5.8 AT+CMSS Send SMS message from storage	
Test command AT+CMSS=?	<p>Response</p> <p>OK</p> <p>Parameter</p>
Execute command +CMSS= <index>[,<da> [,<toda>]]	<p>Response</p> <p>TA sends message with location value <index> from message storage <mem2> to the network (SMS-SUBMIT or SMS-COMMAND). If new recipient address <da> is given for SMS-SUBMIT, it shall be used instead of the one stored with the message. Reference value <mr> is returned to the TE on successful message delivery. Values can be used to identify message upon unsolicited delivery status report result code.</p> <p>1) If text mode (+CMGF=1) and send successful: +CMSS: <mr>[,<scts>] OK</p> <p>2) If PDU mode (+CMGF=0) and send successful: +CMSS: <mr>[,<ackpdu>] OK</p> <p>3) If error is related to ME functionality: +CMS ERROR: <err></p> <p>Parameter</p> <p><ackpdu> GSM 03.40 RP-User-Data element of RP-ACK PDU; format is same as for <pdu> in case of SMS, but without GSM 04.11 SC address field and parameter shall be bounded by double quote characters like a normal string type parameter.</p> <p><index> integer type; value in the range of location numbers supported by the associated memory</p> <p><da> GSM 03.40 TP-Destination-Address Address-Value field in string format; BCD numbers (or GSM default alphabet characters) are converted into characters; type of address given by <toda></p> <p><scts> GSM 03.40 TP-Service-Centre-Time-Stamp in time-string format.</p> <p><toda> GSM 04.11 TP-Destination-Address Type-of-Address octet in integer format (when first character of <da> is + (IRA 43) default is 145, otherwise default is 129)</p> <p><mr> GSM 03.40 TP-Message-Reference in integer format</p>
Reference GSM 07.05	<p>Note</p>

5.9 AT+CNMA New SMS message acknowledge to ME/TE, only phase 2+

<p>Test command AT+CNMA=?</p>	<p>Response</p> <p>1) If text mode (+CMGF=1): OK</p> <p>2) If PDU mode (+CMGF=0): +CNMA: (list of supported <n>s) OK</p> <p>Parameters See execute command</p>
<p>Execute command</p> <p>1) If text mode: AT+CNMA</p> <p>2) If PDU mode: AT+CNMA[=<n>]</p>	<p>Response</p> <p>TA confirms successful receipt of a new message (SMS-DELIVER or SMS-STATUS-REPORT) which is routed directly to the TE. TA shall not send another +CMT or +CDS result code to TE until previous one is acknowledged.</p> <p>If ME does not receive acknowledgment within required time (network timeout), ME sends RP-ERROR to the network. TA shall automatically disable routing to TE by setting both <mt> and <ds> values of +CNMI to zero.</p> <p><u>Note: the command shall only be used when +CSMS parameter <service> equals 1 (= phase 2+).</u></p> <p>1) If text mode: OK</p> <p>2) If PDU mode: OK</p> <p>3) If error is related to ME functionality: +CMS ERROR: <err></p> <p>Parameters <n> 0 command operates similarly as defined for the text mode</p>
<p>Reference GSM 07.05</p>	<p>Note</p>

5.10 AT+CNMI New SMS message indications

<p>Test command AT+CNMI=?</p>	<p>Response +CNMI: (list of supported <mode>s), (list of supported <mt>s), (list of supported <bm>s), (list of supported <ds>s), (list of supported <bfr>s) OK Parameter See set command</p>
<p>Read command AT+CNMI?</p>	<p>Response +CNMI: <mode>,<mt>,<bm>,<ds>,<bfr> OK Parameter See set command</p>
<p>Write command AT+CNMI = [<mode>] [,<mt>][,<bm>] [,<ds>][,<bfr>]</p>	<p>Response TA selects the procedure, how the receipt of new SMS messages from the network is indicated to the TE when TE is active, e.g. DTR signal is ON. If TE is inactive (e.g. DTR signal is OFF), message receiving should be done as specified in GSM 03.38. Note1: If the DTR signal is not available or the state of the signal is ignored (V.25ter command &D0), reliable message transfer can be assured by using +CNMA acknowledgment procedure. Note2: The rules <mt>=2 and <mt>=3 for storing received SM are possible only if phase 2+ compatibility is activated with +CSMS=1 Note3: The parameter <ds>=1 is only available in phase 2+ OK If error is related to ME functionality: +CMS ERROR: <err> Parameter <mode> <u>0</u> Buffer unsolicited result codes in the TA. If TA result code buffer is full, indications can be buffered in some other place or the oldest indications may be discarded and replaced with the new received indications. 1 Discard indication and reject new received message unsolicited result codes when TA-TE link is reserved (e.g. in on-line data mode). Otherwise forward them directly to the TE. 3 Forward unsolicited result codes directly to the TE. TA-TE link specific inband technique used to embed result codes and data when TA is in on-line data mode. <mt> Rules for storing received SMs depend on the relevant data coding method (refer to GSM 03.38 [2]), preferred memory storage (+CPMS) setting and this value Note: If AT command interface is acting as the only display device, the ME must support storage of class 0 messages and messages in the message waiting indication group (discard message) <u>0</u> No SMS-DELIVER indications are routed to the TE. 1 If SMS-DELIVER is stored in ME/TA, indication of the memory location is routed to the TE using unsolicited result code: +CMTI: <mem>,<index></p>

	<p>2 SMS-DELIVERs (except class 2 messages and messages in the message waiting indication group (store message)) are routed directly to the TE using unsolicited result code: +CMT: ,<length><CR><LF><pdu> (PDU mode enabled) +CMT: <oa>,, <scts> [,<tooa>, <fo>, <pid>, <dcsc>, <sca>, <tosca>, <length>] <CR> <LF> <data> (text mode enabled)</p> <p>3 Class 3 SMS-DELIVERs are routed directly to the TE using unsolicited result codes defined in <mt>=2. Messages of other data coding schemes result in indication as defined in <mt>=1.</p> <p><bm> Rules for storing received CBMs depend on the relevant data coding method (refer to GSM 03.38 [2]), the setting of Select CBM Types (+CSCB) and this value:</p> <p><u>0</u> No CBM indications are routed to the TE.</p> <p>2 New CBMs are routed directly to the TE using unsolicited result code: +CBM: <length><CR><LF><pdu> (PDU mode enabled) or +CBM: <sn>,<mid>,<dcsc>,<page>,<pages><CR><LF><data> (text mode enabled).</p> <p>3 Class 3 CBMs are routed directly to TE using unsolicited result codes defined in <bm>=2.</p> <p><ds> <u>0</u> No SMS-STATUS-REPORTs are routed to the TE.</p> <p>1 SMS-STATUS-REPORTs are routed to the TE using unsolicited result code: +CDS: <length><CR><LF><pdu> (PDU mode enabled) or +CDS: <fo>,<mr>,[<ra>],[<tora>],<scts>,<dt>,<st> (text mode enabled)</p> <p>2 If SMS-STATUS-REPORT is routed into ME/TA, indication of the memory location is routed to the TE using unsolicited result code: +CDSI: <mem>,<index></p> <p><bfr> <u>1</u> TA buffer of unsolicited result codes defined within this command is cleared when <mode> 1...3 is entered.</p>
	<p>Unsolicited result code</p> <p>+CMTI: <mem>,<index> Indication that new message has been received</p> <p>+CBMI: <mem>,<index> Indication that new CB-message has been received</p> <p>+CMT: ,<length><CR><LF><pdu> Short message is output directly</p> <p>+CBM: <length><CR><LF><pdu> Cell broadcast message is output directly</p> <p>During each SMS or Cell Broadcast Messages the Ring Line will remain Logic „0“ for one second.</p>
Reference GSM 07.05	Note Parameters <mt>=2,3 and <ds>=1 are only available with GSM phase 2+ (see +CSMS=1).

5.11 AT+CPMS Preferred SMS message storage

<p>Test command AT+CPMS=?</p>	<p>Response +CPMS: (list of supported <mem1>s),(list of supported <mem2>s) ,(list of supported <mem3>s) Parameter See write command</p>
<p>Read command AT+CPMS?</p>	<p>Response +CPMS: <mem1>,<used1>,<total1>,<mem2>,<used2>,<total2>,<mem3>,<used3>,<total3> OK If error is related to ME functionality: +CMS ERROR</p> <p>Parameter See write command</p>
<p>Write command AT+CPMS = <mem1> [,<mem2> [,<mem3>]]</p>	<p>Response TA selects memory storages <mem1>, <mem2> and <mem3> to be used for reading, writing, etc. +CPMS: <used1>,<total1>,<used2>,<total2>,<used3>,<total3> OK If error is related to ME functionality: +CMS ERROR:<err></p> <p>Parameter <mem1> Messages to be read and deleted from this memory storage "SM" SIM message storage <mem2> Messages will be written and sent to this memory storage "SM" SIM message storage <mem3> Received messages will be placed in this memory storage if routing to PC is not set (" +CNMI") "SM" SIM message storage <usedx> Number of messages currently in <memx> <totalx> Number of messages storable in <memx></p>
<p>Reference GSM 07.05</p>	<p>Note</p>

5.12 AT+CSCA SMS service centre address

Test command AT+CSCA=?	Response OK
Read command AT+CSCA?	Response +CSCA: <sca>,<tosca> OK Parameter See write command
Write command AT+CSCA = <sca>[,<tosca>]	Response TA updates the SMSC address, through which mobile originated SMs are transmitted. In text mode, setting is used by send and write commands. In PDU mode, setting is used by the same commands, but only when the length of the SMSC address coded into <pdu> parameter equals zero. <u>Note: this command writes the service centre address to non-volatile memory.</u> OK Parameter <sca> GSM 04.11 RP SC address Address-Value field in string format; BCD numbers (or GSM default alphabet characters) are converted into characters; type of address given by <tosca> <tosca> Service centre address format GSM 04.11 RP SC address Type-of-Address octet in integer format (default refer <toda>)
Reference GSM 07.05	Note In case of using no parameter after AT+CSCA= the sca will be deleted.

5.13 AT+CSCB Select cell broadcast messages

Test command AT+CSCB=?	Response +CSCB: (list of supported <mode>s) Parameter See write command
Read command AT+CSCB?	Response +CSCB: <mode>,<mids>,<dcss> Parameter See write command
Write command AT+CSCB=[<mode>[,<mids>[,<dcss>]]]	Parameter <mode> 0 Accepts messages that are defined in <mids> and <dcss> 1 Does not accept messages that are defined in <mids> and <dcss> <mids> String type; combinations of CBM message IDs (e.g. "0,1,5,320-478,922"). The number of ranges in <mids> parameter string is limited to 6 <dcss> String type; combinations of CBM data coding schemes (e.g. "0-3,5") <i>Note: If <mode> = 1 is selected the parameter <mids> has to be given as only one area (e.g. "0-99")</i>
Reference GSM 07.05	Note

5.14 AT+CSDH Show SMS text mode parameters

Test command AT+CSDH=?	Response +CSDH: (list of supported <show>s) OK Parameter See write command
Read command AT+CSDH?	Response +CSDH:<show> OK Parameter See write command
Write command AT+CSDH= <show>	Response TA sets whether or not detailed header information is shown in text mode result codes. OK Parameter <show> 0 do not show header values defined in commands +CSCA and +CSMP (<sca>, <tosca>, <fo>, <vp>, <pid> and <dcs>) nor <length> , <toda> or <tooa> in +CMT, +CMGL, +CMGR result codes for SMS-DELIVERs and SMS-SUBMITs in text mode; for SMS-COMMANDs in +CMGR result code, do not show <pid> , <mn> , <da> , <toda> , <length> or <cdata> 1 show the values in result codes
Reference GSM 07.05	Note

5.15 AT+CSMP Set SMS text mode parameters

<p>Test command AT+CSMP=?</p>	<p>Response OK</p>
<p>Read command AT+CSMP?</p>	<p>Response +CSMP:<fo>,<vp/scts>,<pid>,<dcs> OK</p> <p>Parameter See set command</p>
<p>Set command AT+CSMP= [<fo>[,<vp/scts >[,<pid> [,<dcs>]]]]</p>	<p>Response TA selects values for additional parameters needed when SM is sent to the network or placed in a storage when text format message mode is selected. It is possible to set the validity period starting from when the SM is received by the SMSC (<vp> is in range 0... 255) or define the absolute time of the validity period termination (<vp> is a string). The format of <vp> is given by <fo>. If TA supports the enhanced validity period format, see GSM 03.40), it shall be given as a hexadecimal coded string (refer e.g. <pdu>) with double quotes.</p> <p>NOTE: When storing a SMS_DELIVER from the TE to the preferred memory storage in text mode (refer write command to Message Memory +CMGW), <vp> field can be used for <scts></p> <p>Parameter <fo> depending on the command or result code: first octet of GSM 03.40 SMS-DELIVER, SMS-SUBMIT (default 17), , or SMS-COMMAND (default 2) in integer format <scts> GSM 03.40 TP-Service-Centre-Time-Stamp in time-string format (refer <dt>) <vp> depending on SMS-SUBMIT <fo> setting: GSM 03.40 TP-Validity-Period either in integer format (default 167) , in time-string format (refer <dt>), or if is supported, in enhanced format (hexadecimal coded string with double quotes) <pid> Protocol-Identifier in integer format (default 0), refer GSM 03.40 <dcs> SMS Data Coding Scheme (default 0), or Cell Broadcast Data Coding Scheme in integer format depending on the command or result code: GSM 03.38</p>
<p>Reference GSM 07.05</p>	<p>Note The command writes the parameters in NON-VOLATILE memory.</p>

5.16 AT+CSMS Select Message Service

<p>Test command AT+CSMS=?</p>	<p>Response +CSMS: (list of supported <service>s) OK</p> <p>Parameter See write command</p>
<p>Read command AT+CSMS?</p>	<p>Response +CSMS: <service>,<mt>,<mo>,<bm> OK</p> <p>Parameter See write command</p>
<p>Write command AT+CSMS= <service></p>	<p>Response +CSMS: <mt>,<mo>,<bm> OK</p> <p>If error is related to ME functionality: +CMS ERROR: <err></p> <p>Parameter <service></p> <p>0 GSM 03.40 and 03.41 (the syntax of SMS AT commands is compatible with GSM 07.05 Phase 2 version 4.7.0; Phase 2+ features which do not require new command syntax may be supported (e.g. correct routing of messages with new Phase 2+ data coding schemes))</p> <p>1 GSM 03.40 and 03.41 (the syntax of SMS AT commands is compatible with GSM 07.05 Phase 2+ version; the requirement of <service> setting 1 is mentioned under corresponding command descriptions).</p> <p><mt> Mobile Terminated Messages: 0 Type not supported 1 Type supported</p> <p><mo> Mobile Originated Messages: 0 Type not supported 1 Type supported</p> <p><bm> Broadcast Type Messages: 0 Type not supported 1 Type supported</p>
<p>Reference GSM 07.05</p>	<p>Note If CSMS Mode is switched from Phase 2+ to Phase 2 and one or more CNMI Parameter are Phase 2+ specific a '+CMS ERROR: unknown error' will appear. It is recommended to switch the CNMI Parameters to Phase 2 specific values before entering Phase 2.</p>

	<p>ME is connected:</p> <pre>Serving Cell chann rs dBm PLMN LAC cell NCC BCC PWR RXLev C1 I chann TS timAdv PWR dBm Q ChMod 102 33 -77 26201 3006 6060 3 0 5 -102 25 I 102 4 1 5 -76 2 S_EFR</pre> <p>OK</p>
	<p>Parameters</p> <p>Serving Cell:</p> <p>chann traffic channel number rs RSSI value (0–63) dBm receiving level in dBm PLMN PLMN ID code LAC location area code, see note below. cell Cell ID, see note below. NCC PLMN colour code BCC Base Station colour code PWR maximal power level used on RACH channel RXLev minimal receiving level (in dBm) to allow registration C1 coefficient for base station selection</p> <p>Dedicated channel:</p> <p>chann traffic channel number Note: <chann> = 0 signals frequency hopping. TS timeslot no. timAdv timing advance in bits PWR current power level dBm receiving level in dBm Q receiving quality (0–7) ChMod channel mode (S_HR: Half rate, S_FR: Full rate, S_EFR: Enhanced Full Rate)</p>
<p>Reference Siemens</p>	<p>Note</p> <ol style="list-style-type: none"> If during a connection the radio cell is changed, the parameter LAC and Cell will not be updated (see also +CREG, pg 79). As a result of this command the requested output may be issued by the ME at any moment (related to <period>). To indicate such unsolicited result codes to a connected application, the ME usually activates it's Ring Line (Logic "0") for one second. This is <u>not true</u> during unsolicited output of AT^MONI and AT^MONP.

6.3 AT^MONP Monitor neighbour cells

<p>Test command</p> <p>AT^MONP=?</p>	<p>Response</p> <p>^MONP: (list of supported <period>s) OK</p>
<p>Write command</p> <p>AT^MONP=[<period>]</p>	<p>This command is used to output neighbour cell information periodically. It is cancelled by any character sent to serial port except if autobauding is enabled (+IPR=0). Then type character 'a' to abort.</p> <p>Response</p> <p>See execute command</p> <p>Parameter</p> <p><period> 1 – 254 Display period in seconds</p>
<p>Execute command</p> <p>AT^MONP</p>	<p>This command is used to output neighbour cell information one time.</p> <p>Response (Example)</p> <pre>At^monp Chann rs dBm PLMN BCC C1 C2 29 22 -70 26201 2 33 33 31 21 -72 26201 2 31 31 27 19 -75 26201 0 28 28 47 19 -76 26201 2 27 27 32 18 -77 26201 7 26 26 124 17 -79 26201 2 24 24</pre> <p>OK</p> <p>Parameter:</p> <p>Chann Channel number</p> <p>rs RSSI value (063)</p> <p>dBm Receiving level in dBm</p> <p>PLMN PLMN ID code</p> <p>BCC Base Station colour code</p> <p>C1 coefficient for base station selection</p> <p>C2 coefficient for base station selection</p>
<p>Reference</p> <p>Siemens</p>	<p>Note</p> <p>As a result of this command the requested output may be issued by the ME at any moment (related to <period>).</p> <p>To indicate such unsolicited result codes to a connected application, the ME usually activates it's Ring Line (Logic "0") for one second. This is <u>not true</u> during output of AT^MONI and AT^MONP.</p>

6.4 AT^SACM Advice of charge and query of ACM and ACMmax

<p>Test command AT^SACM=?</p>	<p>Response ^SACM: (list of supported <n>s) OK Parameter See write command</p>
<p>Execute command AT^SACM</p>	<p>Response TA returns the Advice of Charge supplementary service function mode and the SIM values for accumulated call meter (ACM) and accumulated call meter maximum (ACMmax). ^SACM: <n>,<acm>,<acm_max> OK If error is related to ME functionality: +CME ERROR: <err> Parameter See write command</p>
<p>Write command AT^SACM=<n> ></p>	<p>Response TA sets the Advice of Charge supplementary service function mode. OK If error is related to ME functionality: +CME ERROR: <err> Parameter <n> 0 suppress unsolicited result code 1 display unsolicited result code <acm> ACM, string type; three bytes of the current ACM value in hexadecimal format (e.g. "00001E" indicates decimal value 30) 000000–FFFFFF <acm_max> ACMmax, string type; three bytes of the max. ACM value in hexadecimal format (e.g. "00001E" indicates decimal value 30) 000000 disable ACMmax feature 000001-FFFFFF <ccm> string type; three bytes of the current CCM value in hexadecimal format (e.g. "00001E" indicates decimal value 30); bytes are coded in the same way as ACMmax value in the SIM 000000-FFFFFF</p>
	<p>Unsolicited result code When activated, an unsolicited result code is sent when the CCM value changes, but not more often than every 10 seconds +CCCM: <ccm> Parameter See write command</p>
<p>Reference Siemens</p>	<p>Note See also GSM07.07: AT+CACM, AT+CAMM, AT+CAOC</p>

6.5 AT^SBC Battery charge and Charger Control

<p>Test command AT^SBC=?</p>	<p>Response</p> <p>^SBC: (list of supported <bcs>s),(list of supported <bcl>s),<mpc> module power consumption</p> <p>Defined values</p> <p><bcs></p> <ol style="list-style-type: none"> 0 No Charging Adapter is connected 1 Charging Adapter is connected 2 Charging Adapter is connected, charging in process 3 Charging Adapter is connected, charging has finished 4 Charging Error, charging is interrupted 5 Wrong Charging Temperature, charging is interrupted while temperature is in forbidden range <p><bcl></p> <p>Battery capacity</p> <p>0 battery is exhausted or capacity value is not available</p> <p>0, 20, 40, 60, 80, 100 percent of remaining capacity (6 steps)</p> <p><mpc></p> <p>Value (0...5000) of average power consumption (mean value during some seconds) in mA. This means, that <mpc> is the average value of the power consumption of the ME and the current value given by the AT^SBC write command.</p>
<p>Read command AT^SBC?</p>	<p>Command returns battery connection status <bcs>, battery charge level <bcl> and module power consumption <mpc> of the ME.</p> <p>After connecting the Charging Adapter the charging process start automatically. While charging is in progress (Charging Adapter is connected) battery capacity is not available!</p> <p>Response</p> <p>^SBC: <bcs>,<bcl>,<mpc></p>
<p>Write command AT^SBC=<current></p>	<p>The write command sends the actual power consumption of any external application. It is necessary to send this information, because otherwise the ME cannot properly control the charging process.</p> <p>This command registers the serial port as the output channel for unsolicited result codes for charging.</p> <p>Response</p> <p>OK</p> <p>If error is related to ME functionality:</p> <p>+CME ERROR: <err></p> <p>Parameter</p> <p><current> Power consumption in mA (0...5000).</p> <p>Note: Maximal power consumption is 70 mA if the 2.9 voltage power pin is used.</p>

	<p>Unsolicited result code</p> <p>^SBC: Undervoltage</p> <p>If undervoltage is recognized this string is sent to the registered output channel three or more times. If the module is in idle mode it takes typically one minute to de-register from the network and to switch off.</p> <p>Note: This unsolicited result code is output only after write command was issued.</p>
Reference Siemens	<p>Note</p> <p>During charging, it is not possible to determine the capacity of the battery. Consequently, parameter <bcl>=0.</p>

6.6 AT^SCID Display SIM card identification number

Test command AT^SCID=?	<p>Response</p> <p>OK</p> <p>If error is related to ME functionality:</p> <p>+CME ERROR: <err></p> <p>Parameter</p>
Execute command AT^SCID	<p>Response</p> <p>TA returns the identification number of the SIM card (see GSM 11.11 Chapter 10.1.1).</p> <p>^SCID: <cid> OK</p> <p>If error is related to ME functionality:</p> <p>+CME ERROR: <err></p> <p>Parameter</p> <p><cid> string type: card identification number in SIM</p>
Reference Siemens	<p>Note</p>

6.7 AT^SCKS Set SIM connection presentation mode and query SIM connection status

<p>Test command AT^SCKS=?</p>	<p>Response ^SCKS: (list of supported <n>s) OK Parameter See write command</p>
<p>Read command AT^SCKS?</p>	<p>Response TA returns SIM connected presentation mode and SIM connected status. ^SCKS: <n>, <m> OK Parameter See write command</p>
<p>Write command AT^SCKS=<n></p>	<p>Response TA sets SIM connected presentation mode whether or not an unsolicited result code is to be sent to TE when SIM is not connected. OK Parameter <n> 0 Suppress unsolicited result codes 1 Output unsolicited result codes <m> 0 No card 1 Card in card reader</p>
	<p>Unsolicited result code When the status SIM connected has changed, an unsolicited result code is sent to TE ^SCKS: <m> Parameter See write command</p>
<p>Reference Siemens</p>	<p>Note</p>

6.8 AT^SCNI List Call Number Information

Test command AT^SCNI=?	Response OK
Execute command AT^SCNI	Response TA returns a list of current calls of ME. [^SCNI: <id1>[,<cs>[,<number>,<type>]]] [^SCNI: <id2>[,<cs>[,<number>,<type>]]] [...] OK If error is related to ME functionality: +CME ERROR: <err>
	Parameter <idx> 1-7 integer type; call identification number as described in GSM 02.30[19] subclause 4.5.5.1; this number can be used in +CHLD command operations <cs> Call status of respective call number (first parameter) 0 call hold 1 call in progress 2 Waiting call <number> string type phone number in format specified by <type> <type> type of address octet in integer format; 145 when dialling string includes international access code character "+", otherwise 129
Reference Siemens	Note See also GSM 07.07: AT+CLCC

6.9 AT^SCTM Set critical operating temperature presentation mode or query temperature

<p>Test command AT^SCTM=?</p>	<p>Response ^SCTM: (list of supported <n>s) OK Parameter See write command</p>																					
<p>Read command AT^SCTM?</p>	<p>Response TA returns critical operating temperature presentation mode setting and temperature data ^SCTM: <n>, <m> OK Parameter See write command</p>																					
<p>Write command AT^SCTM=<n> ></p>	<p>TA sets critical operating temperature presentation mode</p> <p>Response OK</p> <p>Parameters</p> <table border="0"> <tr> <td style="vertical-align: top;"><n></td> <td style="vertical-align: top;"><u>0</u></td> <td style="vertical-align: top;">Suppress unsolicited result codes.</td> </tr> <tr> <td></td> <td style="vertical-align: top;">1</td> <td style="vertical-align: top;">Output unsolicited result codes.</td> </tr> </table> <table border="0"> <tr> <td style="vertical-align: top;"><m></td> <td style="vertical-align: top;">-2</td> <td style="vertical-align: top;">Below lowest-temperature limit (causes immediate switch-off)</td> </tr> <tr> <td></td> <td style="vertical-align: top;">-1</td> <td style="vertical-align: top;">Below low-temperature-alert limit</td> </tr> <tr> <td></td> <td style="vertical-align: top;">0</td> <td style="vertical-align: top;">Valid working temperature</td> </tr> <tr> <td></td> <td style="vertical-align: top;">1</td> <td style="vertical-align: top;">Above upper-temperature-alert limit</td> </tr> <tr> <td></td> <td style="vertical-align: top;">2</td> <td style="vertical-align: top;">Above uppermost-temperature limit (causes immediate switch-off)</td> </tr> </table>	<n>	<u>0</u>	Suppress unsolicited result codes.		1	Output unsolicited result codes.	<m>	-2	Below lowest-temperature limit (causes immediate switch-off)		-1	Below low-temperature-alert limit		0	Valid working temperature		1	Above upper-temperature-alert limit		2	Above uppermost-temperature limit (causes immediate switch-off)
<n>	<u>0</u>	Suppress unsolicited result codes.																				
	1	Output unsolicited result codes.																				
<m>	-2	Below lowest-temperature limit (causes immediate switch-off)																				
	-1	Below low-temperature-alert limit																				
	0	Valid working temperature																				
	1	Above upper-temperature-alert limit																				
	2	Above uppermost-temperature limit (causes immediate switch-off)																				
	<p>Unsolicited result code When the temperature data has changed, an unsolicited result code is sent to TE: SCTM_A: <m> for accu temperature SCTM_B: <m> for board (module) temperature Parameter See write command</p>																					
<p>Reference Siemens</p>	<p>Note Important: The device switches off (like AT^SMSO) even if <n> is 0 and user is not informed. Critical temperatures will be defined in the hardware specifications.</p>																					

6.10 AT^SDLD Delete the “last number redial“ memory

Test command AT^SDLD=?	Response OK
Execute command AT^SDLD	Response OK/ERROR/+CME ERROR
Reference Siemens	Note

6.11 AT^SHOM Display Homezone

Test command AT^SHOM=?	Response OK Parameter See execute command						
Execute command AT^SHOM	Response TA returns homezonestate ^SHOM: <homezonestate> OK Parameters <table border="0"> <tr> <td>< homezonestate ></td> <td>0</td> <td>ME is out of Homezone</td> </tr> <tr> <td></td> <td>1</td> <td>ME is within the Homezone</td> </tr> </table>	< homezonestate >	0	ME is out of Homezone		1	ME is within the Homezone
< homezonestate >	0	ME is out of Homezone					
	1	ME is within the Homezone					
Reference Siemens	Note						

6.12 AT^SLCD Display Last Call Duration

Test command AT^SLCD=?	Response OK Parameter See execute command
Execute command AT^SLCD	Response TA returns last call duration or current call duration ^SLCD: <time> OK Parameter <time> string type value; format is "hh:mm:ss", where characters indicate hours, minutes, seconds; E.g. 22:10:00 "22:10:00", max values are 9999:59:59
Reference Siemens	Note

6.13 AT^SLCK Facility lock (including self-defined locks)

<p>Test command AT^SLCK=?</p>	<p>Response ^SLCK: (list of supported <fac>s) OK Parameter See write command</p>
<p>Write command AT^SLCK = <fac>, <mode> [,<passwd> [,<class>]]</p>	<p>Response This command is used to lock, unlock or interrogate a ME or a network facility <fac>. Password is normally needed for such actions. When querying the status of a network service (<mode>=2) the response line for 'not active' case (<status>=0) should be returned only if service is not active for any <class>. It should be possible to abort the command when network facilities are set or interrogated.</p> <p>If <mode><=2 and command is successful OK If <mode>=2 and command successful ^SLCK: <status>[,<class1>[<CR><LF> ^SLCK: <status>, class2....]] OK If error is related to ME functionality: +CME ERROR: <err></p> <p>Parameter <fac> "CS" Keypad lock (not supported since keypad cannot be connected) "PS" Phone locked to SIM (phone code). ME requests password when other than current SIM card inserted; ME may remember certain number of previously used cards thus not requiring password when they are inserted. "SC" SIM card (PIN). SIM requests password upon ME power-up and when this lock command issued. "FD" FDN lock, SIM fixed dialling memory feature (if PIN2 authentication has not been performed during the current session, PIN2 is required as <passwd>) "AO" BAOC (Bar All Outgoing Calls) "OI" BOIC (Bar Outgoing International Calls) "OX" BOIC-exHC (Bar Outgoing International Calls except to Home Country) "AI" BAIC (Bar All Incoming Calls) "IR" BIC-Roam (Bar Incoming Calls when Roaming outside the home country) "AB" All Barring services (applicable only for <mode>=0) "AG" All Outgoing barring services (applicable only for <mode>=0) "AC" All inComing barring services (applicable only for <mode>=0)</p> <p><u>The following parameters depend on the factory settings:</u> "PF" lock Phone to the very First SIM card "PN" Network Personalisation "PU" Network subset Personalisation "PP" Service Provider Personalisation "PC" Corporate Personalisation</p>

	<p><mode> 0 disable lock 1 enable lock 2 query lock status</p> <p><passwd> password</p> <p><class> 1 voice 2 data 4 fax Z all classes</p> <p><status> 0 off 1 on</p>
Reference Siemens	Note See also GSM 07.07: AT+CLCK

6.14 AT^SMGL List SMS messages from preferred storage

Test command AT^SMGL=?	Response See write command + CMGL Parameters See command +CMGL
Execute/Write command AT^SMGL [=<stat>]	Response TA returns messages with status value <stat> from message storage <mem1> to the TE. The status of the messages is <code>u n c h a n g e d</code> (unread remains unread). Otherwise: See command +CMGL Parameters See command +CMGL
Reference Siemens	Note See also GSM 07.05: +CMGL

6.15 AT^SMGO Set or query SMS overflow presentation mode or query SMS overflow

<p>Test command AT^SMGO=?</p>	<p>Response ^SGMO: (list of supported <n>s) OK Parameter See write command</p>
<p>Read command AT^SMGO?</p>	<p>Response TA returns overflow presentation mode and SMS overflow status ^SGMO: <n>,<mode> OK If error is related to ME functionality: +CME ERROR: <err> Parameter See write command</p>
<p>Write command AT^SMGO=<n> ></p>	<p>Response TA sets overflow presentation mode OK Parameter <n> SMS overflow presentation mode 0 disable (default) 1 enable <mode> SMS overflow status 0 space available 1 SMS buffer full (chip card) 2 Buffer full and new message waiting in SC for delivery to phone</p>
	<p>Unsolicited result code When the status SIM overflow changes, an unsolicited result code is sent to TE ^SMGO: <mode> Parameter See write command</p>
<p>Reference Siemens</p>	<p>Note Indication during data transfer via break (100ms). Data transmission will only be interrupted by a break and for only 100ms.</p>

6.16 AT^SMSO Switch off mobile station

Test command AT^SMSO=?	Response OK
Execute command AT^SMSO	Response ^SMSO: MS OFF OK Device will be switched off (power down mode)
Reference Siemens	Note Don't send any command after this command

6.17 AT^SMGR Read SMS message without set to REC READ

Test command AT^SMGR=?	Response OK
Execute command AT^SMGR= <index>	Parameter See AT+CMGR
Reference GSM 07.05	Note The AT^SMGR command is a specific Siemens command with the same syntax as "AT+CMGR Read SMS message". The only difference is that the SMS Message, which has REC_UNREAD status, is not overwritten to REC_READ.

6.18 AT^SM20 Set M20 Compatibility

Test command AT^SM20=?	Response OK
Read command AT^SM20?	Response ^SM20: <n> OK Parameters See write command
Write command AT^SM20=<n>	Response TA switch the compatibility to other GSM modules OK Parameters <n> 0 Compatible to X35 Mobile Phones 1 Compatible to M20
Reference Siemens	Note There is a difference during call establishing (e.g. ATD): If x35 selected, the TC35 will respond always OK after attempting a call. If M20 is selected, the TC35 will respond OK only in case of a successful connection.

6.19 AT^SNFD Set audio parameters to manufacturer default values

Test command AT^SNFD=?	Response OK
Execute command AT^SNFD	Response TA sets the active audio parameters to manufacturer defined default values. OK
Reference Siemens	Note The restored values are: <inBbcGain>, <inCalibrate>, <outBbcGain>, <outCalibrate[0 to 4]>, <sideTone> of all audio modes

6.20 AT^SNFI Set microphone path parameters

Test command AT^SNFI=?	Response ^SNFI: (list of supported <inBbcGain>s), (list of supported <inCalibrate>s) OK Parameters See write command
Read command AT^SNFI?	Response +SNFI: < inBbcGain >, <inCalibrate> OK Parameters See write command
Write command AT^SNFI=<inBbcGain>,<inCalibrate>	Response TA sets microphone path amplifying. OK
	Parameters <inBbcGain> Setting for ADC gain Amplifier 0 - 7 (0=0 dB, 7=42 dB, 8 steps of 6 dB) <inCalibrate> Multiplication factor 0 – 32767 for input samples attenuation= $20 \cdot \log(\text{inCalibrate}/32767)$
Reference Siemens	Note <ol style="list-style-type: none"> 1. Write command works only in audio modes 2 to 6! 2. Read and write options of this command refers to the active audio mode. 3. The range of <inCalibrate> is up to 65535 but will be suppressed to 32767. Values above <inCalibrate> = 65535 will cause a failure 4. Changed values have to be stored via ^SNFW. 5. Attention! In case of changing audio parameters it is possible that the maximum allowed volume will be exceeded and users could get damage to their hearing! 6. The default values are customer-specific.

6.21 AT^SNFM Mute microphone

Test command AT^SNFM=?	Response ^SNFM: (list of supported <mute>s) OK Parameter See write command						
Read command AT^SNFM?	Response +SNFM: <mute> OK Parameter See write command						
Write command AT^SNFM= <mute>	Response TA switches on/off the microphone OK Parameter <table border="0"> <tr> <td><mute></td> <td>0</td> <td>Mute microphone</td> </tr> <tr> <td></td> <td><u>1</u></td> <td>Microphone on</td> </tr> </table>	<mute>	0	Mute microphone		<u>1</u>	Microphone on
<mute>	0	Mute microphone					
	<u>1</u>	Microphone on					
Reference Siemens	Note This command can be used in all audio modes and during a voice call only.						

6.22 AT^SNFO Set audio output (= loudspeaker path) parameter

<p>Test command AT^SNFO=?</p>	<p>Response ^SNFO: (list of supported <outBbcGain>), (list of supported <outCalibrate[0...4]>), (list of supported <outStep>), (list of supported <sideTone>s) OK Parameter See write command</p>
<p>Read command AT^SNFO?</p>	<p>Response +SNFO: <outBbcGain>, <outCalibrate[0]>,...<outCalibrate[4]>, <outStep>, <sideTone> OK Parameter See write command</p>
<p>Write command AT^SNFO=<outBbcGain>,<outCalibrate[0]>,...<outCalibrate[4]>,<outStep>,<sideTone></p>	<p>Set TA's loudspeaker path parameters. Response <outBbcGain> <outCalibrate[0]>...<outCalibrate[4]> <outStep> <sideTone> OK Parameters <outBbcGain> Setting for DAC gain Amplifier attenuation 0 – 3 (0=0 dB, 3=-18 dB, 4 steps of 6 dB) <outCalibrate[0]> ... <outCalibrate[4]> Multiplication factor 0 – 32767 for output samples Attenuation = 20 * log (outCalibrate[n]/32767) <outStep> Setting of actual volume; 0 – 4 <sideTone> Multiplication factor 0 – 32767 determining how much of the original microphone signal is added to the earpiece signal. Side Tone Gain/dB = 20 * log (sideTone/32767)</p>
<p>Reference Siemens</p>	<p>Note 1. Write command works only in audio modes 2 to 6! 2. Read and write options of this command refer to the active audio mode. 3. The values <outStep> can be changed also by ^SNFV . 4. The range of <outCalibrate> is up to 65535 but will be suppressed to 32767. A value above <outCalibrate> = 65535 will cause a error 5. Changed values will not be stored automatically, but via the at command AT^SNFW except <outStep>. The parameter <outStep> will be saved after AT^SMSO only. 6. The volume level as well as mute affects all audio modes. 7. In case of audio mode 1 the parameter <outStep> has no effect. 8. Attention! In case of changing audio Parameters it is possible that the maximum allowed <i>volume will be exceeded</i> and users could get damage to their hearing!</p>

6.23 AT^SNFS Select audio hardware set

Test command AT^SNFS=?	Response ^SNFS: (list of supported <audMode>s) OK Parameter See write command
Read command AT^SNFS?	Response ^SNFS: <audMode> OK Parameter See write command
Write command AT^SNFS= <audMode>	Response TA activates the selected audio mode. OK If error is related to ME functionality: + CME ERROR: <error> Parameters <audMode> <ol style="list-style-type: none"> 1 Audio mode 1: Standard mode approved for default handset, switched always through analog interface 1. Volume level is to be controlled with the related knob of the default handset only. This handset can be used in audio mode 4 with user defined parameters. <i>Note:</i> The default parameters are determined for type approval and are not adjustable by AT Commands in this audio mode. 2 Audio mode 2: Customer specific mode for basic handsfree (Siemens Car-Kit), switched through analog interface 2; audio parameters can be adjusted by AT Commands 3 Audio mode 3: Customer specific mode for mono-headset; audio parameters can be adjusted by AT Commands; switched through analog interface 2 4 Audio mode 4: Customer specific mode for user handset switched through analog interface 1; audio parameters can be adjusted by AT Commands 5 Audio mode 5: Customer specific mode switched through analog interface 1; audio parameters can be adjusted by AT Commands 6 Audio mode 6: Customer specific mode switched through analog interface 2; audio parameters can be adjusted by AT Commands
Reference Siemens	Note

6.24 AT^SNFV Set loudspeaker volume

Test command AT^SNFV=?	Response ^SNFV: (list of supported <outStep>s) OK Parameter See write command
Read command AT^SNFV?	Response ^SNFV: <outStep> OK Parameter See write command
Write command AT^SNFV=<outStep>	Response TA sets the volume of the loudspeaker to the value <outCalibrate> addressed by <outStep>. OK Parameter <outStep> Volume range 0 to 4
Reference Siemens	Note <ol style="list-style-type: none"> 1. Read and write commands are related to the active audio mode. 2. The changes are allowed in audio modes 2 to 6. 3. <outStep> can be changed by AT^SNFO, too. 4. <outCalibrate> can be changed by AT^SNFO. 5. The changed <outStep> value will not be saved via AT^SNFW but via AT^SMSO during „switch off“.

6.25 AT^SNFW Write audio setting in non-volatile store

Test command AT^SNFW=?	Response OK
Execute command AT^SNFW	Response TA writes the active audio parameters in non-volatile store related to the active mode. OK If error is related to ME functionality: + CME ERROR: <error> <error> memory failure Flash write error
Reference Siemens	Note Execute command works only in audio mode 2 to 6. TA writes the following audio parameter values in non-volatile store: <inBbcGain>, <inCalibrate>, <outBbcGain>, <outCalibrate[0]> ... <outCalibrate[4]>, <side Tone>

6.26 AT^SPBC Seek the first entry in the sorted telephone book

Test command AT^SPBC=?	Response ^SPBC: (list of sorted telephone books supported <mem>s) See AT+CPBS/AT^SPBS OK/ERROR/+CME ERROR
Write command AT^SPBC=<char>	Parameter <char> First letter of sought entry <index> Index in the sorted telephone book (access via AT^SPBG)
	Response ^SPBC: <index> OK/ERROR/+CME ERROR
Reference Siemens	Note There is no difference between small and capital letters.

6.27 AT^SPBG Read entry from the sorted telephone book via the sorted index

Test command AT^SPBG=?	Response ^SPBG: (list of supported <index>s), <nlength>, <tlength> OK/ERROR/+CME ERROR
	Parameter <index> Location number <nlength> Max. length of telephone number <tlength> Max. length of the text corresponding to the number
Write command AT^SPBG= <index1> [, <index2>]	Response ^SPBG: <index1>, <number>, <typ>, <text>[<CR><CL> ^SPBG: ^SPBG: <index2>, <number>, <typ>, <text>] OK/ERROR/+CME ERROR
	Parameter <index1> Location number where reading of the entry starts <index2> Location number where reading of the entry ends <number> Telephone number <typ> Type of number <text> Text corresponding to the telephone number
Reference Siemens	Note

6.28 AT^SPBS Steps the selected phonebook alphabetically

Test command AT^SPBS=?	Response ^SPBS: (list of supported <value>s) OK Parameter See write command
Write command AT^SPBS= <value>	Parameter <value> 1 to make a step downward in the alphabetically sorted phonebook 2 to make a step upward in the alphabetically sorted phonebook Response if <value>=1 TA steps down one entry. ^SPBS: <index2>,<number>,<type>,<text> <CR,LF> ^SPBS: <index3>,<number>,<type>,<text> <CR,LF> ^SPBS: <index4>,<number>,<type>,<text> <CR,LF>,<CR,LF> OK if <value>=2 (after <value>=1) TA steps up one entry. ^SPBS: <index1>,<number>,<type>,<text> <CR,LF> ^SPBS: <index2>,<number>,<type>,<text> <CR,LF> ^SPBS: <index3>,<number>,<type>,<text> <CR,LF>,<CR,LF> OK If error is related to ME functionality: +CME ERROR: <err> The parameters in the response are explained in the specification of the "AT^SPBG" command.
Reference Siemens	Note This command can be used for the ME, SM and FD phonebook.

6.29 AT^SPIC Display PIN counter

Test command AT^SPIC=?	Response OK If error is related to ME functionality: +CME ERROR: <err> Parameter
Execute command AT^SPIC	TA returns the number of attempts still available for entering the required password. <i>Note:</i> Use command "AT+CPIN?" to check if password entry is currently required. Response ^SPIC: <counter> OK If error is related to ME functionality: +CME ERROR: <err> Parameter <counter> Number of attempts still available for entering the required password.
Reference Siemens	Note

6.30 AT^SPLM Read the PLMN list

Test command AT^SPLM=?	Response OK Parameter See execute command
Execute command AT^SPLM	Response TA returns the list of operator names from the ME. Each operator code <numeric> that has an alphanumeric equivalent <alphan> in the ME memory is returned. ^SPLM: numeric <numeric1>,long alphanumeric <alpha1><CR><LF> ^SPLM:.....OK If error is related to ME functionality: +CME ERROR: <err> Parameter <numeric> string type; operator in numeric form; GSM location area identification number <alphan> string type; operator in long alphanumeric format; can contain up to 16 characters
Reference Siemens	Note See also GSM 07.07: +COPN, +COPS

6.31 AT^SPLR Read entry from the preferred operators list

Test command AT^SPLR=?	Response TA returns the whole index range supported by the SIM. ^SPLR: (list of supported <index>s) OK If error is related to ME functionality: +CME ERROR: <err> Parameter See write command
Write command AT^SPLR= <index1>[, <index2>]	Response TA returns used entries from the SIM list of preferred operators with <index> between <index1> and <index2>. If <index2> is not given, only entry with <index1> is returned. ^SPLR: <index1>, <oper> ^SPLR: ^SPLR: <index2>, <oper> OK If error is related to ME functionality: +CME ERROR: <err> Parameter <index1> location number to read from <index2> location number to read to <oper> string type; operator in numeric form; GSM location area identification number
Reference Siemens	Note GSM 07.07: AT+CPOL

6.32 AT^SPLW Write an entry to the preferred operators list

Test command AT^SPLW=?	Response TA returns the whole index range supported by the SIM. ^SPLW: (list of supported <index>s) OK If error is related to ME functionality: +CME ERROR: <err> Parameter See write command
Write command AT^SPLW = <index> [,<oper>]	Parameter TA writes an entry to the SIM list of preferred operators at location number <index>. If <index> is given but <oper> is left out, the entry is deleted. If <oper> is given but <index> is left out, <oper> is inserted in the next free location. <index> location number <oper> string type; operator in numeric form; GSM location area identification number <i>Note:</i> <oper> is a 5 digit number, 3 digits country code and 2 digits for the Network provider. Response OK If error is related to ME functionality: +CME ERROR: <err>
Reference Siemens	Note See also GSM 07.07: AT+CPOL

6.33 AT^SPWD Change password for a lock (including locks defined by Siemens AG)

<p>Test command AT^SPWD=?</p>	<p>Response ^SPWD: (list of supported (<fac>, <pwdlength>))s) OK If error is related to ME functionality: +CME ERROR: <err> Parameter <fac> "P2" PIN2 otherwise see write command without "FD" <pwdlength> integer, max. length of password</p>
<p>Write command AT^SPWD = <fac>, <oldp- wd>, <newpwd></p>	<p>Parameter "SC" SIM card (PIN) "AO" BAOC (Bar All Outgoing Calls) "OI" BOIC (Bar Outgoing International Calls) "OX" BOIC-exHC (Bar Outgoing International Calls except to Home Country) "AI" BAIC (Bar All Incoming Calls) "IR" BIC-Roam (Bar Incoming Calls when Roaming outside the home country) "AB" All Barring services "AG" All outGoing barring services "AC" All inComing barring services "P2" PIN 2 "PS" Phone locked to SIM (device code) "PF" lock Phone to the very first SIM card "PN" Network Personalisation "PU" Network subset Personalisation "PP" Service Provider Personalisation "PC" Corporate Personalisation <oldpwd> password specified for the facility from the user interface or with command. If an old password has not yet been set, <oldpwd> is not to enter. if <fac> = "SC" then PIN if <fac> = "AO"... "AC" (barring) then network password if <fac> = "P2" then PIN2 <newpwd> new password</p>
	<p>Response Facility locks: AO, OI, OX, AI, IR, AB, AG, AC, have the the same ME <password> to lock and unlock. The <password> depends on the network provider. TA sets a new password for the facility lock function. OK If error is related to ME functionality: +CME ERROR: <err></p>
<p>Reference Siemens</p>	<p>Note See also GSM 07.07: AT+CPWD</p>

6.34 AT^SSYNC Configure SYNC Pin

The ^SSYNC command serves to configure the SYNC pin in the ZIF connector of the GSM engine. Please note that the pin may have different functions, depending on the type of GSM engine. The following AT commands apply to the TC35 and TC37 modules and the TC35 Terminal, however the options available for mode 0 and 1 vary with the model.

For detailed information on the SYNC pin refer to the "Hardware Interface Description" supplied with your GSM engine. Before changing the mode of the SYNC pin, carefully read the technical specifications.

<p>Test command AT^SSYNC=?</p>	<p>Response ^SSYNC: (list of supported <mode>s) OK</p> <p>Parameter See write command</p>										
<p>Read command AT^SSYNC?</p>	<p>Response +SSYNC: <mode> OK</p> <p>Parameter See write command</p>										
<p>Write command AT^SSYNC= <mode></p>	<p>Response OK</p> <p>Parameter <mode> <u>0</u> <i>TC35 / TC37 module:</i> Enables the SYNC pin to indicate growing power consumption during a transmit burst. You can make use of the signal generated by the SYNC pin, if power consumption is your concern. To do so, ensure that your application is capable of processing the signal. Your platform design must be such that the incoming signal causes other components to draw less current. In short, this allows your application to accommodate current drain and thus, supply sufficient current to TC35 if required. <i>TC35 Terminal:</i> not applicable (do not select mode 0).</p> <p>1 Enables the SYNC Pin to control a status LED. On <i>the TC35 Terminal</i>, this is the LED placed on the front panel. If you use <i>a TC35 or TC37 module</i>, the SYNC pin can control an LED installed in your application. The options described below are applicable both to the module and the terminal. Note: Mode 1 is the default mode for the TC35 Terminal.</p> <p>Operating modes of the ME indicated to the user (if <mode> = 1):</p> <table border="1" data-bbox="403 1456 1402 1955"> <thead> <tr> <th>LED</th> <th>ME Mode</th> </tr> </thead> <tbody> <tr> <td>Off</td> <td>ME is off or in Sleep mode.</td> </tr> <tr> <td>600ms/600 ms On/Off</td> <td>No SIM card inserted, or no PIN entered, or network search in progress, or ongoing user authentication, or network login in progress.</td> </tr> <tr> <td>75ms/3s High/low</td> <td>Logged to a network (therefore monitoring control channels and user interactions), but no call in progress.</td> </tr> <tr> <td>On</td> <td><i>Voice call:</i> Connected to remote party. <i>Data call:</i> Connected to remote party or exchange of parameters between both parties while setting up or disconnecting a call.</td> </tr> </tbody> </table>	LED	ME Mode	Off	ME is off or in Sleep mode.	600ms/600 ms On/Off	No SIM card inserted, or no PIN entered, or network search in progress, or ongoing user authentication, or network login in progress.	75ms/3s High/low	Logged to a network (therefore monitoring control channels and user interactions), but no call in progress.	On	<i>Voice call:</i> Connected to remote party. <i>Data call:</i> Connected to remote party or exchange of parameters between both parties while setting up or disconnecting a call.
LED	ME Mode										
Off	ME is off or in Sleep mode.										
600ms/600 ms On/Off	No SIM card inserted, or no PIN entered, or network search in progress, or ongoing user authentication, or network login in progress.										
75ms/3s High/low	Logged to a network (therefore monitoring control channels and user interactions), but no call in progress.										
On	<i>Voice call:</i> Connected to remote party. <i>Data call:</i> Connected to remote party or exchange of parameters between both parties while setting up or disconnecting a call.										
<p>Reference Siemens</p>	<p>Note</p>										

6.35 AT^STCD Display Total Call Duration

Test command AT^STCD=?	Response OK
Execute command AT^STCD	<p>Response TA returns total call duration (accumulated duration of all calls) ^STCD: <time> OK</p> <p>Parameter <time> string type value; format is "hh:mm:ss", where characters indicate hours, minutes, seconds; E.g. 22:10:00 "22:10:00" max value is 9999:59:59</p>
Reference Siemens	Note The Total Call Duration will not be reset by power off or other means.

7 Summary of ERRORS and Messages

Final result code **+CMS ERROR: <err>** indicates an error related to mobile equipment or network. The operation is similar to **ERROR** result code. None of the following commands in the same command line is executed. Neither **ERROR** nor **OK** result code are returned.

<err> values used by common messaging commands:

7.1 Summary of CME ERRORS related to GSM 07.07

Code of <err>	Meaning
0	phone failure
1	no connection to phone
2	phone-adaptor link reserved
3	Operation not allowed
4	Operation not supported
5	PH-SIM PIN required
6	PH-FSIM PIN required
7	PH-FSIM PUK required
10	SIM not inserted
11	SIM PIN required
12	SIM PUK required
13	SIM failure
14	SIM busy
15	SIM wrong
16	Incorrect password
17	SIM PIN2 required
18	SIM PUK2 required
20	Memory full
21	invalid index
22	not found
23	Memory failure
24	text string too long
25	invalid characters in text string
26	dial string too long
27	invalid characters in dial string
30	no network service
31	Network timeout
32	Network not allowed emergency calls only
40	Network personalization PIN required
41	Network personalization PUK required
42	Network subset personalization PIN required
43	Network subset personalization PUK required
44	service provider personalization PIN required
45	service provider personalization PUK required
46	Corporate personalization PIN required
47	Corporate personalization PUK required
100	Unknown
256	Operation temporary not allowed
257	call barred
258	phone is busy
259	user abort

Code of <err>	Meaning
260	invalid dail string
261	ss not executed
262	SIM blocked

Note: Values below 256 are reserved.

7.2 Summary of CMS ERRORS related to GSM 07.05

Code of <err>	Meaning
1	Unassigned (unallocated) number
8	Operator determined barring
10	Call barred
21	Short message transfer rejected
27	Destination out of service
28	Unidentified subscriber
29	Facility rejected
30	Unknown subscriber
38	Network out of order
41	Temporary failure
42	Congestion
47	Resources unavailable, unspecified
50	Requested facility not subscribed
69	Requested facility not implemented
81	Invalid short message transfer reference value
95	Invalid message, unspecified
96	Invalid mandatory information
97	Message type non-existent or not implemented
98	Message not compatible with short message protocol state
99	Information element non-existent or not implemented
111	Protocol error, unspecified
127	Interworking, unspecified
128	Telematic interworking not supported
129	Short message Type 0 not supported
130	Cannot replace short message
143	Unspecified TP-PID error
144	Data coding scheme (alphabet) not supported
145	Message class not supported
159	Unspecified TP-DCS error
160	Command cannot be actioned
161	Command unsupported
175	Unspecified TP-Command error
176	TPDU not supported
192	SC busy
193	No SC subscription
194	SC system failure
195	Invalid SME address
196	Destination SME barred
197	SM Rejected-Duplicate SM
198	TP-VPF not supported
199	TP-VP not supported
208	D0 SIM SMS storage full
209	No SMS storage capability in SIM
210	Error in MS

Code of <err>	Meaning
211	Memory Capacity Exceeded
212	SIM Application Toolkit Busy
213	SIM data download error
255	Unspecified error cause
300	ME failure
301	SMS service of ME reserved
302	Operation not allowed
303	Operation not supported
304	Invalid PDU mode parameter
305	Invalid text mode parameter
310	SIM not inserted
311	SIM PIN required
312	PH-SIM PIN required
313	SIM failure
314	SIM busy
315	SIM wrong
316	SIM PUK required
317	SIM PIN2 required
318	SIM PUK2 required
320	Memory failure
321	Invalid memory index
322	Memory full
330	SMSC address unknown
331	no network service
332	Network timeout
340	NO +CNMA ACK EXPECTED
500	Unknown error
512	User abort

7.3 Summary of all Unsolicited Result Codes (URC)

A URC is a report message sent from the ME to the TE. An unsolicited result code can either be delivered automatically when an event occurs or as a result of a query the ME received before. However, a URC is not issued as a *direct* response to an executed AT command.

Typical URCs may be information about incoming calls, received SMS, changing temperature, status of the battery etc. A summary of all URCs is listed below. For each of these messages, you can configure the ME whether or not to send an unsolicited result code.

For the URC to be sent the ME activates its Ring Line (Logic "0"), i.e. the line goes active low.

Message	Meaning
+CCCM: <ccm>	Current call meter value
+CREG: <stat>[,<lac>,<ci>]	Registration in the ME network changed
+CRING: <type>	Indication of an incoming call
+CLIP: <number>, <type>	Telephone number of caller
+CMTI:<mem>,<index>	Indication of a new short message
+CMT:<length><CR><LF><pdu>	Short message
+CBM: <length><CR><LF><pdu>	Cell broadcast message is output directly
+CSSI: <code1> +CSSU: <code2>	Supplementary service intermediate/unsolicited result code
^SMGO: <mode>	SMS overflow indicator
^SCKS: <m>	Message indicating whether card has been removed or inserted
^SCTM: <m>	Temperature data has changed
^SYSSTART	The module is started. This message will be sent after start up.
^SBC: Undervoltage	Undervoltage of battery detected. The module will be switched off within a minute.
+CALA: <text>	Individually configured alarm (see AT+CALA)

7.4 Result codes

Indication	Numeric	Meaning
OK	0	Command executed, no errors, Wake up after reset
CONNECT	1	Link established
RING	2	Ring detected
NO CARRIER	3	Link not established or disconnected
ERROR	4	Invalid command or command line too long
NO DIALTONE	6	No dial tone, dialling impossible, wrong mode
BUSY	7	Remote station busy
CONNECT 2400	10	Link with 2400 bps
CONNECT 4800	30	Link with 4800 bps
CONNECT 9600	32	Link with 9600 bps
CONNECT 2400/RLP	47	Link with 2400 bps and Radio Link Protocol
CONNECT 4800/RLP	48	Link with 4800 bps and Radio Link Protocol
CONNECT 9600/RLP	49	Link with 9600 bps and Radio Link Protocol
ALERTING		Alerting at called phone
DIALING		Mobile phone is dialing

7.5 Cause Location ID for the extended error report (AT+CEER)

ID	Description
0	No error (default)
2	GSM cause for L3 Radio Resource Sublayer
4	GSM cause for L3 Mobility Management Sublayer
6	GSM cause for L3 Mobility Management Sublayer via MMR-SAP
8	GSM cause for L3 Call Control Entity
12	GSM cause for L3 SMS CP Entity
14	GSM cause for L3 SMS RL Entity
16	GSM cause for L3 SMS TL Entity
21	GSM cause for L3 Call-related SS

7.6 Release causes for the Extended Error Report (AT+CEER)

Number	Description
0	No Error (default)
1	UNASSIGNED NUMBER
3	NO ROUTE TO DESTINATION
6	CHANNEL UNACCEPTABLE
8	OPERATOR DETERMINED BARRING
16	NORMAL CLEARING
17	USER BUSY
18	NO USER RESPONDING
19	USER ALERTING, NO ANSWER
21	CALL REJECTED
22	NUMBER CHANGED
26	NON SELECTED USER CLEARING
27	DESTINATION OUT OF ORDER
28	INCOMPLETE NUMBER
29	FACILITY REJECTED
30	RESPONSE TO STATUS ENQUIRY
31	NORMAL, UNSPECIFIED
34	NO CIRCUIT/CHANNEL AVAILABLE
38	NETWORK OUT OF ORDER
41	TEMPORARY FAILURE
42	SWITCHING EQUIPMENT CONGESTION
43	ACCESS INFORMATION DISCARDED
44	REQUESTED CHANNEL NOT AVAIL.
47	RESOURCES UNAVAILABLE, UNSPEC.
49	QUALITY OF SERVICE UNAVAILABLE
50	REQ. FACILITY NOT SUBSCRIBED
55	INCOMING CALLS BARRED IN CUG
57	BEARER CAPABILITY NOT AUTH.
58	BEARER CAP. NOT PRES.AVAIL.
63	SERVICE OR OPTION NOT AVAIL.
65	BEARER SERVICE NOT IMPLEM.
68	ACM EQUAL OR GREATER ACM-MAX
69	REQ. FACILITY NOT IMPLEMENTED
70	ONLY RESTRICTED DIGITAL INFORMATION BEARER CAP. AVAIL.

Number	Description
79	SERVICE OR OPTION NOT IMPL.
81	INVALID TI
87	USER NOT MEMBER OF CUG
88	INCOMPATIBLE DESTINATION
91	INVALID TRANSIT NETWORK SELECTION
95	SEMANTICALLY INCORRECT MESSAGE
96	INVALID MANDATORY INFORMATION
97	MESSAGE TYPE NOT IMPLEMENTED
98	MESSAGE NOT COMP W. CC STATE
99	IE NOT IMPLMENTED
100	CONDITIONAL IE ERROR
101	MESSAGE NOT COMP W. CC STATE
102	RECOVERY ON TIMER EXPIRY
111	PROTOCOL ERROR, UNSPECIFIED
127	INTERWORKING, UNSPECIFIED
	Notification
300	Called party barred incoming call

7.7 Release cause for last Supplementary Service Call (AT+CEER)

Number	Description
	Error Codes
0	No error (default)
1	UnknownSubscriber
9	IllegalSubscriber
10	BearerServiceNotProvisioned
11	TeleserviceNotProvisioned
12	IllegalEquipment
13	CallBarred
15	CUGReject
16	IllegalSSOperation
17	SSErrorStatus
18	SSNotAvailable
19	SSSubscriptionViolation
20	SSIncompatibility
21	FacilityNotSupported
27	AbsentSubscriber
29	ShortTermDenial
30	LongTermDenial
34	SystemFailure
35	DataMissing
36	UnexpectedDataValue
37	PWRegistrationFailure
38	NegativePWCheck
43	NumberOfPWAttemptsViolation
71	UnknownAlphabet
72	USSDBusy
126	MaxNumsOfMPTYCallsExceeded
127	ResourcesNotAvailable
	Problem Codes
300	Unrecognized Component

Number	Description
301	Mistyped Component
302	Badly Structured Component
	<i>Invoke Problem Codes</i>
303	Duplicate Invoke ID
304	Unrecognized Operation
305	Mistyped Parameter
306	Resource Limitation
307	Initiating Release
308	Unrecognized Linked ID
309	Linked Response Unexpected
310	Unexpected Linked Operation
	<i>Return Result Problem Codes</i>
311	Unrecognize Invoke ID
312	Return Result Unexpected
313	Mistyped Parameter
	<i>Return Error Problem Codes</i>
314	Unrecognized Invoke ID
315	Return Error Unexpected
316	Unrecognized Error
317	Unexpected Error
318	Mistyped Parameter

7.8 List of PIN-requiring AT Commands

PIN required commands	Required PIN
AT^SACM	PIN 1, PIN 2
AT^SCID	PIN 1
AT^SCNI	PIN 1
AT^SCTM	PIN 1
AT^SDLD	PIN 1
AT^SLCD	PIN 1
AT^SLCK	PIN 1
AT^SNFD	PIN 1
AT^SNFI	PIN 1
AT^SNFM	PIN 1
AT^SNFO	PIN 1
AT^SNFS	PIN 1
AT^SNFV	PIN 1
AT^SNFW	PIN 1
AT^SPBC	PIN 1
AT^SPBG	PIN 1
AT^SPBS	PIN 1
AT^SPLM	PIN 1

PIN required commands	Required PIN
AT^SPLR	PIN 1
AT^SPLW	PIN 1
AT^SPWD	PIN 1, PIN 2
AT^MONP	PIN 1
AT^MONI	PIN 1
AT+CACM	PIN 1, PIN 2
AT+CALA	PIN 1
AT+CAMM	PIN 1, PIN 2
AT+CAOC	PIN 1
AT+CCFC	PIN 1
AT+CCLK	PIN 1
AT+CEER	PIN 1
AT+CFUN	PIN 1
AT+CHLD	PIN 1
AT+CHUP	PIN 1
AT+CIMI	PIN 1
AT+CLCC	PIN 1
AT+CLCK	PIN 1
AT+CLIP	PIN 1
AT+CLIR	PIN 1
AT+CMUT	PIN 1
AT+COPN	PIN 1
AT+COPS	PIN 1
AT+CPBR	PIN 1
AT+CPBS	PIN 1
AT+CPBW	PIN 1
AT+CPUC	PIN 1, PIN 2
AT+CPWD	PIN 1, PIN 2
AT+CRC	PIN 1
AT+CREG	PIN 1
AT+CRSM	PIN 1
AT+CSSN	PIN 1
AT+ILRR	PIN 1
AT+VTS	PIN 1

PIN required commands	Required PIN
AT^SMGL	PIN 1
AT^SMGO	PIN 1
AT^SMGR	PIN 1
AT+CMGC	PIN 1
AT+CMGD	PIN 1
AT+CMGF	PIN 1
AT+CMGL	PIN 1
AT+CMGR	PIN 1
AT+CMGS	PIN 1
AT+CMGW	PIN 1
AT+CMSS	PIN 1
AT+CNMA	PIN 1
AT+CNMI	PIN 1
AT+CPMS	PIN 1
AT+CSCA	PIN 1
AT+CSCB	PIN 1
AT+CSDH	PIN 1
AT+CSMP	PIN 1
AT+CSMS	PIN 1
AT^STCD	PIN 1
AT+CXXCID	PIN 1

7.9 List of *# codes

The following commands can be used with ATD (for voice calls only, i.e. use ‘;’)

*# code	Functionality	Possible response(s)
*#06#	Query IMEI:	<IMEI> OK
**04[2]*oldPin*newPin[2]*newPin[2]#	Change SIM pwd:	+CME ERROR: <err> / OK
**05[2]*unbKey*newPin[2]*newPin[2]#	Change/Unblocking SIM pwd:	OK
[]03[*][ZZ]*oldPw*newPw*newPw#	Registration of net password:	
*#30#	Interrogation CLIP	+CLIP : <n>,<m> OK (p 63)
*#31#	Interrogation CLIR	+CLIR : <n>,<m> OK (p 64)
*#76#	Interrogation COLP	+COLP : 0,<m> OK
*#77#	Interrogation COLR	+COLR : 0,<m> OK
(choice of *,#,*,*,*,###)21*DN*BS#	Act/deact/int/reg/eras CFU	^SCCFC : <reason>, <status>, <class> [...] like +CCFC *) (p 53)
(choice of *,#,*,*,*,###)67*DN*BS#	Act/deact/int/reg/eras CF busy	
(choice of *,#,*,*,*,###)61*DN*BS*T#	Act/deact/int/reg/eras CF no reply	
(choice of *,#,*,*,*,###)62*DN*BS#	Act/deact/int/reg/eras CF no reach	
(choice of *,#,*,*,*,###)002*DN*BS*T#	Act/deact/int/reg/eras CF all	
(choice of *,#,*,*,*,###)004*DN*BS*T#	Act/deact/int/reg/eras CF all cond.	
(choice of *,#,*,*)43*BS#	Activation/deactivation/int WAIT	
(choice of *,#,*,*)33*Pw*BS#	Act/deact/int BAOIC	+CCWA : <status>, <class> *) ^SCLCK : <fac>, <status>, <class> [, ...] like +CLCK *) (p 60)
(choice of *,#,*,*)331*Pw*BS#	Act/deact/int BAOIC	
(choice of *,#,*,*)332*Pw*BS#	Act/deact/int BAOIC exc.home	
(choice of *,#,*,*)35*Pw*BS#	Act/deact/int. BAIC	
(choice of *,#,*,*)351*Pw*BS#	Act/deact/int BAIC roaming	
#330*Pw*BS#	Deact. All Barring Services	
#333*Pw*BS#	Deact. All Out.Barring Services	
#353*Pw*BS#	Deactivation. All Inc.Barring Services	
[C]...[C]#	Send USSD message	+CME ERROR: <err> / OK
C[C] in call	Call hold and multiparty	+CME ERROR: <err> / OK
C[C] (excluded 1[C])	Send USSD message	+CME ERROR: <err> / OK

Meaning of Abbreviations:

ZZ	type of supplementary services:	Barring services	330
		All services	----
DN	dialling number: string of digits 0-9		
BS	basic service: Voice		11
		Sms	16
		Fax	13
		Sms+fax	12
		Voice+fax	19
		Voice+sms+fax	10
		Data circuit asynchron	25
		Data circuit synchron	24
		PAD	27
		packet	26
		data circuit async.+PAD	21
		data circuit sync.+packet	22
		data circ.async+sync.+PAD+packet	20
		all services	----
T	time in seconds		
Pw	net password		
C	character of TE character set		

*) ^SCCFC, ^SCCWA, ^SCLCK: The output depends on teleservices which are coded in <class>. If no teleservice or bearer service is active for a given interrogation a “7” is generated as default value for the <class> parameter. In addition only for every active class in the network one output line will be created. ^SCCFC and ^SCLCK are modified by giving an additional <reason> or <fac> in front of the regular output string generated by the standard commands +CCFC and +CLCK.

+COLP, +COLR: <m>
0 not active
1 active

+CCWA: <status>
0 not active
1 active
<class>
like +ccfc <class> (p 53)

7.10 Alphabet tables

This section provides tables for the special GSM 03.38 alphabet supported by the ME (see chapter „Supported character sets“, pg 10).

Character table of default GSM 03.38 alphabet (7 Bits per character):					b7	0	0	0	0	1	1	1	1
					b6	0	0	1	1	0	0	1	1
					b5	0	1	0	1	0	1	0	1
b4	b3	b2	b1		0	1	2	3	4	5	6	7	
0	0	0	0	0	@	Δ	SP	0	i	P	ç	p	
0	0	0	1	1	£	—	!	1	A	Q	a	q	
0	0	1	0	2	\$	Φ	„	2	B	R	b	r	
0	0	1	1	3	¥	Γ	#	3	C	S	c	s	
0	1	0	0	4	è	Λ	α	4	D	T	d	t	
0	1	0	1	5	é	Ω	%	5	E	U	e	u	
0	1	1	0	6	ù	Π	&	6	F	V	f	v	
0	1	1	1	7	ì	Ψ	'	7	G	W	g	w	
1	0	0	0	8	ò	Σ	(8	H	X	h	x	
1	0	0	1	9	Ç	Θ)	9	I	Y	i	y	
1	0	1	0	10 /A	LF	Ξ	*	:	J	Z	j	z	
1	0	1	1	11 /B	Ø	¹⁾	+	;	K	Å	k	å	
1	1	0	0	12 /C	ø	Æ	,	<	L	Ö	l	ö	
1	1	0	1	13 /D	CR	æ	-	=	M	Ñ	m	ñ	
1	1	1	0	14 /E	Ä	ß	.	>	N	Ü	n	ü	
1	1	1	1	15 /F	ä	É	/	?	O	§	o	à	

¹⁾ This code is an escape to the following extension of the 7 bit default alphabet table.

Extension table of GSM 7 bit default alphabet					b7	0	0	0	0	1	1	1	1
					b6	0	0	1	1	0	0	1	1
					b5	0	1	0	1	0	1	0	1
b4	b3	b2	b1		0	1	2	3	4	5	6	7	
0	0	0	0	0									
0	0	0	1	1									
0	0	1	0	2									
0	0	1	1	3									
0	1	0	0	4		^							
0	1	0	1	5								²⁾	
0	1	1	0	6									
0	1	1	1	7									
1	0	0	0	8			{						
1	0	0	1	9			}						
1	0	1	0	10 /A	³⁾								
1	0	1	1	11 /B		¹⁾							
1	1	0	0	12 /C				[
1	1	0	1	13 /D				~					
1	1	1	0	14 /E]					
1	1	1	1	15 /F			\						

In the event that an MS receives a code where a symbol is not represented in the above table then the MS shall display the character shown in the main default 7 bit alphabet table.

1) This code value is reserved for the extension to another extension table. On receipt of this code, a receiving entity shall display a space until another extension table is defined.

- 2) This code represents the EURO currency symbol. The code value is that used for the character 'e'. Therefore a receiving entity which is incapable of displaying the EURO currency symbol will display the character 'e' instead.
- 3) This code is defined as a Page Break character and may be used for example in compressed CBS messages. Any mobile which does not understand the 7 bit default alphabet table extension mechanism will treat this character as Line Feed.